



Integrati Programming Reference Manual

V17.0

**Current to Controller Firmware V17.0.3
See 'Integrati Controller Firmware Versions' Notice on Page 3.**

Document Part No: 636001P

Additional Reading

NOTE: A comprehensive list of supporting documentation is provided immediately after the Table of Contents.

Integriti Programming via LCD Terminal-Generic Operations

Provides overviews and descriptions of the following LCD Terminal operations:

- Generic programming operations
- Logged-off operations
- The Information Menu
- The Test Menu
- The Service Menu

NOTE: Programming menus provided on an LCD Terminal are primarily intended for testing and commissioning purposes. Depending on the system settings, changes made via the LCD Terminal may be overwritten by the Integriti software.

Reporting Format Mapping Tables

These tables provide details of the Input mapping schemes for alarm reporting formats such as:

Contact ID	SIMSII	IRfast	SIA
------------	--------	--------	-----

Integriti Software Manuals

- Interface Elements for Integriti
- System Configuration Handbook
- A range of guides covering specific Integriti Software features.

INNER RANGE recommends that all Inner Range systems be installed & maintained by FACTORY CERTIFIED TECHNICIANS.

For a list of Accredited Dealers in your area refer to the Inner Range Website.

<http://www.innerrange.com>

DISCLAIMER

- 1) The manufacturer and/or its agents take no responsibility for any damage, financial loss or injury caused to any equipment, property or persons resulting from the correct or incorrect use of the Integriti system and its peripherals. The purchaser assumes all responsibility in the use of the Integriti system and its peripherals.
- 2) Whilst every effort has been made to ensure the accuracy of this manual, Inner Range Pty Ltd assumes no responsibility or liability for any errors or omissions. Due to ongoing development the contents of this manual is subject to change without notice.

Please send any comments on this manual to:
publications@innerrange.com

Table of Contents

Integriti Controller Firmware & Integriti Software Versions	3
Related documentation and further reading	8
Recommended Programming Sequence	9
Common Options	9
Alarm System.....	9
Module Programming	10
Access Control	10
User Programming	11
Reporting.....	12
Miscellaneous Options & Automation	12
Generic Programming Operations	13
Permission programming (Qualify Pairs)	13
Action programming	16
Action Type and Qualification settings	17
Entity State Valid/Invalid conditions.....	19
Action Entity settings	21
AREA or AREA LIST	21
AUXILIARY or AUXILIARY LIST	21
DOOR or DOOR LIST	22
FLOOR (LIST) and LIFT CAR (LIST)	24
TRIGGER INPUT.....	24
SET AREA USER IS IN (User Location).....	26
SET AREA USER COUNT (Number of Users in Area)	26
SET INPUT COUNTERS.....	26
SIREN CONTROL	27
SET TIMER VARIABLE	28
SET GENERAL VARIABLE.....	28
CONTROL AIR-CONDITIONING.....	29
MACRO CONTROL	30
ISOLATE / SOAK TEST AN INPUT	30
COMMS TASK CONTROL.....	31
GRANT AMNESTY.....	31
SET AIR-CONDITIONER TEMPERATURE	32
CALL FLOOR	32
SET ANALOGUE AUXILIARY / AUXILIARY LIST	33
EXECUTE ACTION LIST	33
SET ANALOGUE INPUT.....	33
MAKE XMIT FOR AREA (Commissioning Report).....	34
EN FUNCTION	35

RESET PANEL.....	35
OVERRIDE DOOR LOCKED	36
CONTROL LOCKER.....	36
BATTERY TEST.....	37
Users and Permissions	38
User Codes.....	38
Permission Groups.....	44
Lists	46
Groups	47
MENU GROUPS	47
PROCESS GROUPS.....	51
Integriti Default Process Groups. Typical Applications & Contact ID Event Codes	51
Cards.....	60
ADD CARD.....	61
ADD BATCH OF CARDS	61
Card Templates.....	62
RF Remotes	62
RF Remote Templates	63
RF Remote operations supported	65
Apartments.....	65
User Qualifications	66
Times.....	69
Time and Date	69
Time Periods.....	69
Schedules.....	71
Holidays.....	72
LCD Messages.....	72
Installer	74
General Controller Programming	76
Controller – Module Details.....	76
Controller – Connection Details.....	87
Input Programming.....	90
Area Programming	93
Modules	104
LCD Terminal	104
Integriti Colour Graphic Terminal (Prisma).....	110
Expander	116
Radio Expander (RF/Wireless Expander)	118
Reader Module (2 Door)	122
Intelligent Reader Module.....	132

Concept Intelligent 4-Door Access Module Notes.....	140
LAN Power Supply Module.....	141
Communications Programming.....	145
Comms Tasks	145
Important Upgrade Notes.....	145
Comms Task Status Monitoring.....	146
INTEGRITI FORMAT	148
DIGITAL DIALLER FORMATS.....	153
Dialler Common Settings.....	153
Dialler Format Settings	157
GSM Comms Task Notes.....	159
GSM FORMAT	160
SMS Control	166
SMS Control Command Syntax.....	168
AUTOMATION FORMAT	170
EMS Comms Task Notes.....	172
EMS FORMAT.....	173
Introduction to Securitel Comms Task.....	176
SECURITEL FORMAT.....	177
Introduction to the Intercom Comms Task.....	178
INTERCOM FORMAT	179
Intercom Comms Task Kenwei Interface.....	181
Intercom Comms Task Aiphone Interface.....	181
BMS Comms Task Notes.....	182
BMS FORMAT.....	182
EN 32 PIN FORMAT	184
SKYTUNNEL FORMAT	185
E-MODEM FORMAT	187
PEER REPORTING FORMAT	188
INTREPID FORMAT.....	189
ARC (Alarm Reporting & Control) FORMAT.....	190
NEMTEK FORMAT	192
MODBUS FORMAT	193
Telephone Numbers.....	194
Telephone Number Lists. <i>See “Users and Permissions” – “Lists”</i>	194
Network Interface Controllers	194
DNS Names	195
System Options Programming.....	196
Memory Configuration.....	196
Auxiliary Options	196
EOL Configurations	196

Access Control	198
Entity Types and Groups	198
DOOR TYPES	198
QUALIFIED DOOR TYPES	200
INTERLOCKS	201
LIFT TYPES	202
QUALIFIED LIFT TYPES	203
LIFT GROUPS	204
CHALLENGE DEFINITIONS	205
Access Control Entities	208
Card Formats	208
Photo ID Designs	213
Locations	213
Door Programming	214
Roller Doors	222
Lift Car Programming	223
Floor Programming	225
Locker Programming	226
Locker Bank Programming	226
Bulk Create Lockers	227
Automation and Logic Functions	228
Auxiliary Lists. See “Users and Permissions”, “Lists”	228
Compound Entities	228
Foreign Entities	229
Automation Points	230
Named Actions	233
Action Lists	235
Macros	235
General Variables	237
General Timers	237
Calibrations	238
Comparisons	240
Air-conditioning	242

Related documentation and further reading

The following documentation provides additional detail and application-specific installation, programming and commissioning information for the Integrati system.

Note that this list does not include:

- The Integrati hardware installation manuals that are provided for each product.
- The Integrati system software manuals that cover both generic and application-specific configuration and operation details of software features.

Documents can be obtained from the ‘Technician Downloads’ page in the ‘Training & Support’ portal on the Website.
<http://www.innerrange.com>

<u>DOCUMENT</u>	<u>FORMAT</u>	
Manuals		
Integrati Programming via LCD Terminal - Generic Operations	pdf	
Integrati Routine Maintenance	pdf	
630026I Integrati Elite LCD User-Basic	pdf	
636000U Integrati Graphic User	pdf	
Tables		
Integrati Programming LAN Module Input-Output_assignments	pdf	
Integrati ContactID Input Mapping	pdf	xlsx
Integrati ContactID SIMS2 Input Mapping	pdf	xlsx
Integrati C3k Compatible IRfast Mapping	pdf	xlsx
Integrati Securitel Comms Task Input Map		xlsx
Integrati SIA DECIMAL Mapping		xlsx
Integrati SIA HEX Mapping		xlsx
Application Notes		
Integrati Application Note - EN50131 Recommended programming.	pdf	
Integrati App Note - Aperio Integration.	pdf	
Integrati App Note - Locker Configuration	pdf	
Integrati Application Note – Battery Testing On 2A PSU	pdf	
Integrati-Inception Inovonics RF Expander Application Note	pdf	
Integrati Application Note – Tecom™ Reader Integration	pdf	

Recommended Programming Sequence

The Recommended Programming Sequence provides a step-by-step approach to programming the main features in the product. It serves as a general guide only and lists the more common programming areas and options which are likely to be considered when programming a typical system. Where specific options are listed, they are listed for consideration and the installer must determine whether or not the option is relevant to the particular entity and application being programmed.

Power-up Checks.

Power Up the System and check LAN communications

Check that all Terminals are operational and default messages are being shown on the displays.

Check the system Time and Date. [LCD Terminal, MENU, 3]

Check that all Modules installed on the LAN are powered up and communicating with the Control Module. This can be done with the software or from a Terminal. To use a Terminal, logon then press MENU, 1, 8, OK then use the v & ^ keys to scroll through the Modules.

Common Options

General System options [Hardware > Control Module > Module Details]

Locale Settings. Select the Country.

General Behaviour. AC Holdoff time and PIN Code Length options.

Daylight Saving.

Battery Testing.

Time Report.

LAN Module. LAN Fail Delay, Battery Test time and Battery Installation date.

Times

One or more of the 'Times' features may need to be programmed ready for use in other appropriate programming options.

- Time Periods [System > Time Periods]
- Schedules [System > Schedules]
- Holidays [System > Holidays]

Typical applications:

- User or system operations are required to be restricted or altered according to a specific time or time period/s.
- Doors/Lifts/Floors are required to be in free access at nominated times.
- Automation (Lighting, HVAC, etc.) operations may require time parameters in their logic.

Alarm System

Inputs. [Intruder > Inputs]

Input Name.

Optional Actions. For any functionality where an input is required to directly control, or otherwise manipulate another entity. e.g. Arm/disarm via Keyswitch, Doorbell button, Home/Building automation, etc.

Options. No Test on Exit, Auto-Isolate on exit, Zone Test Enabled & No Review.

Process Groups. [Intruder > Process Groups]

The default Process Groups cover the vast majority of input applications.

You may need to edit a Process Group or program additional Process Groups for special input functions such as Pulse Count Inputs, Swinger Shutdown, Plant monitoring, etc.

Auxiliary Lists. [Automation > Auxiliary Lists]

Where any action (e.g. Input Optional Action, Area Action or Named Action) is required to control multiple Auxiliaries, an Auxiliary List may be programmed and assigned to the action instead of an individual Auxiliary.

e.g. To control the pulsing beeper auxiliary on a number of LCD Terminals.

To provide two or more strobe outputs in an Area.

Areas. [Intruder > Areas]

Area Name.

Reporting. Report Openings, Report Closings, Report 24Hr Open/Close.

General. Sub-Area, Arm Self-Test Count.

Entry/Exit. Entry delay &/or Exit delay.

Sirens.	Siren Modules, Siren Time, Internal Siren mode & External Siren mode.
Actions.	Close Action, Entry Action, Exit Action. Area Actions can also be useful for Building/Home Automation operations where Area status (e.g. Close or Unseal) can be used as a trigger.
Process Alarm Action.	Process Action 1 (Strobe)
Inputs.	Assign the relevant Inputs to the Area using an appropriate Process Group for each Input.

NOTES:

- 1) At least one Area will have System Inputs assigned. There are two ways of assigning System Inputs to Areas; individually in the same way that Zone Inputs are assigned or collectively by using the “Assign System Inputs” Wizard.
- 2) If access control is employed in the system, remember to include the System Inputs and any Zone Inputs required for access control monitoring. e.g. Door Forced, DOTL, Reader Invalid, Reader Fault, etc.

Module Programming

See the table in ‘Modules’ programming for details of which products are covered by each of the 4 Module types below.

LCD Terminals [Hardware > LCD Terminal] or Graphic Terminals [Hardware > Graphic Terminal]

Name.

General. Associated Area, Associated Area List, Exit Display, Exit Beep, LED Mode.

Logged Off Display.

Logged Off Keys.

Access Control. If the Terminal is the primary device used to access a Door, etc.

Expanders [Hardware > Expander]

LAN Module. Battery Test time and Battery Installation date if an Integrati Smart PSU is connected.

Wireless Expanders [Hardware > Radio Expander]

Remotes. Enable RF Remotes.

Sensor Registry. To enroll RF Sensors.

Readers [Hardware > Reader] or Intelligent Readers [Hardware > Intelligent Reader]

Readers. Only if advanced options &/or Lift access control required. Normally done via Door programming.

Door Access Control. Only if advanced options are required. Normally done via Door programming.

Lift Access Control. Only if Lift access control is required.

Offline Operation. Offline Function. REX/REN button options.

LAN Module. Battery Test time and Battery Installation date if an Integrati Smart PSU is connected.

Access Control***Door Types [Access Control > Door Types]***

The default Door Types cover the majority of access control applications.

You may require additional Door Types or Qualified Door Types for special access control functions such as Dual User or Anti-Passback, etc. or when a Door Type is only to be valid under certain time &/or status conditions.

Lift Types [Lifts > Lift Types]

If Lift access control is required, one or more Lift Types will need to be programmed to define Lift access operation.

Qualified Lift Types may also be required when a Lift Type is only to be valid under certain time &/or status conditions.

Refer to Lift Type programming in this document for details.

Card Formats [Access Control > Card Formats]

The default Card Formats cover the majority of credential data formats likely to be encountered.

Additional Card Formats can be programmed if required and if supported by the system.

Doors [Access Control > Doors]

Door Name.

Door Programming. Programming the relevant parameters on the ‘Door Programming’ tab is normally all that is required for typical door access control applications.

- Module, Relay, Door Type and Reader are mandatory.
- Area, Arm Mode & Enable Reed Input are commonly used. (e.g. For Area control, anti-passback, user tracking, door forced, DOTL, etc.)
- Enable Tongue Input and Location are less common.

The 'Hardware Options...' and Reader Details buttons can be used to program additional options for those devices. 'Reader Details' allows the Card Format and options for Card+PIN and other Reader purposes to be programmed. If more advanced options are required, return to 'Readers' &/or 'Door Access Control' in Module programming. i.e. The relevant Reader Module, Intelligent Reader Module or IAC.

Advanced. The 'Advanced' tab provides for disability unlock time, DOTL time, anti-passback options, free access options, interlocking and many other features if required.

Lift Cars [Lifts > Lift Cars] / Lift Floors [Lifts > Lift Cars] / Lift Groups [Lifts > Lift Cars]

The way in which Lift access control is programmed will depend on the low-level or high-level interface method used. Refer to Lift, Lift Floor and Lift Group programming in this document for details.

User Programming

Menu Groups. [Intruder > Menu Groups]

The default Menu Groups cover typical User menu requirements. You may need to edit or add Menu Groups for different types of Users &/or for additional functionality. e.g. Defer arming, Dual User, Remote access, etc.

Lists

Area Lists. [Intruder > Area Lists]

Door Lists. [Access Control > Door Lists]

Floor Lists. [Lifts > Floor Lists]

Lift Car Lists. [Lifts > Lift Car Lists]

Program a name and the entities allowed in one or more Area, Door, Floor & Lift Car Lists according to the permissions required for the different types of Users in your system.

Lists can be assigned directly to a User, or via the User's Permission Group to define their permissions. Lists can also be used in other parts of the system programming to define restrictions or the entities to be controlled/manipulated in an operation. e.g. In Terminal programming, Actions, Comms Tasks, Lift Cars, etc.

Permission Groups. [Home / Intruder / Access Control > Permission Groups]

Program a name and the entities allowed in one or more Permission Groups according to the permissions required for the different types of Users in your system. Permission Groups may then be assigned to a User to define their permissions.

A Permission Group may typically include a Menu Group and a combination of Lists &/or individual entities to define a User's permissions. Each entity may be assigned a qualifier to specify when it is allowed or not allowed and options to define the type of control/access that is allowed.

Card Templates [Access Control > Card Templates]

If Readers are used in the system, one or more Card Templates must be programmed.

A Card Template defines a Card Format and the Site Code (if used) for a particular batch of cards or other access credentials, and is then used when assigning a card to a User.

Cards [Access Control > Cards]

Batches of Cards, or individual Cards may be pre-enrolled in the system so that they are already present for when the User programming is done. Refer to Cards programming in this document for details.

RF Remote Templates [Access Control > RF Remote Templates]

If Wireless RF Remotes are used in the system, one or more RF Remote Templates must be programmed.

An RF Remote Template defines button operations and other functionality relevant to the particular product, and is then assigned to a pre-enrolled Remote or used when assigning an RF Remote to a User from Review.

RF Remotes [Access Control > RF Remotes]

RF Remotes may be pre-enrolled in the system so that they are already present for when the User programming is done. Refer to RF Remote programming in this document for details.

Users. [Home / Intruder > Users]

First/Second Name.

Security PIN. If PIN codes are required.

Cards.	If any type of credential Readers are used in the system.
RF Remotes.	If Wireless RF Remotes are used in the system.
Primary Permission Grp.	Recommended method of defining all, or most of, a User's permissions via a single entity.
Extra Permissions.	Additional method of defining a User's permissions via a combination of one or more Permission Groups, Menu Groups, Lists &/or individual entities. Each entity may be assigned a qualifier to specify when it is allowed or not allowed and options to define the type of control/access that is allowed.
User Options.	Allows options unique to this User to be defined. e.g. Disabled User, Expiry Date, etc.

Reporting

Reporting. [System > Comms Tasks]

When the system is required to communicate to a Central Monitoring Station, a number of different Communications formats are available. The most suitable format will be determined by the level of security required and the format/s capable of being monitored by the Central Station.

Additional hardware may be required (e.g. TS4000) and additional entities such as Telephone Numbers, Network Interfaces or DNS Names may also need to be programmed.

Refer to Communications Programming in this document for details.

Miscellaneous Options & Automation

In order to keep programming of actions and logic operations as simple and practical as possible, try to choose programming methods best suited to the task.

Check if the task can be achieved through basic features like the "Optional Action" in 'Inputs', "Actions" in 'Areas' &/or by using 'Auxiliary Lists'. *These are all described in "Alarm System" above.*

If the task cannot be achieved with those features, then you may need to use one or more of the more powerful features like 'Named Actions', 'Compound Entities', 'Action Lists', 'General Variables', 'General Timers' and 'Comparisons'. When a task cannot be achieved in a practical manner using one or more of those features, then one or more "Macros" may need to be programmed. *The more commonly used of these features are described below.*

Auxiliaries. [Home / Automation > Auxiliaries]

Depending on their purpose, each Auxiliary used in the system may be programmed to:

- Have a name to identify its location &/or purpose.
- Not have its activity saved to Review.
- Have its current state preserved through a system reset event.

Compound Entities. [Automation > Compound Entities]

Compound Entities enable up to eight different Entities to be logically combined for use as:

- A Qualifier in Permissions.
- A Qualifier in an Action or Named Action.
- A trigger in a Named Action.
- An entity in a Macro.

Named Actions. [Automation > Named Actions]

Named Actions allow almost any operation to be performed in the system by almost any entity (including Users) under a defined set of conditions. If a Named Action is allowed to be controlled by a User, options are provided to restrict its use to nominated Users or types of Users via PIN code or other credential.

e.g. User control of outputs used in lighting and HVAC & other automation controls.
 Auto-arming by time &/or another entity state.
 Control lighting, HVAC or irrigation by time &/or entity status (e.g. Area or Input) parameters.

Action Lists. [Automation > Action Lists]

Action Lists enable up to eight separate Actions to be combined in a single entity for use wherever an Action can be assigned.

Macros. [Automation > Macros]

Macros can be used to perform complex operations that are not practical to achieve via one or more of the other logic and automation features of the product listed above.

Generic Programming Operations

Permission programming (Qualify Pairs)

Permissions allow relevant entities to be paired together to provide a simple and logical, yet flexible and powerful means of defining permissions or qualifying operations.

A Permission consists of a “What” entity (Qualifyee) and an optional “When” entity (Qualifier).

- “What” is an item or a list of items that will be allowed or denied, or that will be processed together in some way. e.g. “What” is typically an entity such as an Area, Area List, Door, Door List, Floor List, Menu Group, Input, User Action, etc.
- “When” is an optional item or list of items that will determine when the permission applies. i.e. Defines when the “What” entity will be used in the processing. e.g. “When” is typically an entity such as a Time Period, Schedule, Area, Input, Comparison, etc. The absence of a “When” entity implies that the permission “Always” applies.

When programming via the Integriti System Designer, Permissions or Qualify Pairs are given different titles depending on where they are applied.

e.g. When applied to User programming, they are called “Extra Permissions” or “Permissions”.

See the list below for how Permissions are described when they are applied to other entities.

In short, a Permission or Qualify Pair determines “what” entity is used in that permission or operation, and “when” it is used.


<u>This Number of Permissions:</u>	<u>Can be assigned to:</u>	<u>Where they are referred to as:</u>
8	Users	Extra Permissions
16	Permission Groups	Permissions
6	LCD Terminals	Extra Restrictions
2	Integriti Graphic Terminals	Extra Restrictions
16	Interlock Groups	Interlocked Entities
8	Qualified Door Types	Door Types
8	Qualified Lift Types	Lift Types
3	Lift Cars	Restricted Floors

Entities relevant to each type of Permission listed above are as follows:

Permission Type	Relevant Entities
Users (Extra Permissions)	Permission Groups. Menu Groups. Door Lists. Doors. Area Lists. Areas. Lift Cars. Lift Car Lists. Lift Floors. Lift Floor Lists.
Permission Groups (Permissions)	Permission Groups. Menu Groups. Door Lists. Doors. Area Lists. Areas. Lift Cars. Lift Car Lists. Lift Floors. Lift Floor Lists.
LCD Terminals (Extra Restrictions)	Menu Groups. Door Types. Area Lists. Areas. LCD Messages.
Graphic Terminals (Extra Restrictions)	Menu Groups. Door Types. Area Lists. Areas. LCD Messages.
Interlock Groups (Interlocked Entities)	Door Lists. Doors. Area Lists. Areas. Auxiliaries. Inputs.
Qualified Door Types (Door Types)	Door Types.
Qualified Lift Types (Lift Types)	Lift Types.
Lift Cars (Restricted Floors)	Lift Floor Lists. Lift Floors.

Regardless of which of the above entities the Permissions are assigned to, a dialog box like the one pictured below is displayed.

- The “Allow or Deny”, “What”, “When” and “Is Valid/Invalid” columns are always available, regardless of the entity being programmed.
- The “Options” column is only available in User, Permission Group, LCD Terminal and Graphic Terminal programming, but might not be active, depending on the type of entity selected for the “What” parameter.



Option	Initial Screen / Option	Description
Allow / Deny		Select whether the entity that is to be defined in this Permission, is to be “Allowed” or “Denied” by this Permission. e.g. If a Door List is to be defined and this option is set to “Allow”, then those Doors will be allowed.
What	Door Door List Area Area List Lift Floor Lift Floor List Lift Car Lift Car List Menu Group Permission Group User Door Type Lift Type Auxiliary Aux List Input LCD Message	Select the entity to be used as the “What” for this Permission. The options listed opposite are the entities most likely to be used in this setting, depending on the type of Permission being programmed. <i>See table on the previous page.</i> When you click on the “+ Add” button a search window will open to allow an entity to be selected. The entity types relevant to the Permission being programmed will automatically be displayed in the “List Filters” column on the left-hand side. Other entity types may be accessed via the “Everything” filter, however, this option should be used with extreme caution or on advice from Technical Support and should be tested thoroughly, as you might choose an entity type that is not relevant to the Permission and will not work.
Options		Depending on the type of “What” chosen, options for that entity may then be available. Options are provided for Door, Door List, Area or Area List.
	DOOR / DOOR LIST OPTIONS Permit Entry Permit Exit	Entry / Exit Options Access via an Entry Reader is permitted. Access via an Exit Reader is permitted.

	<p>AREA / AREA LIST OPTIONS</p> <p>Arm (On) Disarm (Off) Grant Access to Area.</p>	<p>Area Control Options.</p> <p>On control (Arm) allowed. Off control (Disarm) allowed. Allow a User to gain entry through a Door into an Area that is allowed, regardless of whether the Door is allowed.</p>
When		<p>If the “What” entity selected is not “Always” allowed, you will need to select a “When” entity.</p> <p>e.g. Time Period, Area, etc.</p> <p>Refer to the table in the next option for a list of the entities most likely to be used in this setting.</p>
Is	<p>Valid / Invalid Valid / Invalid Locked / Unlocked</p> <p>All Locked / Any Unlocked Armed / Disarmed All Armed / Any Disarmed Valid / Invalid Valid / Invalid On / Off All On / Any On Valid / Invalid Valid / Invalid Valid / Invalid Valid / Invalid Non-Zero / Zero Running / Not Running Valid / Invalid</p>	<p>If a “When” entity is selected you now need to define how it will qualify the What entity. This is done by choosing the required option from the “Is” column.</p> <p>e.g. If a Time Period is selected and this option is set to “Valid”, then the “What” Entity will only be allowed when the Time Period is Valid.</p> <p>The following table shows the options available for the types of entities that might be used in this option. <i>A more comprehensive list is provided in the table ‘Entity State Valid/Invalid conditions’ in ‘Action Programming’.</i></p> <p>Time Period / Schedule / Holiday User Qualification Door (Unlocked means Door is Unlocked &/or Open. Reed &/or Tongue Sense must be enabled to sense Opened/Closed state) Door List Area Area List Floor (Valid=Secure. Invalid=Free access) Floor List (Valid=All Secure. Invalid=One or more free) Lift Car. (Valid=Button Timer running) Auxiliary. (Valid = ON. Invalid=OFF) Auxiliary List. (Valid=All On. Invalid=Any Off) Zone. (Valid = Sealed. Invalid=Unsealed) User. (Valid=User exists) Macro. (Valid=Macro procedure is running) Comparison. (Valid=Value is \geq Threshold1 & \leq Threshold2) General Variable. (Valid=Current Value is \geq Test Value) General Timer. (Valid=Expiry Time has elapsed) Compound Entity. (Valid= TRUE)</p>

Action programming.

Actions allow an entity to be programmed to provide direct control of another entity. This eliminates the need to program separate intermediate logic operations to link these entities.

Actions can be programmed for entities such as:


- Zones and System Inputs (Alarm Action)
- Areas
- RF Remote Templates (Button Actions)
- RF Expanders (Feedback Action)
- Communications Tasks (Status Actions and Command-back Action)
- Named Actions
- Macros
- Comparisons

If an Action is not required to operate at all times, a Qualifier may be assigned to determine the conditions under which the Action will be enabled and disabled. e.g. A Time Period, an Area State, etc. may be used to qualify the Action.

Note that Action processing only checks the Qualifying entity on assert, not de-assert.

Regardless of which of the above entities an Action is programmed for, when the required Action option is expanded, a dialog box like the one pictured below is displayed.

This example is the “Entry Action” in Area programming.



Programming is described in the following tables.

- The first table describes the programming options common to all actions.
- The second table describes the programming specific to particular entity types.

Actions can be manually generated or tested prior to programming via the ‘Send Action’ operation provided on the Automation tab in the Integriti software.

Action Type and Qualification settings

Option	Initial Screen / Option	Description
Action Type	None Control Area Control Area List Control Aux Control Aux List Control Door Control Door List Secure/Unsecure a floor on a lift car Secure/Unsecure a floor on a lift car list Secure/Unsecure a floor list on a lift car Secure/Unsec a floor list on a lift car list Trigger Input Set Area User is in Set Area User Count Set Input Counters Control Siren Set Timer Variable Set Variable Control Air-conditioning Macro Control Isolate Comms Task Control Grant Amnesty Set Air-conditioner Temperature Call Floor Set Analogue Auxiliary Set Analogue Auxiliary List Execute Action List Set Analogue Input Make XMIT for Area (Area Commissioning Report) EN Function Reset Panel Override Door Locked Control Locker Battery Test	Select the Entity type that will be controlled or adjusted by the entity that you are currently programming. e.g. In Zone Input programming, this is the entity that will be controlled by the Alarm/Seal state of this Input. Control an Area (On/Off/Defer) Control an Area List (On/Off/Defer) Control an Auxiliary Control an Auxiliary List Unlock/Lock/Override a Door Unlock/Lock/Override a Door List Secure/Unsecure a floor on a lift car Secure/Unsecure a floor on a lift car list Secure/Unsecure a floor list on a lift car Secure/Unsecure a floor list on a lift car list Trigger an Input State Adjust the location of a nominated User. Adjust the number of Users currently in an Area. Adjust the current value of an Input event count. Control a Siren Trigger a General timer Trigger a General Variable Control Air conditioning zones Start/Stop a Macro Isolate a nominated Input Comms Task operation. e.g. Restart or Update. Reset all User Anti-Passback Area records. Adjust Temperature setting for a nominated Zone in a nominated Air-conditioning Unit. Enable the Floor Selection button for a nominated Floor on a nominated Lift Car. Set the value of an Analogue Auxiliary output. Set the value of the Analogue Auxiliaries in an Auxiliary List. Control an Action List. Set the value of an Analogue Input. Forces an "XMIT" (reporting) Review entry for one Input, or all Inputs, in a nominated Area as a method of providing a commissioning report to a Central Monitoring Station. Perform the nominated EN50131 operation. Reset or perform a Memory Default on the nominated Controller (ISC or IAC). V4.1 or later only. Set &/or remove an override state of "locked" on the nominated Door/Door List. i.e. Trigger &/or clear a 'lockdown' condition. V4.3.0 or later only. Open/Close a Locker and optionally Allocate/De-allocate a User for the nominated Locker. V16.0.0 or later only. Perform a Battery Test. Three modes are available allowing a single Battery or all Batteries to be tested for a nominated period of time. V17.0.0 or later only.

<p>Select the Entity to control.</p>	<p>The terminology specific to each entity type for this option is shown in the next table.</p>	<p>When the Action Type has been selected, the title of the next field will change accordingly and you can select the entity of that type.</p> <p>e.g. If “Control Aux List” is selected, the title of the next field will change to “Auxiliary List” and you can select from the Auxiliary Lists available in the system.</p>
<p>When Asserted / When De-asserted</p>	<p>The terminology for the options in this setting adjusts for the selected entity.</p> <p>The options specific to each entity type are shown in the next table.</p>	<p>The “When Asserted” option specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>e.g.</p> <ol style="list-style-type: none"> 1. In Zone Input programming, this is the action that will occur when the Input goes into the “Alarm” state. 2. In the Area Close Action it is the action that will occur when the Area is turned On. <p>The “When De-asserted” option specifies the operation that will be performed on the selected entity type when the action is De-asserted.</p> <p>e.g.</p> <ol style="list-style-type: none"> 1. In Zone Input programming, this is the action that will occur when the Input goes into the “Seal” state. 2. In the Area Entry Action it is the action that will occur when the Entry Timer expires, or the Area is turned Off.
<p>Qualify settings</p>		<p>Actions may be qualified by the state of another entity.</p> <p>e.g.</p> <p>An action may be programmed to cause a Door to be unlocked when an Area is Disarmed.</p> <p>A Time Period can then be used in the Qualify options for this action, to ensure that the action will only occur during normal working hours.</p>
<p>Qualifier</p>		<p>Select the Entity to be used to Qualify the Action.</p> <p>e.g. Time Period, Schedule, Area, Auxiliary, etc.</p> <p>The Action will be allowed if the Qualifier is Valid.</p> <p>e.g.</p> <p>Time Period or Schedule is Valid Area is On Door is Locked. etc.</p> <p><i>Refer to the following table for details of what constitutes a valid and invalid condition for entities when used as a Qualifier.</i></p>

Invert Qualifier		<p>Enable this option if the Action is required to be allowed when the Qualifier is NOT Valid (Invalid).</p> <p>e.g. Time Period or Schedule is Invalid Area is Off Door is Unlocked etc.</p> <p><i>Refer to the following table for details of what constitutes a valid and invalid condition for entities when used as a Qualifier.</i></p>
------------------	--	---

Entity State Valid/Invalid conditions.

This table shows what condition/s constitute a 'valid' or 'invalid' state for each entity.

Entities not included in this list, or Entities with N/A means that the entity is not suitable to be used as a Qualifying entity.

For most entities, the 'Invert Qualifier' option simply reverses the conditions for the Valid/Invalid states. In the case of entities that monitor multiple items, the conditions that constitute a valid or invalid state are provided in the two right hand columns.

Entity	Normal		'Invert Qualifier' option enabled.	
	Valid when	Invalid when	Valid when	Invalid when
Input	No State asserted (Sealed)	Any State asserted		
Auxiliary	Auxiliary On	Auxiliary Off		
Area	Area is On	Area is Off		
Door	Locked & Sealed *	Unlocked or Unsealed *		
Lift Car	Button time running	Button timer not running.		
Lift Floor	Floor Secure	Floor Unsecure (free)		
Locker				
Time Period	Valid	Invalid		
Holiday	Valid	Invalid		
Schedule	Valid	Invalid		
Area List	All Areas On	Any Area Off	All Areas Off	Any Area On
Door List	All Doors Valid	Any Door Invalid.	All Doors Invalid	Any Door Valid
Lift Car List	N/A	N/A		
Lift Floor List	All Floors Secure	Any Floor Unsecure	All Floors Unsecure	Any Floor Secure
Auxiliary List	All Auxiliaries On	Any Auxiliary Off	All Auxiliaries Off	Any Auxiliary On
User	User exists	User does not exist		
Permission Group	When being checked #	All other times.		
Comms Task	Running	Idle (Not running)		
Interlock	Interlocked	Not Interlocked		
Compound Entity	Expression = True	Expression = False		
Comparison	<i>See below</i>			
General Timer	Expiry time elapsed	Timer running		
General Variable	Value >= Test Value	Value < Test Value		
Macro	Process running	Process not running.		

*Doors. Sealed (Closed) and Unsealed (Open) condition is determined by Reed &/or Tongue Sense Inputs, if present and enabled. If not enabled, they are ignored.

Permission Groups. A Permission Group is 'Valid' when being checked in the course of processing an event. e.g. A User is attempting an operation at a Terminal, or has presented their card at a Reader. Note that the Permission Group will be considered valid even if the user is denied the

operation. i.e. The valid state only indicates that a user with this permission group has attempted an operation.

Comparisons.

Valid when the Value is \geq Threshold 1 & \leq Threshold 2.

Invalid when the Value is $<$ Threshold 1 or $>$ Threshold 2.

Action Entity settings

The next settings that will be displayed will depend on the Action Type selected above.

AREA or AREA LIST		
Area or Area List to control.		Select the Area or Area List to be controlled by this Action.
Control Type.	Normal Defer Twenty-four Hour Cancel Exit Delay Arm 1 st Stage Arm 2 nd Stage Arm if Secure	Select the type of control to be performed. Normal Arm/Disarm Start Defer Arming Timer Arm Disarm 24 Hour (Tamper) part of Area Cancel Exit Delay timer and Arm. Trigger 1 st Stage Arming. See Note below. Trigger 2 nd Stage Arming. See Note below. Arm the Area/s, but only if all the Inputs are Sealed. (V16.0.0 or later only) If this action fails it will sound the Arm Fail tone programmed for the area/s siren and log the first unsealed input in review. “Arm 1 st Stage” and “Arm 2 nd Stage” are only relevant to systems in which “Enable EN50131 processing” has been selected in the Control Module options and for Areas where the 2 nd Stage delay has been programmed. <i>See Control Module, Process Group and Area programming for more details. Also refer to the Integrati Application note; “Recommended Installation Procedures For EN50131 Grade 3 Compliance.”</i>
When Asserted / When De-asserted	Nothing Arm Disarm Toggle	“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted. “When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted. No action. Area or Area List will be Armed. Area or Area List will be Disarmed. Area will change to the opposite state. (NOTE: Not applicable to Area List Control)
AUXILIARY or AUXILIARY LIST		
Auxiliary or Auxiliary List selection.		Select the Auxiliary or Auxiliary List to be controlled by this Action.
Use Aux List State	False (Unchecked) True (Checked)	This option is only used in conjunction with the “Control Aux List” action and the “Toggle” operation. <i>See “When Asserted/When De-asserted” below.</i> Every Auxiliary in the Auxiliary List will have its state toggled independently. If <u>any</u> Auxiliary in the list is OFF then <u>all</u> Auxiliaries will be set to ON. If <u>all</u> Auxiliaries in the list are ON then <u>all</u> Auxiliaries in the list will be turned OFF.

Control Type	Normal Timed Only Leave Timer	Select the type of control required for this Auxiliary/Aux List. Auxiliary will be controlled as specified in the Action. If a timer is currently running on the Auxiliary, the timer will be restarted with the new timer value. If a timer is currently running on the Auxiliary, it will not be refreshed.
On Time.		If the Auxiliary action requires an On timer, program the timer value in Hours, Minutes and Seconds. A value of up to 65535 Seconds may be programmed. i.e. 18 Hrs, 12 Mins and 15 Seconds.
Off Time.		If the Auxiliary action requires an Off timer, program the timer value in Hours, Minutes and Seconds. Value setting as above.
Auxiliary Action options	Delay On Delay Off Update Dynamic Only	If required, select one or more of the required Auxiliary Action options. Delay On instead of Timed On. Delay Off instead of Timed Off. NOT AVAILABLE V3.0 OR LATER. Changes the internal state, but does not change the real state of the output.
When Asserted / When De-asserted	Nothing Turn On Turn Off Toggle	“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted. “When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted. No action. Auxiliary or Aux List will be turned On. Auxiliary or Aux List will be turned Off. Auxiliary will change to the opposite state. NOTE: For the Toggle option to work with Auxiliary List control, Controller firmware must be V3.0 or later. <i>See “Use Aux List State” option above for details of how the Toggle option operates with Auxiliary List Control.</i>
<u>DOOR or DOOR LIST</u>		V4.2.1 or later recommended.
Door or Door List selection.		Select the Door or Door List to be controlled by this Action:
Unlock time		If the Door or Door List is required to Unlock for a specific period of time, program the timer value in Hours, Minutes and Seconds. A value of up to 65535 Seconds may be programmed. i.e. 18 Hrs, 12 Mins and 15 Seconds.

<p>Override Mode</p>	<p>Normal Override Complex Remove Override Force (Ignore Override)</p>	<p>This option allows an override mode to be selected.</p> <p>A Door/Door List Override allows one or more Doors to be set to the nominated state and forced to remain in that state until the override is removed, or an action or user operation that takes priority over a door's override state occurs.</p> <p>This allows operations such as a lockdown (e.g. all doors locked to prevent intruder progress) or an evacuation (e.g. all doors unlocked to provide free egress) to be implemented.</p> <p>The following options are available to allow nominated events &/or users to ignore a door override if necessary. e.g. A Security Guard may require permission to access a locked-down door or all doors must be unlocked if a fire alarm is triggered.</p> <p>1) The "Ignore Door Override" option can be used in 'Menu Group' programming. 2) A separate 'Control Door/Door List' action can be programmed using the "Force" option for 'Override Mode'.</p> <p>No override. A normal Door action will be performed. Causes the Door state to be overridden in the state this action sets. The underlying Door state is remembered.</p> <p>An override state on the Door is removed. The underlying door state is restored.</p> <p>The door action will be performed even if the Door is overridden. e.g. For a door action that must be performed regardless of the override state. <i>See examples above.</i></p> <p>IMPORTANT NOTES:</p> <p>1) Lockdown. To override one or more Doors to the <u>locked</u> state (i.e. A lockdown condition), the dedicated "Override Door Locked" action is recommended rather than using a 'Control Door' or Control Door List' action.</p> <p>2) Named Action User Interface options. If programming 'User Interface' options for an override action, note that while an override action can be performed from a Terminal, the override state cannot be displayed as there is no 'Sense Entity' available that can represent an override state.</p>
<p>Disarm Areas</p>	<p>V17.0.0 or later only.</p>	<p>Allow disarming any Areas assigned to either side of the Door when unlocking it.</p> <p>NOTE: If the action is being performed via the Integriti mobile app, the User will require permission to disarm the area on the other side of the Door.</p>

When Asserted / When De-asserted	Nothing Lock Unlock Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>NOTE: The “When De-asserted” option <u>must not</u> be used if an ‘Override Mode’ has been selected. To set and remove an override, program two separate actions and assign the appropriate setting only in the “When Asserted” option in each action.</p> <p>No action. Door or Door List will be Locked. Door or Door List will be Unlocked. Door will change to the opposite state. (NOTE: Not applicable to Door List Control)</p>
<u>FLOOR (LIST) and LIFT CAR (LIST)</u>		
Floor or Floor List		Select the Floor or Floor List to be controlled by this Action.
Lift Car or Lift Car List		Select the Lift Car or Lift Car List to be controlled by this Action.
Cancel Action Timer		Select this option if this action is to cancel any Floor selection button timers currently running for this Floor.
Floor Time		<p>If the Floor or Floor List is required in Free Access for a specific period of time, program the timer value in Minutes and Seconds.</p> <p>A value of up to 255 Seconds (4 mins 15 secs) may be programmed.</p>
When Asserted / When De-asserted	Nothing Secure Unsecure Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Floor or Floor List for the nominated Lift Car or Lift Car List will be Secured. Floor or Floor List for the nominated Lift Car or Lift Car List will be put into Free Access. Floor for nominated Lift Car will change to the opposite state. (NOTE: Not applicable to Floor List or Lift Car List Control)</p>
<u>TRIGGER INPUT</u>		
Input to trigger		<p>Select the Input to be controlled by this Action.</p> <p>“Trigger Input” normally causes an input to briefly go into the nominated state and then return to its previous state. e.g. The Alarm state is asserted just long enough to cause an alarm to be reported in an Area. An option is also available to allow the input to remain in the nominated state. See “Update State” below.</p>

<p>State to trigger</p>	<p>Alarm Mask Orientation Fault Range Tamper Low Tamper High Tamper Zone Self-test Failure Low Battery Encryption failure Poll failure Spare Soaking Soak Test Fail Isolate</p>	<p>Select the Input state to be triggered.</p> <p>The “Alarm” state will normally be chosen.</p>
<p>Update State</p>	<p>False (unchecked) True (Checked)</p>	<p>Selects whether the Action will cause the nominated state selected above to be a momentary or permanent change.</p> <p>When the action is executed the Input will only have an “edge” generated for the Input and will then return to the previous state.</p> <p>The Input will remain in the selected state after the Action has been executed. i.e. An “edge” is generated for the Input and then the Input is left in the nominated State. Physical Zone Inputs: The input will be triggered into the nominated state, but if the physical state of the input changes, the input will revert to that physical state. e.g. If C01:Z01 is triggered into Tamper while it is physically in the seal state, then the physical input goes in alarm, the input state will be updated from Tamper to Alarm. Non-physical Inputs (e.g. C01:Z33): Will only leave the nominated state when another Trigger Input action is performed on the Input with a Restore or Toggle operation selected. <i>See below.</i> e.g. If C01:Z33 is in the Alarm and Isolate states and a Trigger Input action is performed for a Restore operation on the Alarm state, the input will only remain in the Isolate state.</p>
<p>Operation When Asserted / When De-asserted</p>	<p>Nothing Trigger Restore Toggle</p>	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The nominated Input State will be Triggered. The nominated Input State will be Restored. The nominated Input State will change to the opposite state.</p>

<u>SET AREA USER IS IN (User Location)</u>		This action is used to put a User in a particular Area. This will also cause Area User counts to be updated (i.e. Area User count for the Area the User is in will be decremented and Area User count for the Area the User is put in, will be incremented. As a result, one or more Area User count actions may be invoked if required.
User.		Select the User to whom the nominated Area will be assigned.
Area.		Select the Area to be assigned to the User by this Action.
Don't update Area User Counts		Enable this option if you do not want the Area User Count to be incremented/decremented when the User location is altered.
When Asserted / When De-asserted	Nothing Set	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The nominated Area will be set as the Area the User is in.</p>
<u>SET AREA USER COUNT (Number of Users in Area)</u>		This action is used to set the number of Users in Area to a number. Area User count action will not be tested.
Area.		Select the Area to be adjusted by this Action.
User Count		Enter the value that the Area Count will be set to when the Action is triggered. The value is programmable from 0-9999999.
When Asserted / When De-asserted	Nothing Set	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. User Count will be set to the programmed value for the nominated Area.</p>
<u>SET INPUT COUNTERS</u>		
Input.		Select the Input that will have its Count adjusted by this Action.
Count		Enter the Count Value required. The selected Input will have its count adjusted to this value when the Action is triggered.

<p>When Asserted / When De-asserted</p>	<p>Nothing Set</p>	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Count will be set to the programmed value for the nominated Input.</p>
<p><u>SIREN CONTROL</u></p>		
<p>LAN Module</p>		<p>Select the Module on which Sirens will be controlled by this Action.</p> <p>At present, the Integriti Security Controller, Zone Expander Modules and Graphic Terminals can be selected. Note that the Graphic Terminal only supports Siren tones via its built-in speaker and cannot be used to drive a Horn Speaker or Piezo Screamer.</p>
<p>Time</p>		<p>Enter a Siren Time in Hours, Minutes and Seconds. Determines how long the siren will stay active when the Action is triggered. A time of up to 1 Hr, 49 Min and 13 Seconds may be set.</p>
<p>Siren Tone</p>	<p>None Bell Sweep Fire Evacuation Chirp: Arm Fail Chirp: Arm Success Chirp: Beep Chirp: Double Beep Exit Delay Warning</p>	<p>Select the Siren Tone to be used for this Action.</p> <p>The listed Siren Tones are described fully in ‘Siren Programming’ under Process Group programming.</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) Different siren tones have different priorities so that if more than one Input triggers the same Siren, the highest priority Siren Tone will be sounded. The Siren Tone Priority can be overridden by enabling the “Override Priority” option in the Siren Options below. 2) Concept Expanders do not support all Siren tones. <p><i>See ‘Siren Tone’ in Process Group programming for the Siren Tone priorities and details of Concept Expander Siren Tones supported.</i></p>
<p>Siren Options</p>	<p>Sound Internal Siren Sound External Siren Override Priority</p>	<p>Siren options allow you to select which Sirens will be triggered and the Siren tone priority.</p> <p>The Module’s Internal Siren output will be triggered. The Module’s External Siren output will be triggered. If this option is enabled, and the nominated Siren is already running, the Siren tone selected for this Siren Action will override the Siren tone currently sounding, regardless of the Siren tone priority. If this option is not enabled, then the highest priority Siren tone will sound.</p>

When Asserted / When De-asserted	Nothing Turn On Turn Off Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Siren will be turned On. Siren will be turned Off. Siren will change to the opposite state. Note that this option only applies to continuous Siren tones and will have no effect on the “Chirp” Siren tone types.</p>
<u>SET TIMER VARIABLE</u>		
Timer		Select the General Timer that will be adjusted by this Action.
Time		Enter a Timer period in Days, Hours, Minutes and Seconds. A time of up to 49 days may be set.
When Asserted / When De-asserted	Nothing Set	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The General Timer period will be set to the programmed value.</p>
<u>SET GENERAL VARIABLE</u>		
General Variable		Select the General Variable that will be controlled by this Action.
Use Entity	False (Not checked) True (Checked)	<p>Select whether the Value or Entity will be used for this Action.</p> <p>Use the programmed “Value” for this Action. Use the selected “Entity” for this Action.</p>
Value		If “Use Entity” is set to “False”, the selected General Variable is set to this value.
Entity		<p>If “Use Entity” is set to “True”, select the Entity that will be evaluated to get its value. The selected General Variable is set to whatever numerical value the entity equates to.</p> <p>Entities currently supported in this option are: Input – Input States Input – Input Count Input – Analogue Value Auxiliary – Analogue Value General Variable Value.</p>

When Asserted / When De-asserted	Nothing Set	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. General Variable will be set to the value of the constant value or entity as selected above.</p>
<u>CONTROL AIR- CONDITIONING</u>		
Air Conditioner		Select the Air Conditioner to be controlled by this Action.
Mode	Off Heat Cool Ventilate HeatPump Max Mode	Select the Mode of operation to be applied.
Zone Enables		<p>Determines which Air Conditioning Zones to control.</p> <p>Create an 8-bit binary bitmap by using a 1 for the Zones to control. The Most Significant Bit (Left-hand end) represents Zone 1.</p> <p>Convert that binary number to a decimal number between 1 and 255, and enter that decimal number here.</p> <p>e.g. To control Zones 2, 3 and 5 the bitmap will be 01101000 Converting that binary number to decimal gives 104.</p>
Control Options	Enables Only Boost	Not implemented Not implemented
Delay Time		<p>Program the Delay timer.</p> <p>Enter a Timer period in Days, Hours, Minutes and Seconds. A time of up to 45 Days, 12 Hours, 15 Minutes (65,535 Minutes) may be set.</p>
Running Time		<p>Program the Running Time.</p> <p>Enter a Timer period in Days, Hours, Minutes and Seconds. A time of up to 45 Days, 12 Hours, 15 Minutes (65,535 Minutes) may be set.</p>

When Asserted / When De-asserted	Nothing Turn On Turn Off Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Air Conditioner will be turned On. (After the Delay Time, if programmed) Air Conditioner will be turned Off. (After the Delay Time, if programmed) Air Conditioner will change to the opposite state.</p>
<u>MACRO CONTROL</u>		
Macro		Select the Macro to be controlled by this Action.
When Asserted / When De-asserted	Nothing Start Stop Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The Macro will be Started. The Macro will be Stopped. The Macro will be toggled. i.e. Started if currently stopped, or stopped if currently running.</p>
<u>ISOLATE / SOAK TEST AN INPUT</u>		
Input		<p>Select the Input to be Isolated or Soak Tested by this Action.</p> <p>Isolating an Input allows the Input to be temporarily disabled and will prevent the Input from being processed in any way. e.g. It may be necessary to Isolate an Input when a detection device or input wiring is faulty in order to allow an Area to be turned on and/or prevent the faulty device from causing alarms.</p> <p>Soak Testing an Input allows an Input to be temporarily disabled from being processed, while still being monitored for problems. Note that a Soak Test time must also be programmed for each Area in which Soak Testing may be required. The Soak Test timer allows any Inputs that are put into the Soak Test state to be automatically re-instated if no problems are detected during the soak time.</p>
Sticky Isolate		<p>Enable this option if the Input is <u>not</u> to be De-Isolated by Area Off. (Isolated Inputs are normally automatically de-isolated when the Area is turned off, this option prevents auto de-isolate)</p>
Mode	Isolate Mode Soak Mode	<p>Selects whether the Input is to be Isolated, or put in the Soak Test state. The Input will be Isolated. The Input will be set to the Soak Test state.</p>

When Asserted / When De-asserted	Nothing Isolate De-isolate Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The Input will be Isolated or set to Soak Test. The Input will be De-isolated or removed from Soak Test. The Input will be changed to the opposite state relevant to the Mode selected above.</p>
<u>COMMS TASK CONTROL</u>		
Comms Task		Select the Comms Task to be controlled by this Action.
State	Normal Restart Update All	<p>Select the operation to perform when the Action is triggered.</p> <p>Activate = Start. Deactivate = Stop. Toggle = toggle.</p> <p>Activate = Restart if active or Start if idle. Deactivate and Toggle not used.</p> <p>Activate = Update. Deactivate and Toggle not used. If CT is programmed and running and the programming is the same then skip. If CT is programmed and running and the programming is different, then Restart to implement programming changes. If CT is programmed and stopped then Start. If CT is not programmed but is running then Abort.</p>
When Asserted / When De-asserted	Nothing Activate Deactivate Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Start, Restart or Update according to the “State” selected above. Stop the Comms Task if “Normal” selected above. Toggle the Active/Idle state of the Comms Task if “Normal” selected above.</p>
<u>GRANT AMNESTY</u>		
Select Controller		Select the Controller to provide Anti-passback Amnesty for.

When Asserted / When De-asserted	Nothing Grant Amnesty Deny Amnesty Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Anti-passback Amnesty will be granted for all Users on this Controller. i.e. Location for all Users will be reset to “No Area”.</p> <p>No action will take place. Not applicable to Amnesty.</p>
<u>SET AIR-CONDITIONER TEMPERATURE</u>		
Select Air-conditioner		Select the Air-conditioning Unit to control.
Unit		Enter the Air-conditioning Unit number.
Zone		Enter the Zone number to adjust.
Temperature		Enter the temperature that you wish the nominated Zone to be set to.
When Asserted / When De-asserted	Nothing Set Temperature Turn Off Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Set the nominated Air-Conditioner Zone to the programmed temperature. Not applicable to Set AirCon Temperature. Not applicable to Set AirCon Temperature.</p>
<u>CALL FLOOR</u>		The Call Floor action is for a HLI Remote Call Giver InterFace (e.g. Kone). It will tell the lift system to send the nominated Lift Car to its home floor (e.g. Building Lobby) and enable it to go to the destination floor specified.
Floor		Select the Destination Floor.
Lift Car		Select the Lift Car.
Cancel Action Timer		Not relevant to this Action.
Floor Time		Not relevant to this Action.
When Asserted / When De-asserted	Nothing Call	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Send the Call Floor command with the nominated Floor and Lift Car parameters to the EMS.</p>

<u>SET ANALOGUE AUXILIARY / AUXILIARY LIST</u>		
Auxiliary/Auxiliary List selection.		Select the Analogue Auxiliary or Auxiliary List to be controlled by this Action.
No Review If Same	True (Checked)	If the analogue value to be set is the same as the current analogue value of the selected Analogue Auxiliary, a Review event will not be logged. Intended for use in applications such as advanced automation (e.g. A Fence monitoring interface) to avoid constant review being generated every time automation updates the state but the state hasn't changed.
Value		The selected Analogue Auxiliary/Auxiliaries will be set to this value.
When Asserted / When De-asserted	Nothing Set	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The Analogue Auxiliary will be set to the programmed value.</p>
<u>EXECUTE ACTION LIST</u>		
Action List.		Select the Action List to be controlled by this Action.
When Asserted / When De-asserted	Nothing Execute Assert Edge Execute Deassert Edge Toggle	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. Sends the Assert edge to all actions in the Action List. Sends the Deassert edge to all actions in the Action List. No action.</p>
<u>SET ANALOGUE INPUT</u>		
Input selection.		Select the Input to be controlled by this Action.
Value		The selected Analogue Input will be set to this value.
When Asserted / When De-asserted	Nothing Set	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. The Analogue Input will be set to the programmed value.</p>

<u>MAKE XMIT FOR AREA (Commissioning Report)</u>		<p>This action forces an “XMIT” (reporting) Review entry to be generated for one Input, or all Inputs, in a nominated Area.</p> <p>The resulting alarm messages can serve as a method of providing a commissioning report to a Central Monitoring Station.</p> <p>If a reporting format such as “IRfast with text” is used, the Monitoring Station will receive an alarm message for the nominated inputs that includes the text description for every input. That text can then be used to populate the Zone/Input list for that client.</p> <p>IMPORTANT NOTES:</p> <ol style="list-style-type: none"> 1) Ensure that Input names have been programmed for all the Inputs to be reported. 2) Liaise with the Central Monitoring Station before performing this action so that normal alarm response procedures are not invoked when the alarm messages are received.
Area Selection	Area	<p>Select the Area to make XMIT Review entries for.</p> <p>To include ALL Areas in the report, leave the field for this option empty. i.e. Do not select an Area. (V16.0.0 or later only)</p>
Input Selection	Input	<p>Optional Input to use.</p> <p>If you only wish to report one specific Input, this option allows that Input to be assigned.</p> <p>The “All Inputs” option below must be Disabled.</p>
Options	All Inputs Do Restore	<p>Forces an XMIT Review message to be generated for all Inputs in the nominated Area.</p> <p>Forces a Restore XMIT Review message to be generated for each Input. This may be of benefit to the Central Monitoring Station to clear the alarms generated by this action in their Automation Software.</p>
Input State Selection	States to Save Alarm Tamper Low Tamper High Tamper Zone Self-Test Fail Battery Isolate	<p>Select the Input State/s to Save to Review.</p> <p>Normally, only the “Alarm” state would be selected for this action.</p> <p><i>See Process Group programming for more information on Input states if required.</i></p>
When Asserted / When De-asserted	 Nothing Make	<p>“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted.</p> <p>“When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted.</p> <p>No action. An XMIT Review message will be generated for the selected Input/s in the nominated Area.</p>

EN FUNCTION		
Controller	Target Controller	Select the Controller on which the action is to be performed.
Function	EN Function None Clear Lockout	Select the EN50131 operation to be performed. No function. Clear the User Lockout state.
Options	Act as Installer	If enabled allows the operation to be performed with Installer permissions.
When Asserted / When De-asserted	Nothing Activate	“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted. “When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted. No action. Perform the nominated operation.
RESET PANEL		
Controller Firmware V4.1 or later only.		
Controller	Target Controller	Select the Controller (ISC or IAC) on which the action is to be performed.
Reset Type	No Change Default	Select the type of Reset operation to perform. Will Reset the Controller without making any programming changes. Will Reset the Controller and perform a Memory Default. CAUTION. This operation will return the Controller to factory default settings and programming.
When Asserted / When De-asserted	Nothing Reset	“When Asserted” specifies the operation that will be performed on the selected entity when the action is asserted. “When De-asserted” specifies the operation that will be performed on the selected entity when the action is De-asserted. No action. The nominated Reset operation is performed. When a Reset is performed the Controller will be out of operation for around 30 to 60 seconds. Integriti software and any other devices that communicate with the Controller (e.g. Multipath IP reporting device) will probably report an offline, comms fail or similar condition. These communications paths should automatically be restored after the reset. The Central Monitoring Station should be informed prior to performing a Reset.

<u>VERRIDE DOOR LOCKED</u>		<p>Controller Firmware V4.3.0 or later only.</p> <p>This action allows one or more Doors to be set to the <u>locked</u> state and forced to remain locked until the override is removed, or an action or user operation that takes priority over a door's override state occurs.</p> <p>This allows operations such as a lockdown (e.g. all doors locked to prevent intruder progress) to be implemented.</p> <p>The following options are available to allow nominated events &/or users to ignore a door override if necessary. e.g. A Security Guard may require permission to access a locked-down door or all doors must be unlocked if a fire alarm is triggered.</p> <ol style="list-style-type: none"> 1) The "Ignore Door Override" option can be used in 'Menu Group' programming. 2) A 'Control Door/Door List' action can be programmed using the "Force" option for 'Override Mode'. <p>NOTES:</p> <ol style="list-style-type: none"> 1) Override Unlocked. (e.g. Evacuation condition) To set a Door/Door List to an override <u>unlocked</u> state, program a 'Control Door' or 'Control Door List' action and select the appropriate override mode and the unlock option. 2) Named Action User Interface options. If programming 'User Interface' options for an override action, note that while an override action can be performed from a Terminal, the override state cannot be displayed as there is no 'Sense Entity' available that can represent an override state.
Door(s)	Door Door List	Select the Door or Door List on which to perform the override action.
When Asserted/ When Dis-asserted	Nothing Override Clear Override	<p>Select the type of override operation to perform. Typically, the 'When Asserted' option would be set to "Override" and the 'When Disasserted' option would be set to "Clear Override".</p> <p>No change will be made. Will set the nominated Door/Door List to the override <u>locked</u> state. The underlying Door state is remembered. Will clear the override condition and restore the underlying door state.</p>
<u>CONTROL LOCKER</u>		<p>Controller Firmware V16.0.0 or later only. Note that Locker Control is a licensed feature. <i>Refer to the "Integrati Locker Configuration Guide" for more details.</i></p>
Lockers	Locker	Select the Locker on which the action is to be performed.
User	User	Option to select the User to be assigned to the nominated Locker if required.

Reset Type	Nothing Lock / Allocate Open / De-allocate Toggle	Select the Locker control operation to perform. No change will be made. Will lock the Locker and allocate the nominated User if defined. Will open the Locker and de-allocate the nominated User if defined. Will toggle the lock/open state and allocate/de-allocate state of the Locker if defined.
<u>BATTERY TEST</u>		Controller Firmware V17.0.0 or later only.
LAN Module		Select the Module on which a Battery Test will be performed by this Action. Modules with an on-board power supply or that have an Integriti 3A or 8A Smart Power Supply connected via the 10-way Smart PSU cable can be selected. If a Test Mode that causes all Batteries to be tested is selected (<i>see 'Test Mode' below</i>), select the Control Module. Modules that currently support an Integriti Smart Power Supply connection are; IAC, Integriti 8-32 Zone Expander, Integriti SLAM & Integriti ILAM. Modules that have an on-board power supply are: ISC, Concept 3/4k Universal Expander, Concept 3/4k IFDAM/I2DAM, Concept 3/4k LAN PS.
Test Time	("Single Battery" or "Test All In Parallel" test modes only)	Enter a Battery Test Time for "Single Battery" or "Test All In Parallel" test modes in Hours, Minutes and Seconds. Determines the duration of the battery test for the Module/s to be tested. If the "One At A Time" Test Mode is selected (<i>see 'Test Mode' below</i>), the Battery Test Time programmed for each individual Module is used. NOTE: If a Module has no battery test time programmed, it will <u>not be</u> tested in "One At A Time" Test mode. For some guidelines on setting the Battery test time, see 'Battery Test Time' in Controller - Module Details.
Test Mode	None One at a Time Test all in Parallel Single Battery	Select the Battery Test Mode to be used for this Action. No action. All system Batteries on Modules that have a 'Battery Test Time' programmed will be tested sequentially. All system Batteries on Modules that have a 'Battery Test Time' programmed will be tested concurrently. Only the Battery for the 'LAN Module' selected above will be tested.
When Asserted / When De-asserted	Nothing Start Stop	"When Asserted" specifies the operation that will be performed on the selected entity when the action is asserted. "When De-asserted" specifies the operation that will be performed on the selected entity when the action is De-asserted. No action. The Battery Testing will be started. The Battery Testing will be stopped.

Users and Permissions

Entity/Feature	Description
User Codes	Edit User name, credentials, options and permissions.
Permission Groups (User Groups)	Edit User Group name, options and permissions.
Lists	Edit the names and members of Lists. Available Lists are: <ul style="list-style-type: none"> • Area Lists • Door Lists • Telephone Number Lists • Floor Lists • Lift Car Lists • Auxiliary Lists
Groups	Edit the names, options and permissions of Groups. Available Groups are: <ul style="list-style-type: none"> • Menu Groups • Process Groups • Interlock Groups
Backup Cards	Not yet implemented.
RF Remotes	Register or De-register an RF Remote, set its status and associate it with an RF Remote Template and a User.
Card Templates	Edit Card Templates. A Card Template is assigned to each User with a card credential to define how their card will be processed.
RF Remote (Fob) Templates	Edit RF Remote Fob Templates. An RF Remote Template is assigned to each RF Remote to define how the Fob will operate.
Apartments	Edit Apartment settings. Apartments allow an Intercom unit to be linked to an access controlled Floor.
User Qualifications	Edit User Qualification settings. User Qualifications allow User Permissions to be qualified by additional parameters such as currency of training qualifications or licences, induction program completion, membership of an organization, credits, etc.

User Codes

Feature	Option	Description
User Codes		Select the User you wish to edit.

<p>Cards</p>		<p>There are three methods for assigning a Card to a User.</p> <ul style="list-style-type: none"> • Acquire Card: The Card to be assigned to the User is presented at a Reader connected to an Integriti Module or a Reader connected to the Management Software PC. • Enter Number: A pre-programmed Card Template is selected and the Card number is entered manually. • Existing Card: The Card can be selected from a list of pre-programmed Cards. <p><u>Extended User Data.</u> Prior to Controller Firmware V3.2.1, one Card could be assigned to each User. Controller Firmware V3.2.1 or later introduces the “Extended Users” feature. This feature allows up to 6 Cards to be assigned to a User. In addition, the maximum number of: - Permissions increases from 8 to 68 - User Qualifications increases from 8 to 168.</p> <p>NOTES: 1) The memory required to utilize the Extended Users feature is obtained from unused User Records. Therefore, when more than 1 Card and/or 8 Permissions and/or 8 User Qualifications are assigned to a User, the total number of User Records in the Controller is reduced. 2) Extended User Records cannot be programmed or edited via an LCD Terminal.</p>
	<p>Acquire Card</p>	<p>If the User’s Card data is assigned via the “Acquire Card” method, select the “Acquire Card” option to open the “Card Acquire” dialogue.</p> <p>Select the source of the Card data:</p> <ul style="list-style-type: none"> • Review: A Reader connected to an Integriti Module. • Console Reader: A Reader connected to the Management Software PC. <p>If “Console Reader” is selected, choose the PC Com Port that the Reader is connected to.</p> <p>Follow the displayed prompts and instructions to assign the Card to the User.</p> <p><i>See the Integriti software manual for more details.</i></p>

	<p>Enter Card Number</p> <p>Card Template</p> <p>Card Number</p>	<p>If the User's Card data is assigned via the "Enter Card Number" method, the following two options must be programmed. Select the "Enter Number" option to open the "Manual Card Entry" dialogue.</p> <p>Select the Card Template relevant to this User. Card Templates are programmed separately.</p> <p>The data entered here will depend on the Card Template selected.</p> <p>If the Card Template is a Site Code type, the Card Number may be entered in Decimal.</p> <p>If the Card Template is a type that utilizes raw card data, the User's Card may be entered in this field in HEX format. Up to 32 Hexadecimal characters may be entered.</p>
	Existing Card	<p>The "Existing Card" option allows individual Cards or batches of Cards to be pre-programmed into the system to simplify the process of assigning Cards to Users. <i>See "Cards" in the chapter "Users and Permissions" for details.</i></p> <p>If the User's Card data is assigned via the "Existing Card" method, select the "Existing Card" option to open the "Find Entity" dialogue.</p> <p>Choose a List Filter ("Available Cards" is recommended), then select the required card from the displayed list.</p> <p><i>See the Integrati software manual for more details.</i></p>
RF Remotes	Remote Template	<p>RF Remotes are programmed separately with details of the ID data, functionality (via an RF Remote Template) and status.</p> <p>An RF Remote is associated with a User. This can be done via the RF Remote programming dialogue or the User programming dialogue.</p> <p>When associating an RF Remote with a User from the User programming dialogue, the two options described below are provided.</p> <p>When an RF Remote has been associated with a User, the Remote Template, Remote Data and current Status is displayed.</p>
	From Review	<p>"From Review" allows the RF Remote to be associated with the User by selecting this option, then pressing a button on the Remote. Note that the person operating the RF Remote button must be within range of an RF Module to use this option. For further details refer to the Integrati software manual.</p>
	Existing Remote	<p>"Existing Remote" allows an RF Remote that has already been programmed, to be selected for this User.</p>

Primary Permission Group (Qualify Group)		<p>Select the Permission Group that defines the operations and permissions relevant to the User being programmed.</p> <p>A Primary Permission Group is the simplest way to define User permissions, but is optional and may not be required if you choose to define all User permissions via the 'Extra User Permissions' below.</p> <p>The 'Permission Groups' (Qualify Groups) are programmed separately.</p>
Extra User Permissions		<p>Up to 8 additional User Permissions may be assigned to the User to define operations and permissions for the User. This may not be necessary if all the operations and permissions required for this User have already been defined via the 'Primary Permission Group' above.</p> <p>NOTE: Extra User Permissions can be assigned <u>in addition to, or in place of</u>, the User's Primary Permission Group. e.g. To define one or more Menu Groups, Area Lists, Door Lists, etc. or individual entities (Doors, Areas, etc.) allowed.</p> <p>Controller Firmware V3.2.1 or later introduces the "Extended Users" feature. This feature allows up to 68 Permissions to be assigned to a User. <i>See User 'Cards' programming above for details.</i></p>
	<p>What</p> <p>When</p> <p>Options</p>	<p>Defines the entity for this User Permission. e.g. Door List, Menu Group, etc.</p> <p>Defines when the entity is valid for this User Permission. e.g. Time Period, Area state, etc.</p> <p>Defines options relevant to the entity. e.g. Control options if the entity is an Area or Area List. Options are not available for all entity types.</p> <p><i>See "Permission Programming" for details of how to program this User option.</i></p>

User Options	<p>Cancel on Card access. Cancel on PIN Logon.</p> <p>Disability.</p> <p>Duress Code.</p> <p>User Cancelled.</p> <p>No Greeting</p> <p>Permanent Cache.</p> <p>Exclude from "Ask PC".</p> <p>AURM Permanent</p> <p>Default Floor</p> <p>Start Date/Time</p> <p>Expiry Date/Time</p>	<p>Enable/Disable the general options for this User.</p> <p>User's permissions will be cancelled after next card use. User's permissions will be cancelled after next PIN use. Controller Firmware V3.2.1 recommended if this option is used with a Weatherproof Terminal. Longer unlock times etc, if programmed, will automatically be invoked to cater for a User with a disability. The Duress System Input will be triggered on the Module where this User PIN and/or Card is used. User is currently cancelled. No security or access operations will be allowed. Greetings will not be displayed for this User when logging on to an LCD Terminal. This User will be stored permanently in the Card Cache on Reader Modules for access when the Module is offline. This option allows a User record to be excluded from the Active User Rotation Module (AURM) feature and/or the Operator Challenge feature. AURM. <i>See the "Enable AURM" option in the Controller General Behaviour options for more details.</i> OPERATOR CHALLENGE <i>See the Integriti Software "Guide - Operator Challenge" document for more details.</i> If this option is enabled, this User will not be removed from any Controller's local User database by the Active User Rotation Module (AURM) feature. <i>See "Ask PC" above.</i> Sets the default Floor that will optionally be sent to the Elevator Management System on door access. If programmed, the "User Cancelled" option will be cleared at the designated Date and Time. i.e. The User will be enabled if they weren't already. If programmed, the "User Cancelled" option will be invoked at the designated Date and Time. i.e. The User will be cancelled if they weren't already.</p>
Installer Lockout Options	<p>Controller Firmware V4.2.4 or later only. V16.0.1 or later recommended.</p> <p>Is Installer (Level 3). (Formerly 'Lockout Enabled')</p> <p>Can toggle Installer Lockout. (Formerly 'Lockout control')</p>	<p>Programs options relating to the EN50131 Installer Lockout feature. <i>Refer to the Integriti Application note; "Recommended Installation Procedures For EN50131 Grade 3 Compliance."</i></p> <p>This option allows some 'Level 3' privileges for this User within the EN50131 functionality, but the User will still be locked out when 'Installer Lockout' is enabled. If this option is enabled, "Can toggle Installer Lockout" below <u>must be disabled</u>.</p> <p>Enables this User to allow a "locked out User" permission to logon with a PIN entry. Only Level 2 users with an appropriate level of authority (building owner/managers) should have "Can toggle Installer Lockout" enabled, as they have the power to grant access to the Installer again after the system has been commissioned.</p>

User Tenancy Area		<p>Area to be optionally armed and/or disarmed on Door access and/or Reader arming, instead of the Area/s assigned to the inside/outside of the Door.</p> <p>If the Door option “Update Tenancy Area” is enabled, then the Area User Count and User location will be performed on the User’s Tenancy Area instead of the Area’s assigned to the Door.</p>
Custom Fields	<p>User Qualification Date or Value.</p> <p>Communications Handler E-mail or Telephone Number.</p>	<p>One or more Custom User data entry fields may be added to support additional system features. Some examples are listed below.</p> <p>User Qualifications is a feature that requires a Custom Field to be added. If the User Qualification is an Expiry Qualification type, a Date field will be added to allow an expiry date to be entered for the Qualification. If the User Qualification is a Credit Qualification type, a value field will be added to allow a decimal credit value to be entered for the Qualification.</p> <p>Note that the text labels for Custom Fields are programmable and will therefore be unique to each system.</p> <p><i>See “User Qualifications” for details.</i></p> <p>Communications Handler is a feature that allows the Integriti software to communicate with a range of other software and communications services. These include the Clickatell SMS Sender and an e-mail sender that allow e-mail or SMS messages to be sent to a User under nominated conditions. These services would require user e-mail address &/or mobile telephone numbers to be assigned to relevant Users. <i>Refer to the relevant Integriti Communication Handler guide for details.</i></p>

Permission Groups

Entity/Feature	Option	Description
Permission Groups		Select the User Permission Group you wish to edit.
Name		Program a name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Permissions		Up to 16 Permissions may be assigned to the Permission Group to define operations and permissions for this Group.

<p>Permissions 1 to 16</p>	<p>Allow/Deny</p> <p>What</p> <p>When</p> <p>Options</p> <p>Is</p>	<p>Defines if this permission is to allow or deny the nominated 'What' entity.</p> <p>Defines the entity for this User Permission. e.g. Door List, Menu Group, etc.</p> <p>Defines when the entity is valid for this User Permission. e.g. Time Period, Area state, etc.</p> <p>Defines options relevant to the entity. e.g. Control options if the entity is an Area or Area List. Options are not available for all entity types.</p> <p>Defines if the nominated 'When' entity must be Valid or Invalid to qualify the permission.</p> <p><i>See "Permission Programming" for details of how to program this option.</i></p>
----------------------------	--	---

Lists

Entity/Feature	Option	Description
Lists	Area Lists Door Lists Telephone Number Lists Floor Lists Lift Car Lists Auxiliary Lists	Edit the names and members of Lists. Lists simplify the programming of other entities such as User Permissions, Permission Groups and Actions by providing pre-programmed groups of the same entity.
AREA LISTS		Select the Area List you wish to edit.
	Area List Name.	Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
	Area assignment.	Assign the required Areas to this Area List. Highlight the required Areas in the bottom (“Not In List”) field and click on the “Add” button to assign them to the List. Once an Area is in the List it will be displayed in the top (“In List”) field.
DOOR LISTS		Door Lists are edited in the same manner as Area Lists described above.
TELEPHONE NUMBER LISTS		Select the Telephone Number List you wish to edit.
	Name	Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
	Assign Telephone Numbers	Assign the required Telephone Numbers to the list. Select from the available Telephone Numbers in the “Not In List” field. The Telephone Numbers are programmed separately.
FLOOR LISTS		Floor Lists are edited in the same manner as Area Lists described above.
LIFT CAR LISTS		Lift Car Lists are edited in the same manner as Area Lists described above.
AUXILIARY LISTS		Select the Auxiliary List you wish to edit.
	Name	Program a text name of up to 32 characters in length.
	Assign Auxiliaries	Assign the required Auxiliaries to the list. Select from the available Auxiliaries in the “Not In List” field. Up to 32 Auxiliaries can be assigned to an Auxiliary List. NOTE: Prior to V3.0, only 16 Auxiliaries can be assigned to an Auxiliary List.

Groups

Entity/Feature	Option	Description
Groups	Menu Groups Process Groups	Edit the names, options and permissions of Groups. Groups simplify the programming of other entities such as Users, Input processing and Modules by providing pre-programmed entities that define permissions and operations.

MENU GROUPS		Select the Menu Group you wish to edit.
Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Menu Permissions	Area Information Access Isolate Testing Time Miscellaneous Installer (Engineer) Service Control Lists Groups Edit Input Count Edit User Count RF Remote Full Test suite allowed Alter Any PIN	Defines which Menu options are allowed at a User Terminal for Users with this Menu Group. NOTE: If the "Isolate" menu option is enabled, then the "Isolate on Exit" operation is also allowed, regardless of the setting for the "Isolate on Exit" option in 'Area Control Permissions' below.
Sub Menu Permissions 1	User Codes User Groups (Permission Grps) Review Date and Time Time Periods Schedules Holidays LCD Messages Card Formats Card Templates Soak	Defines which Sub-Menu options are allowed at a User Terminal for Users with this Menu Group.

Area Control Permissions.	<p>Initiate Defer</p> <p>Isolate on Exit</p> <p>24 Hour Off</p> <p>Default List</p> <p>Isolate All</p> <p>Sticky Isolate</p>	<p>Define which Area and Zone Isolate operations are allowed.</p> <p>User will initiate a deferred Area Off operation if turning off an Area defined as a “Defer” Area. <i>See ‘Defer Area’ in Area programming for details.</i></p> <p>Unsealed Inputs will automatically be Isolated on Area Arming.</p> <p>NOTE: In V16.0.0 and in V4 stream firmware prior to V4.3.3, the “Isolate” option in ‘Menu Permissions’ above, also had to be enabled for “Isolate on Exit” to be allowed.</p> <p>In V16.0.1 and in V4.3.3 or later, “Isolate on Exit” can be enabled regardless of the setting of the “Isolate” option.</p> <p>User is allowed to turn off the 24-Hour (Tamper) part of an Area.</p> <p>Terminal display will default to Area List control on User logon. Controller Firmware V3.1.2 or later recommended if the Area List control feature is used.</p> <p>User is allowed to Isolate any Input. Not just Inputs in Areas that they have permission for.</p> <p>User is allowed to Sticky Isolate an Input. i.e. The Input will not be automatically de-isolated on Area Off.</p>
Access Control Options	<p>Exit (Leaving) options</p> <p>Outside Area OFF on Egress (Exit)</p> <p>User Area Off on Egress (Exit)</p>	<p>Access Control Leaving (Exit or Egress) options.</p> <p>Defines Area control operations allowed from Access control Exit Readers.</p> <p>Door “Outside” Area will turn Off on egress.</p> <p>Door “Tenancy Area” will turn Off on egress.</p>
	<p>Entry options</p> <p>Inside Area OFF on Ingress (Entry)</p> <p>User Area Off on Ingress (Entry)</p>	<p>Define the Access Control Entering (Entry or Ingress) options.</p> <p>Defines Area control operations allowed from Access control Entry Readers.</p> <p>Door “Inside” Area will turn Off on entry.</p> <p>Door “Tenancy Area” will turn Off on entry.</p>
	<p>General User Credential options.</p> <p>Dual User Provider</p> <p>Dual User Override</p> <p>Anti-Passback Override</p> <p>Dual Credential Override (e.g. Card + PIN Override)</p> <p>Ignore Door Override</p> <p>Dynamic Locker Override</p>	<p>This User can provide a credential to validate another User when “Dual User” access is required.</p> <p>This User will not require another User to validate when Dual User” access is required.</p> <p>This User can override an Anti-passback restriction.</p> <p>This User can override the need for a second credential when the Door has options such as “Card + PIN” enabled.</p> <p>This User can access or control (lock/unlock) overridden Doors.</p> <p>Door override conditions are implemented via “Control Door” or “Override Door Locked” Actions. <i>Refer to these options for more details and examples.</i></p> <p>Controller Firmware V4.3.0 or later only.</p> <p>This User can open a dynamic locker that is allocated to someone else. The User must also have permission for that locker.</p> <p>Controller Firmware V16.0.0 or later only.</p>

<p>Advanced Options</p>	<p>Named Action Groups</p>	<p>Named Actions (Predefined Actions) can be grouped together in up to 16 Action Groups. This is done in the Named Action programming.</p> <p>This option allows the Action Groups that are allowed for Users with this Menu Group to be defined.</p> <p>Select which of the 16 Action Groups are allowed.</p>
<p>Remote Access Permissions (Remote Control)</p>	<p>Arm Area Disarm Area Arm 24 Hour part of Area Disarm 24 Hour part of Area Isolate Control Aux Lock Door Unlock Door Siren control Comms Task control Adjust Count Secure Allowed Free Access Allowed Installer Access</p>	<p>Define the Remote Control operations allowed for this Menu Group.</p> <p>These options define which operations are allowed when the system is accessed remotely (typically off-site) via a Comms Task. e.g. Integrati CS Software, Integrati Mobile App, GSM SMS Commands, etc.</p> <p>NOTE: USER RF REMOTES. Prior to V17, these options were also required for User RF Remote operations. e.g. Visonic or Paradox Fobs. In V17 or later, these options are NOT required for User RF Remote operations performed from Visonic, Paradox or Inovonics Fobs/Pendants/etc. Permissions for User RF Remote operations are managed by: - The actions programmed in the 'Remote Template' assigned to each individual Remote. - The User's Area, Door, etc. permissions.</p> <p>Area Arming allowed Area Disarming allowed Arming of 24-Hour (Tamper) part of Area allowed Disarming of 24-Hour (Tamper) part of Area allowed Isolate allowed Auxiliary control allowed Lock Door allowed Unlock Door allowed Siren control allowed Enable/Disable Comms Task control allowed Adjust Counter values allowed Can Set Lift Floor/s to Secure mode. Can Set Lift Floor/s to Free Access mode. Can connect to Panel via Integrati CS (Commissioning Software). e.g. via Ethernet, SkyTunnel, iModem (Dialler) or USB.</p>

<p>Review Level</p>	<p>Everyone User - Essential User - Standard User - Detailed Installer - Standard Installer - Detailed Inner Range - Debug</p>	<p>Select the Review Level required for Users with this Menu Group. This option determines the amount of detail that will be included in the Review log.</p> <p>Lowest level of detail.</p> <p>Highest level of detail.</p> <p>The Review Level settings in the four default Menu Groups will give a guide to how you might select this setting in any additional Menu Groups programmed.</p>
<p>Review Classifications</p>	<p>Input Area User Communications Isolate Module Siren General Timer Auxiliary Door Rtos Area Timer C info Lift Time Period Holiday Schedule Debug Air-conditioning Area Counters Input Counters RF Device Information EN50131 Message Power & Battery Testing Macro Comms Task Analogue I/O</p>	<p>Select the Categories required for Users with this Menu Group. This option determines the types of entities that will be included in the Review log.</p> <p>The Review Classification settings in the four default Menu Groups will give a guide to how you might program these options in any additional Menu Groups programmed.</p>
<p>Message Acknowledge</p>	<p>Acknowledge message. Acknowledge All Messages. Auto Siren Off. Clear Area lockout(s) on logon Allow Acknowledge All</p>	<p>Select the Message Acknowledge options required.</p> <p>The User is allowed to acknowledge alarm messages in the Areas that they have permission to turn Off. The User is allowed to acknowledge all alarm messages. Sirens sounding in the Areas that the User has permission to turn Off, will be cancelled on User logon. The User is allowed to clear any Area ‘On Key Lockouts’ when they logon. This option is relevant when the Control Module “Enable Lockout” mode is set. <i>Do not change the setting of this option unless you understand the implications for EN50131 Alarm processing.</i> In EN50131 systems, enable this option for Level 3 Users (Engineer/Installer) only.</p>

EN: Message Acknowledge Options	Clear EN Alarm Clear EN Fault	<p>The User is allowed to acknowledge an Alarm condition when EN50131 Alarm processing is enabled.</p> <p>The User is allowed to clear a Fault condition when EN50131 Alarm processing is enabled.</p> <p><i>Do not change the setting of these options unless you understand the implications for EN50131 Alarm processing. Refer to the Integriti Application note; "Recommended Installation Procedures For EN50131 Grade 3 Compliance."</i></p>
---------------------------------	----------------------------------	---

PROCESS GROUPS

Process Groups define how Inputs of the same type are to be processed.

A Process Group is assigned to each Zone or System Input when it is placed in an Area.

Integriti allows extremely flexible Input processing by allowing a different Process Group to be assigned for each Area that a Zone is in. e.g. The same movement detector can provide Intruder alarm monitoring in one Area, while also providing timed lighting control in another Area.

Integriti Default Process Groups. Typical Applications & Contact ID Event Codes.

A range of default Process Groups are available that cover the majority of Input processing requirements.

The table on the following page shows all the current default Process Groups, their Contact ID Event Codes and the typical applications relating to each.

DEFAULT PROCESS GROUP TABLE NOTES:

1) Process Group Contact ID (CID) Event Codes.

- a) "0" indicates that the default Event Code defined in the relevant Contact ID Mapping table or the Event Code assigned by the Installer in Input Programming will be used.
- b) A number in brackets shows the default CID Event Code that was assigned to the Process Group in V1.1 to V2.5 Integriti Controller Firmware.
- c) A number in square brackets shows the default CID Event Code that was assigned to the Process Group in V3 to V4.2.3 Integriti Controller Firmware.

2) Default Process Group changes.

Controller Firmware V4.2.4 or later adds default Process Groups 26 to 28 and some enhancements and minor changes to some of the existing default Process Groups. The new defaults should be functionally the same for most installations.

The enhancements are primarily to enable processing of additional input states that are used in some European installations, to provide clearer names where required and to change the reporting codes for Process Groups 14 & 17 as shown above.

The additional Process Groups and changes will be visible on new sites, but to utilize them on older sites which are to be upgraded, you will need to use the Integriti Software 'Import Data' feature or enrol a new Controller while the 'Prefer Controller Changes' option is selected.

Default Process Group		CID Event	Input Example
<i>Process Groups 1 to 13 are primarily intended for use with physical Zone Inputs.</i>			
1	Intruder/Burglary (Instant)	130	Internal intruder detector.
2	Entry-Exit Burg (Handover)	130	Internal intruder detector in Entry-Exit path.
3	Primary Intruder/Final Exit (Delay)	130	Intruder detector at point of entry.
4	Silent Alarm	150	Plant alarm with off-site reporting.
5	Local Alarm	0	Plant alarm with local audible/visual annunciation only.
6	Local Silent	0	Plant alarm with Terminal message only.
7	Fire	110	Smoke or Heat-rise detector.
8	Duress/Panic Silent	121	Duress device, Holdup device or Keypad/Reader Duress System Inputs.
9	Panic Audible (Holdup)	123	Panic device or Keypad Panic System Inputs.
10	Emergency	100	Evacuation device.
11	Automation	0	Lighting and HVAC control.
12	Log & Report Only	300	Memory Fault.
13	Log Only	0	
<i>Process Groups 14 to 25 are primarily intended for use with System Inputs.</i>			
14	Tamper	137 [0] (145)	Cabinet Tamper Siren Tamper LAN Power Supply Auxiliary Tamper
15	LAN Fault	0 (143)	LAN Comms Fail LAN Unsecured
16	AC Fail	301	AC Fail
17	Battery Problem	302 [0] (302)	Low Battery / RF Transmitter Low Battery Battery Test Fail Battery Fail
18	Power Supply Fault	0 (312)	Fuse Fail (LAN Fuse / DET Fuse) Low Volts Detector Over-current Battery Over-current Over Volts PS Fail / PS Slave Fail
19	Comms Problem	0 (350)	Unibus Problem Comms Backup Triggered Comms Fail Phone Line
20	RF Transmitter Fault	0 (381)	RF Transmitter Timeout RF Transmitter Poll Fail
21	RF Transmitter Jam	344	RF Transmitter Jam
22	Access Alarm	0 (423)	Door (or Lock) Fault / Door Forced / Reader Fault
23	Access Silent	0 (426)	DOTL
24	Access Local	0	PIN Attempts (Too Many Tries) / Invalid Card
25	Time Report	0 (602)	Triggers Periodic Test Report
<i>Process Groups 26 to 28 are primarily for EN50131/BS8243. See Note 2 above & the EN50131 Application Note for details.</i>			
26	Confirmed Panic/Holdup	121	Intelligent panic button devices (EN50131)
27	Warning Device Fault	321	Siren Power Problem (EN50131)
28	Exit Terminate	0	Dedicated device to trigger 2 nd stage arming. (EN50131)

PROCESS GROUPS		Select the Process Group you wish to edit.
Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
States to process.	<p>Alarm Tamper Low Tamper High Tamper Zone Self-Test Fail Battery Isolate</p> <p><u>EOL Input States</u> Alarm Tamper Low Tamper High Tamper</p> <p><u>Logical Input States</u> Zone Self-Test Fail Battery Isolate</p>	<p>Select the Input States to process. Other Input States will be ignored. A list of the Input States currently available is displayed for selection.</p> <p>Some Input States are physical states determined by the End-Of-Line (EOL) Resistor scheme used in the Input wiring. Most devices support one or more of these physical states; Alarm, Tamper Low, Tamper High and Tamper.</p> <p>Other Input States are logical states determined by system operations and processes or data transfer. Most devices only require the Zone Self-Test Fail and/or Isolate states to be processed.</p> <p>The current Input States that fall under each type are listed opposite.</p> <p>Do not select an Input state for monitoring unless you understand how the relevant EOL scheme or Logical Input State scheme operates for those states.</p>
Processing.	<p>Entry Zone. Exit Zone. Primary Entry Zone. Pulse Count Zone. One Pulse Count only.</p> <p>No 24 Hour if Armed. Process 24 Hour.</p> <p>2nd Stage Arm On Restore</p> <p>EN Ack requires Installer Arm Unsealed</p> <p>Restore Unsealed</p> <p>Invert Qualifier</p>	<p>Inputs will have Entry Delay applied on selected states. Inputs will have Exit Delay applied on selected states. Inputs can start the Entry Timer. Inputs will have Pulse Count logic applied. Inputs can only contribute one pulse per Input to the Pulse Count.</p> <p>24-Hour Input states will not be processed while Area armed. The EOL "Alarm" states will be processed as 24-Hour states. Inputs are processed the same, regardless of the On/Off state of the Area.</p> <p>When this Zone alarms, and the Area is in 1st Stage Arm, the restore on that Zone will trigger the 2nd Stage Arm. "2nd Stage Arm" is only relevant to systems in which "Enable EN50131 processing" has been selected in the Control Module options and for Areas where the 2nd Stage delay has been programmed. <i>See Control Module, and Area programming for more details.</i></p> <p>Only Installers can acknowledge EN50131 messages. If enabled, one or more unsealed Zones will not prevent arming and will not require the Input/s to be isolated. In an Input is unsealed at the time of Area disarm, generate a 'Restore' review event for the Input regardless. Enable this option if the Process Group is required to be valid when the Qualifier (if defined below) is in the 'false' state. <i>See 'Qualifier' and 'Alternate Process Group' options below.</i></p>

	<p>Qualifier (V4.3.0 or later only)</p>	<p>If this Process Group is only to be used under certain conditions &/or at certain times, etc., select the Entity to be used to Qualify the Process Group. e.g. Time Period, Schedule, Area, Auxiliary, etc.</p> <p>The Process Group will be valid if the Qualifier is 'true'. e.g. Time Period or Schedule is Valid Area is On Door is Locked. etc.</p> <p>If the Qualifier entity is in the 'false' state, then the 'Alternate Process Group', if defined, will be used instead. The chain of qualified Process Groups can be up to 5 levels deep.</p>
	<p>Alternate Process Group (V4.3.0 or later only)</p>	<p>If a Qualifier has been defined above, then an Alternate Process Group may be defined. The Alternate Process Group will be valid when the Qualifier entity is in the 'false' state. e.g. Time Period or Schedule is Invalid Area is Off. Door is Unlocked. etc.</p> <p>If the 'Invert Qualifier' option above is enabled, then the Alternate Process Group will be valid when the Qualifier entity is in the 'true' state.</p>
<p>Messages. (Terminal message options)</p>	<p>States to generate Terminal messages</p> <p>Alarm Tamper Low Tamper High Tamper Zone Self-Test Fail Battery Isolate</p>	<p>Define the Input States to generate Terminal messages. Options are the same as "Input States to process" above.</p> <p>A list of the Input States currently available is displayed for selection. <i>See "States to Process" above for details.</i></p> <p>NOTE: Do not edit these options unless you understand how the Input States scheme operates.</p>
	<p>Terminal Message Categories.</p>	<p>Select one or more of the Message Category/s to allow messages from this Process Group to be sent to User Terminals with the corresponding Message Category options enabled. Up to 8 Message Categories may be utilized. e.g. 1) To send all messages to all Terminals simply assign Category 1 in all Process Groups, and Category 1 in all Terminals. 2) To ensure Intruder and Holdup alarm messages are not sent to Terminals in Public access areas, only assign Category 2 to Process Groups for these types of alarms, then enable Category 2 for Terminals in secure Areas, but disable Category 2 for Terminals in public Areas.</p>

Communications Options. (Reporting)	States to report Alarm Tamper Low Tamper High Tamper Zone Self-Test Fail Battery Isolate	Define the Input States to report. Options are the same as “Input States to process” above. A list of the Input States currently available is displayed for selection. <i>See “States to Process” above for details.</i> NOTE: Do not edit these options unless you understand how the Input States scheme operates.
	Comms Task Groups	Option to allow Input event reporting to be filtered based on the type of Input. Up to 16 separate Comms Task reporting Groups can be established. If one or more Groups are enabled in these options, the Input events will only be reported by Comms Tasks that have: - At least one matching Comms Task Group enabled, Or - No Comms Task Groups enabled. If no groups are enabled in these options, the Input events can be reported by any Comms Task, regardless of how the Comms Task Group options have been set in the Comms Task Programming.
	Reporting options. Report Entry. Report Exit. No Xmit Restore. Delay Report.	Select the required general reporting options. Transmit Alarm events during Entry. Transmit Alarm events during Exit. Don't report Input state Restores. Delay Reporting of events via Digital Dialler formats by the Comms Task Delayed Report Time.
	Swinger Shutdown Max	Maximum number of reports that can be sent on an Input before the Input is Isolated.
	Swinger Shutdown Input States. Alarm Tamper Low Tamper High Tamper Zone Self-Test Fail Battery Isolate	Define the Input States that if reported, will be used in the Swinger Shutdown count. Options are the same as “Input States to process” above. A list of the Input States currently available is displayed for selection. <i>See “States to Process” above for details.</i> NOTE: Do not edit these options unless you understand how the Input States scheme operates.

	<p>Contact ID Message Type (Event Code)</p>	<p>If required, enter a Contact ID Event Code to be used for this Process Group. The Event Code defined in this option will apply to the 'Alarm' state of 'Zone' Inputs only. Event Codes for System Inputs and for other Zone Input states (e.g. Tamper, Isolate, Zone Self-test Fail, etc) cannot be altered.</p> <p>If left at "0", the CID Event Code assigned to the individual Input (if programmed), or via the "Report Type" (if programmed below) or the default Contact ID Event Code defined in the selected Contact ID Map, will be used. <i>See "Alarm Message reporting priorities" below for more information.</i></p> <p>An appropriate default Contact ID Event Code is assigned to some of the pre-programmed Process Groups.</p> <p>Note: Process Groups assigned to System Inputs normally have this option set to "0", as appropriate Event Codes are already defined in the selected Contact ID Map and cannot be altered.</p> <p><i>See the table "Integriti Default Process Group Contact ID Event Codes and typical applications" at the end of Process Group programming for details.</i></p>
--	---	---

	SMS Number	If programmed, this telephone number will override the telephone number programmed in the Comms Task for alarm reporting via SMS. e.g. The GSM Comms Task.
	<p>EN Pin state.</p> <p>None Battery Confirmed Holdup Confirmed Intruder Fault Fire Holdup Isolate Jam Mask Open Power Primary ATS Secondary ATS Soak Soaking Tamper Unconfirmed Intruder</p>	<p>Enter the EN Pin state to be used to identify the alarm type from this Process Group.</p> <p>None Battery Problem Confirmed Holdup Confirmed Intruder Fault Fire Holdup (Panic) Isolate RF Transmitter Jam Mask Open/Close Power Problem Primary Alarm Transmission System Secondary Alarm Transmission System Soak Fail Soaking Tamper Intruder Alarm</p>
	4+2 Reporting format Event Code.	Enter the 4+2 Code to be used to identify the alarm type from this Process Group when reporting in 4+2 Dialler format.
Siren Programming	<p>None Bell * Sweep * Fire * Evacuation * Chirp: Arm Fail</p> <p>Chirp: Arm Success</p> <p>Chirp: Beep Chirp: Double Beep Exit Delay Warning</p> <p style="text-align: right;">Highest priority</p> <p style="text-align: right;">Lowest Priority</p>	<p>Select the Siren Tone to be used for Alarms for this Process Group. *NOTE: Only Bell, Sweep, Fire & Evacuation are supported on legacy Concept Expanders.</p> <p>None Bell Chime tone. Intruder Alarm Sweep tone. Fire tone. Fast alternating tones. Evacuation tone. Long sweeps low to high tone. Mid frequency tone followed by LOW frequency tone. Intended to indicate that an attempted operation failed. Mid frequency tone followed by HIGH frequency tone. Intended to indicate that an attempted operation succeeded. Single Beep. Quick Double Beep at the same pitch. Exit Delay. High pitched short beeps. Warning. Medium pitched long beeps.</p> <p>Different siren tones have different priorities so that if more than one Input triggers the same Siren, the highest priority Siren Tone will be sounded. Priorities are as follows:</p> <ul style="list-style-type: none"> - Evacuation - Fire - Sweep - Bell - Warning - Exit Delay (Will override Warning tone) - Chirp: Beep - Chirp: Double Beep - Chirp: Arm Success - Chirp: Arm Fail

	<p><u>Input states to trigger sirens.</u></p> <p>External Siren Input states. Internal Siren Input states.</p>	<p>Define the Input States to trigger External Sirens. Define the Input States to trigger Internal Sirens.</p> <p>Options are the same as “Input States to process” above.</p>
	<p><u>24 Hour Input states to trigger sirens.</u></p> <p>External Siren Input states 24H. Internal Siren Input states 24H.</p>	<p>This option allows different input states to be defined for triggering sirens when the area is disarmed, but still 24hour armed if required.</p> <p>Define the Input States to trigger External Sirens when the Area is Off and the “Use 24h States” option below is enabled. Define the Input States to trigger Internal Sirens when the Area is Off and the “Use 24h States” option below is enabled.</p> <p>Options are the same as “Input States to process” above.</p>
	<p>Siren Options</p> <p>Siren Lockout</p> <p>Use 24h States</p> <p>Siren Refresh</p>	<p>Select the Siren control options required.</p> <p>An Input that triggers the Siren/s will be Isolated at the end of the Siren Time. Use the input states defined in the 2 options under “24 Hour Input states to trigger sirens” above instead of the 2 options under “Input states to trigger sirens” when the Area is only 24 hour armed. If an Input triggers the Siren/s while the Sirens are already running, the Siren timer will be re-started.</p>
Action Programming	Action Assert Input states.	<p>Define the Input state/s that will <u>trigger</u> the nominated Area Process Action when asserted. Options are the same as “Input States to process” above.</p> <p>Up to 8 Input Process Actions can be programmed.</p> <p>Action 1 is typically used to control an output for the Strobe on the Alarm state and is programmed for this purpose in the relevant default Process Groups. Action 2 is programmed to indicate any Tamper state in the relevant default Process Groups.</p>
	Action De-assert Input states.	<p>Define the Input state/s that will <u>cancel</u> the nominated Area Process Action when de-asserted. Options are the same as “Input States to process” above.</p> <p>Up to 8 Input Process Actions can be programmed.</p>

Cards

Cards can be pre-programmed into the system to simplify User programming. Once created, Cards can then be associated with Users, either within Card programming, or in User programming via the ‘Existing Card’ option. Cards can be added either individually, or in bulk. Both methods are described below.

Entity/Feature	Option	Description
----------------	--------	-------------

<u>ADD CARD</u>		Select the Card to program.
Name		Program a name of up to 32 characters for this Card. The name may include the Card Number, Template, Site Code and/or Type.
Credential	Card Type Card Number Card Issue Number	Select a Card Template. Card Templates are programmed separately and define the Format and Site Code parameters. Enter the Card Number. Enter the Card Issue Number if available. Card Issue numbers are only implemented rarely. This option may need to be programmed if using Inner Range Magnetic Swipe Card Format in Site Code mode.
	Status Active Inactive – Lost Inactive – Suspended Inactive – Unused Inactive – Stolen Inactive – Damaged	View or set the status for this Card. The Card is active. The Card has been lost. The Card has been temporarily suspended. The Card is unused. The Card has been stolen. The Card is damaged.
Miscellaneous Options	Last Used	The date and time that the Card was last used in this system is displayed here.
Card Data	Card Data (Hex)	The raw Card Data in hexadecimal format is displayed here. This data is derived from the Card Type, Card Number and Issue Number data and should not be edited manually.
Association	Associated User	The User to be associated with this Card may be selected here. This association can also be assigned in User programming.
Advanced	Managed By Active Directory	Enable this option to have the credential managed by the Active Directory Integration. This will result in this credential being removed from an associated User if they do not have it in Active Directory. This option is only relevant to sites with Active Directory Integration. <i>See the document “Integriti Guide-User management using Active Directory” for more information.</i>
<u>ADD BATCH OF CARDS</u>		This feature allows a batch of <u>sequentially numbered</u> Cards to be programmed into the system with an option to automatically associate each Card with a new User.
	Card Template	Select a Card Template. Card Templates are programmed separately and define the Format and Site Code parameters.
	Start at Card Number	Define the Card Number of the first Card in this batch.
	Number of Cards	Define how many Cards are in this batch.

	Also create a User with each Card	Selecting this option will cause a new User to be created for each Card created.
	Assign created Users this Primary Permission Group	When the “Create a User” option is selected, another option is provided to nominate the Primary Permission Group. It may be convenient to add batches of Cards and Users according to their Primary Permission Group requirement. This option is particularly useful if all of the new Users/Cards in the batch require the same permissions.

Card Templates

Entity/Feature	Option	Description
Card Template		Select the Card Template to program. Card Templates enhance User programming by combining the Card Format and Site Code in a single entity. IMPORTANT NOTE: If editing an existing Card Template, after the changes are made and saved, you must click on the “Regenerate Card Data” button at the top of the dialogue box.
Name		Program a name of up to 32 characters for this Card Template. The name may include the format and/or Site Code of the cards and/or the tenancy of the Users.
Format	Card Format. Direct Entry Wiegand 26Bit Wiegand (H10301) Indala 27 Bit – Wiegand Keri 30 Bit Wiegand etc...	This screen allows the Card Format to be selected. Card Formats are programmed separately. A wide range of defaults are available covering the majority of common industry Card Formats. <i>See the table under “Card Formats” in the ‘Access Control’ section for the full list of default card formats and their details.</i>
Site Code		Enter the Site Code for this Template. The Site Code can be entered in Decimal or Hexadecimal format. When the Site Code is entered in one field, the other field will automatically be populated with the equivalent number in the alternate format.
Photo ID		Select a Photo ID Design to go with this Card Template if required. When printing a Card with this Card Template, this Photo ID design will be used as the default. Photo ID Designs are programmed separately.

RF Remotes

Entity/Feature	Option	Description
----------------	--------	-------------

Name		Program a name of up to 32 characters for this RF Remote. The name may include the User's name and/or the purpose of the Remote.
Miscellaneous options.	Last Used	Allows the Installer to view a record of the date and time that the RF Remote was last used in this system.
Credential	Remote Data	<p>Allows an RF Remote ID to be viewed and/or manually entered. The data is entered in HEXADECIMAL format.</p> <p>The Remote Data can be obtained from the Review Log if an RF Expander Module is installed and the 'Enable RF Remotes' option is selected. e.g. "Unknown Inovonics Button Prg1 button Not Found at Radio Exp: 01 Sig=88 ID=B29C364E" This is the Review entry for a new Inovonics Pendant where the string B29C364E is the Remote Data to be entered in this field.</p> <p><i>See 'RF Remotes' in 'User Programming' for more information on enrolling RF Remotes.</i> <i>See 'Radio Expander' programming for Wireless products supported and Controller firmware versions required.</i></p>
	Remote Template	Assign an appropriate RF Remote Template to this Remote to define the operations. Remote Templates are programmed separately.
	Status Active Inactive – Lost Inactive – Suspended Inactive – Unused Inactive – Stolen Inactive – Damaged	Set or view the current status for this RF Remote.
Association	Associated User	The User to be associated with this RF Remote may be selected here. This association can also be assigned in User programming.
Advanced	Managed By Active Directory	<p>Enable this option to have the credential managed by the Active Directory Integration. This will result in this credential being removed from an associated User if they do not have it in Active Directory.</p> <p>This option is only relevant to sites with Active Directory Integration. <i>See the document "Integrati Guide-User management using Active Directory" for more information.</i></p>

RF Remote Templates

Entity/Feature	Option	Description
Name		Program a name of up to 32 characters for this RF Remote Template. The name may include the main purpose and/or functionality offered by the template.

Button Definitions	Actions	<p>Program the Action for each button to be used. Depending on the Remote Model, up to 4 Button Actions may be programmed. <i>See Table Below.</i></p> <p>NOTE: Operations on Entities such as Areas, Doors, etc. defined in button actions will only be actioned if:</p> <ul style="list-style-type: none"> a) Also allowed in the User's permissions. b) [If V16 or earlier only] Also allowed in the User's Menu Group "Remote Access (Remote Control) Permissions". (Not required in V17 or later)
	Areas	<p>Select one or two Areas to be controlled. Depending on the Remote Model, up to 2 Areas or Area Lists may be selected. <i>See Table Below.</i></p> <p>Note: If Area List control is required, Controller Firmware V3.2.1 or later should be used.</p> <p>These options are not relevant to Inovonics Remotes.</p>
	Inputs	<p>Select one or two Inputs to be controlled. Depending on the Remote Model, up to 2 Inputs may be selected. <i>See Table Below.</i></p>
Options	PIN Code options Needs 6 Digits Needs PIN for Actions Needs PIN for Area On/Off	<p>Paradox REM3 Only.</p> <p>If PIN Code operation is selected in either of the following options, this option forces a requirement for PIN Codes to be 6 digits long.</p> <p>PIN Code is required to control Actions. i.e. Operations performed via the buttons listed under 'Button Actions' in the table below.</p> <p>PIN Code is required for Area On/Off operations.</p>

RF Remote operations supported

Brand/ Model	Button Actions				Areas		Inputs	
	1	2	3	4	1	2	1	2
Paradox REM1	On	=>			Y			
Paradox REM2	●	●●			Y			
Paradox REM3	PGM1	PGM2	PGM3	PGM4	1 & 7	2 & 8		
Paradox REM15	●	●●			Y			
Paradox REM101			●					
Visonic MCT-231		●						
Visonic MCT-234	🏠	Unlock	Lock	*				
Inovonics EN1223D EN1233D EN1235D EN1235DF*	Both Buttons							
Inovonics EN1223S EN1235S	●							
Inovonics EN1224	Button 1	Button 2	Button 3	Button 4			Buttons 1 & 2	Buttons 3 & 4
Inovonics EN1236D	Left Button	Right Button	Both Buttons					

* **NOTE:** While the Inovonics EN1235DF may be enrolled as a User Remote, it incorporates a tamper switch and is normally intended to be permanently mounted and enrolled as a Zone Input.

Apartments

Apartment programming is used in conjunction with the Intercom Comms Task format to define intercom tenant station parameters. Up to 250 Apartments may be defined.

Feature	Option	Description
Apartment		<p>Select the Apartment you wish to edit.</p> <p>Apartments allow a tenant intercom unit/station to be associated with an Integriti Floor and/or Intercom System Floor.</p> <p>This feature operates in conjunction with the “Intercom” Comms Task format to provide sophisticated Intercom access control integration.</p>

Name		Program a text name of up to 32 characters in length. The name may include the Apartment number and/or Floor details.
Settings	Floor	Select the Floor to be associated with this Apartment.
	Intercom System Floor	Kenwei: Enter the Intercom system Floor number to be associated with this Apartment. Aiphone: Not used.
	Intercom System Unit	Kenwei: Enter the Intercom system Unit number to be associated with this Apartment. Aiphone: Not used.
	Intercom System Tenant ID	Kenwei: Not used. Aiphone: Enter the Tenant Station ID number to be associated with this Apartment. The Tenant Station ID is obtained from Review when the tenant station is called by the entrance station.

User Qualifications

Integriti User Qualifications are a separately licensed feature that allows Users to be granted or denied Door access based on an Expiring or Credit Qualification.

Expiring Qualifications allow an expiry date to be entered for each User that is subject to the Qualification. This type of Qualification can be used where the User is required to hold a license, membership, training certificate, etc. to gain access, and that qualification must be regularly renewed. e.g. A machinery operator's licence, an annual club membership, safety training certificate, etc.

Credit Qualifications allow a decimal number value to be entered for each User that is subject to the Qualification. This type of Qualification can be used where a User is limited to a specific number of entries through the nominated Door or Door List. e.g. A User may pay in advance for a specific number of days of parking in a secure car park. Each time the User is granted entry into the car park, their credit value is reduced by 1. If the value reaches 0, the User will be denied access.

Credit Qualifications can use multiple triggers to credit and/or debit from the User's credit value.

Qualifications work by allowing a User access to a particular Door according to the validity of the Qualification and/or whether the User can otherwise access that Door based on their other permissions.

A Qualification controls User access by use of the 'When' characteristic of a Door (or Door List) permission that is assigned to a User or a Permission Group.

i.e. Depending on how the Qualification is to interact with the other permissions, the permission will typically be programmed to:

- "Allow" the Door/Door List when the nominated User Qualification is "Valid".
- Or - "Deny" the Door/Door List when the nominated User Qualification is "Invalid".

In addition to being used in the User Door access permission logic, User Qualifications also allow one or more nominated Actions to be triggered to indicate that a User's Qualification is about to expire ("Warning Action") or has expired (Expiry Action).

To implement User Qualifications:

1. Create a Custom Field for each Qualification to be implemented. This is used to add one or more custom fields to User programming for entering the expiry date or credit value for any User Qualifications that the User will be subject to.
2. Create one or more User Qualifications.
3. Assign each User Qualification to the relevant Users and/or Permission Groups.

See the Integriti Software "Guide – User Qualifications" document for more details.

Feature	Option	Description
User Qualification		Select the User Qualification you wish to edit.
Name		Program a text name of up to 32 characters in length. The name may include specifics of the qualification.
Qualification Type	<p>Expiring Qualification</p> <p>Credit Qualification</p>	<p>Select the type of Qualification to program.</p> <p>Door access may be restricted by an Expiring Qualification and an expiry date is entered for each User subject to that Qualification.</p> <p>Door access may be restricted by a Credit Qualification and a credit value (decimal number) is entered for each User subject to that Qualification.</p>
Associated Field		<p>Allows a Custom data entry field to be associated with the Qualification for the purpose of entering the expiry date or credit value for each User subject to the Qualification.</p> <p>Custom Fields are programmed separately. One or more relevant Custom Fields must be created before this option can be programmed.</p> <p><i>See the Integriti Software “Guide – User Qualifications” document for more details.</i></p>
Triggers (Credit Qualification Only)	<p>Filter Stack</p> <p>Enabled</p> <p>Change Amount</p>	<p>One or more Filters can be programmed to define additional triggers for the Credit Qualification.</p> <ul style="list-style-type: none"> • Credit Qualifications can contain multiple filters, each with their own deductions and filter rules. • Credit triggers can be used to add or remove credits at a specific Door (or Doors). • Deductions can be a negative value if required to add credits. • Expiry occurs when the credit value reaches or falls below 0. <p>Each trigger filter has its own enable option . Once defined, individual trigger filters may then be Enabled or Disabled as required.</p> <p>Enter the decimal value to deduct for this trigger. If the value is to be added, enter a negative number.</p> <p><i>See the Integriti Software “Guide – User Qualifications” document for more details.</i></p>

Times

Entity/Feature	Option	Description
Times		The various Times entities provide all the settings and programming options relating to Time/Date, Time Periods, Schedules and programmable LCD Terminal messages.
Time and Date		Set the current Time and Date.
Time Periods		Edit Time Period name, Time/Day parameters and options.
Schedules		Edit Schedule name, Start/Stop Date & time, Days of week and options.
Holidays		Edit Holiday name, Start/Stop Date & Time and options.
LCD Messages		Edit the LCD message name, control entity and message text.

Time and Date

Entity/Feature	Option	Description
Time and Date		<p>The Controller Time and Date is normally synchronised with the software when a connection between the software and the Controller is established.</p> <p>The Controller Time and Date can also be synchronised periodically by programming a Scheduled Task to define when, and how often, the Date and Time will be synchronised.</p> <p>There is currently no means of manually manipulating the Controller's Real-time Clock from the Software.</p> <p>If the Controller's Real-time Clock needs to be changed to a different time for testing and commissioning purposes, this must be done at an LCD Terminal via MENU, 5, 1.</p> <p>If there is a Scheduled Task programmed to synchronise the Controller time, you may wish to disable it while performing the testing.</p>

Time Periods

Entity/Feature	Option	Description
Time Periods		Select the Time Period you wish to edit.
Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Options	Defined in UTC Time	Program the options for this Time Period. Time Period is defined in Greenwich Mean Time (GMT). i.e. Coordinated Universal Time (UTC).

Start and End times.	Start Time End Time	Program the Start and End time for the Period. Up to 4 separate Periods can be programmed.
Period Days of Week.	Monday Tuesday Wednesday Thursday Friday Saturday Sunday Ignore Holidays	Assign the Days of Week to be used in the Period. The Period will only be Valid on the days specified. Select "Ignore Holidays" if the Time Period will not be made invalid by Holidays. Up to 4 separate Periods can be programmed. Note that it is not necessary to use separate periods to program a Time Period that spans across midnight. The nominated "End Time" on the following day will automatically be included in the period, even though that day is not selected. After programming the Time Period parameters, always check the graphical display of the Time Period at the top of the dialogue box to ensure that the programmed parameters meet the requirements.
Holidays		Assign the Holidays that will be obeyed by this Time Period. Up to 256 Holidays can be defined.
Schedule Overrides	Add Remove	Schedule Overrides allows different Time Period parameters to be defined for a nominated period of time that will override the normal/default parameters for that Time Period. e.g. - User access times for maintenance staff may be extended to allow longer access times when commissioning a new piece of machinery. - Warehouse staff may be given earlier access times during stock-take. Allows a Time Period Override to be added to, or removed from, the overrides schedule. Clicking on 'Add', will open the 'Edit Time Period Override' window allowing the options below to be programmed. To Remove a Time Period Override, click on (highlight) the specific override in the 'Schedule Overrides' column, then click on 'Remove'.
	Edit Time Period Override. Begin Override End Override Notes / Reason	This window is displayed by double-clicking an existing Time Period Override in the 'Schedule Overrides' column, or by clicking on the 'Add' button to create a new override. Assign a Start Date on which the override will commence. Assign an End Date on which the override will conclude. This will be the last day that the override will be in effect. Program optional notes to name &/or describe the reason for the override.

	Time Periods Holidays	<p>To program the Time Period &/or Holiday parameters for an override, click on (highlight) the override in the 'Schedule Overrides' column.</p> <p>The Time Periods & Holidays required for that override can now be programmed &/or viewed in the right-hand column in same manner as the main Time Period parameters.</p> <p><i>See 'Start and End times', 'Period Days of Week' and 'Holidays' above.</i></p> <p>To return to the main Time Period parameters simply click on (highlight) the 'Default Behaviour' option in the 'Schedule Overrides' column.</p>
--	--------------------------	--

Schedules

Entity/Feature	Option	Description
Schedules		Select the Schedule you wish to edit.
Name		Program a name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Date/Time	Recurrence Never Hourly Daily Weekly Monthly Yearly Weekday Of Month	<p>Select the recurrence frequency for this Schedule.</p> <p>Selecting a repeat frequency causes the nominated value in the Time/Date setting to be ignored. e.g. If "Daily" is selected then the day part of the date setting will be ignored. This allows the Schedule to repeat in the nominated period within the limits of the other values in the Date/Time setting. e.g. If "Daily" is selected, then the Schedule will repeat at the same time each day in the nominated Month and Year.</p> <p>Single shot at the programmed Start/Stop Date & Time. Repeat Hourly. Repeat Daily. Repeat Weekly. Repeat Monthly. Repeat Yearly. Repeat on the same day each month.</p>
	Start Date/Time	<p>Program the Start Date and Time for this Schedule.</p> <p>Enter the current Time and Date in the format; DD/MM/YY – hh:mm Where: DD = Day of month MM = Month YY = Year hh = Hours in 24Hour format mm = minutes</p>
	Stop Date/Time	<p>Program the Stop Date and Time for this Schedule.</p> <p>The format is the same as Start Date/Time above.</p>
	Options Use UTC Time	<p>Program the options for this Schedule.</p> <p>Schedule is defined in Greenwich Mean Time (GMT). i.e. Coordinated Universal Time (UTC).</p>

Days of Week	Sunday Monday Tuesday Wednesday Thursday Friday Saturday	Program the Days of Week for this Schedule. Options are the same as the Days of Week options in Time Period programming, but without the Holidays option.
--------------	--	--

Holidays

Entity/Feature	Option	Description
Holidays		Select the Holiday you wish to edit.
Holiday Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Start Date/Time		Program the Start Date and Time for this Holiday. Enter the current Time and Date in the format; DD/MM/YY – hh:mm Where: DD = Day of month MM = Month YY = Year hh = Hours in 24Hour format mm = minutes
End Date/Time and/or Duration		Program the End Date and Time for this Holiday. Use the “Duration” setting and/or the “End Date” field to set the End Date/Time. The End Date/Time format is the same as Start Date/Time above.
Holiday Options	Recur Annually Use UTC Time	Program the options for this Holiday. Repeat this Holiday Annually. This option is used for holidays that recur on the same date every year. If this option is enabled, the Year value in the Start and Stop settings is ignored. Holiday is defined in Greenwich Mean Time (GMT). i.e. Coordinated Universal Time (UTC).

LCD Messages

Entity/Feature	Option	Description
LCD Messages		Select the LCD Message you wish to edit.
Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.

Message Text		Program the message text. Up to 160 characters may be entered for the message. Note: In Controller Firmware prior to V3.0.2, messages more than 16 characters in length might not be displayed correctly.
Select Qualifier Entity		Defines the entity that will be used to cause the LCD Message to be valid. e.g. A Time Period, Area Status, Schedule, etc.
Qualifier Options	Invert Qualifier	Inverts the logic of the Message Qualifier. i.e. The message text will be displayed when the Qualifier is Invalid.

Installer

Entity/Feature	Option	Description
Installer		The programming options listed in this section of the manual cover the settings and programming options relating to installation, commissioning and operation of the system.
Inputs		Program/Edit the Input parameters.
Areas		Program/Edit the Area parameters.
Modules		Program/Edit the Module parameters.
T	LCD Terminal	-Elite LCD Terminal. -Elite X Keypad. -Elite X-SIFER Keypad. -Legacy Concept 3000/4000 Terminal Emulator.
G	Graphic Terminal	Integriti Graphic Terminal and Prisma-SIFER Terminal.
E	Expander	-Integriti Zone Expander Modules -Legacy Concept 3000/4000 Zone Expander Modules including Universal Expanders and Mini Expanders.
F	Radio (RF) Expander	-Integriti Inovonics RF Expander Module. (V17 or later only) -Legacy Concept 3000/4000 RF Expander Modules. i.e. Visonic RF Expander and Paradox RF Expander.
R	Reader Module	-Integriti SLAM (2-Door Reader Module) -Legacy Concept 3000/4000 1 Door/2 Door Reader Modules and Weatherproof Terminals.
I	Intelligent Reader	-Integriti ILAM (Intelligent LAN Access Module) -Legacy Concept 4000 Intelligent 4-Door Controller.
P	LAN Power Supply	Legacy Concept 3000/4000 LAN Power Supply Module.
C	Control Module	Integriti Controller. ISC or IAC.
	Fob and Zone Registration	RF Expander Remote Fob and Zone Registration Menu
Communications	Integriti Monitor Dialler GSM Automation EMS Securitel Intercom BMS EN32pin SkyTunnel E Modem Peer Reporting	Program/Edit the Communications parameters.

System	<p>Memory</p> <p>Auxiliaries</p> <p>EOL Configurations</p>	<p>Program/Edit the System configuration and system-wide operations.</p> <p>“Default 1” is currently the only Memory configuration supported.</p> <p>Allows basic Auxiliary parameters to be defined for each Auxiliary.</p> <p>Allows EOL scheme parameters to be viewed and edited.</p> <p>CAUTION! Do not edit parameters or options in this menu unless you fully understand the ramifications of the changes. Changing settings for an EOL scheme will affect the operation of all Inputs in the System that use that scheme.</p> <p>Selection of the EOL scheme to be used on specific banks of Inputs is done in the “Modules” Menu and NOT in this Menu.</p>
Access Control	<p>Entity Types and Groups</p> <p>Door Types</p> <p>Qualified Door Types</p> <p>Lift Types</p> <p>Qualified Lift Types</p> <p>Lift Groups</p>	<p>Allows the various Entity Types and Groups related to Access Control operations to be programmed and edited.</p>
	<p>Access Control Entities</p> <p>Card Formats</p> <p>Doors</p> <p>Lifts</p> <p>Floors</p>	<p>Allows the various Entities related to Access Control operations to be programmed and edited.</p>
Automation	<p>Named Actions</p> <p>Macros</p> <p>Air conditioners</p> <p>Comparisons</p> <p>Compound Entities</p> <p>General Variables</p> <p>General Timers</p> <p>Calibrations</p> <p>Automation Points</p>	<p>Allows the various Entities related to Automation operations to be programmed and edited.</p>

General Controller Programming

Controller – Module Details

Entity/Feature	Option	Description
Inputs	EOL for Zones... (EOL [End-Of-Line] Resistor Configuration for Zone Inputs)	Select the End Of Line Resistor Configuration to be used for the Zone Inputs on the Integriti Controller. A Config. can be selected for each block of 8 Zone Inputs: Block 1: Zones 1 to 8 Block 2: Zones 9 to 16 Block 3: Zones 17 to 24 Block 4: Zones 25 to 32 This option is normally left blank allowing the default 'Concept 3K' EOL Configuration to be used.
	Concept 3K	Concept 3000. This is the default configuration for Integriti inputs and also the Concept 1000 through to Concept 5000 product ranges. This configuration provides for either of the 2k2/2k2 or 2k2/6k8 Resistor schemes to be used on Integriti product Zone inputs and also caters for the 2k2/6k8 Resistor scheme on legacy Concept 3000/4000 products. This is the default scheme recommended for new installations and when Integriti hardware is replacing existing Concept 1000, 2000, 3000, 4000 or 5000 products.
	8-State	An EOL scheme for factory use only.
	Tecom Compat	EOL scheme using 2x 10k Resistors. Not recommended for new installations. This scheme provides compatibility with existing installations where the Detectors/Input devices already have two 10k Resistors fitted. NOTE: If using this Config in systems that have, or were commissioned with firmware prior to V17.0.1, the three '...debounce time...' settings under 'Options' in EOL Config programming should be increased to 300mS.
	Class 5	Relevant to Inner Range Infiniti Encrypted Expanders only. (Not relevant to Control Modules) This is an EOL Configuration for Infiniti ELM units where the 'Alarm' and 'Tamper' contacts are wired as <u>separate</u> circuits, without Resistors, using the dedicated Alarm and Tamper wires on the ELM. V4.3.0 or later only. <i>See the Infiniti Encrypted LAN Expander Installation Manual for wiring diagrams.</i> <i>See 'Expander' programming and the 'Infiniti Class 5 Installer Manual' for more details.</i>
	Class 5 with Mask	Relevant to Inner Range Infiniti Encrypted Expanders only. (Not relevant to Control Modules) This is an EOL Configuration for Infiniti ELM units where the 'Alarm', 'Tamper' and 'Mask' contacts are wired to the Alarm Input using EOL Resistors. <i>See 'Expander' programming and the 'Infiniti Class 5 Installer Manual' for more details.</i>

Locale Settings	Country None Australia Czech Republic Great Britain Hungary Iceland Ireland Netherlands New Zealand Norway Poland Sweden	Select the Country in which the Controller is being installed. This ensures that Controllers comply with local standards. e.g. Operation of the built-in modem complies with local telecommunications standards.
General Behaviour	Salto Cache Duration Enable AURM Enable Global Antipassback Enable EN50131 processing. Engineer On Site Input Override EOL	<p>The period of time for which the Salto Locks will cache valid cards. Program a value in Days.</p> <p>Enables this Controller to be used with the Integriti Software “Active User Rotation Module”. The AURM feature allows systems to support numbers of Users far in excess of what the Controller can store locally by dynamically updating the local database from the software database when a credential unknown to the Controller is presented in the system.</p> <p>If a User Credential is presented at a Reader that has the “Ask PC” option enabled, and the Credential is not found in the Integriti Controller database, then the Controller will request a check of the Integriti Software database. If a match is found, and the User record has this option enabled, the User record is downloaded to the Controller which then proceeds with processing the operation. <i>See Active User Rotation Module in the Integriti Software manual for details.</i></p> <p>Enables the use of Global Antipassback across multiple Controllers by using the “Location” assigned to the Inside and/or Outside of each Door, rather than the Area.</p> <p>Configures this Controller to operate in accordance with the EN50131 Alarm processing standard. Enables system-wide functionality pertinent to EN50131 (European standards for Intruder Alarm Systems) NOTE: Controller Firmware must be V4.2.4 or later. V16.0.1 or later recommended. <i>Refer to the Integriti Application note; “Recommended Installation Procedures For EN50131 Grade 3 Compliance.”</i></p> <p>An unused Zone Input may be assigned to report the EN50131 ‘Engineer on-site’ condition. The Input will normally be sealed and will go into alarm when a Level 2 User with lockout control enables Engineer access via a Terminal (MENU, 8, 3) Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p> <p>Overrides the EOL Resistor requirement for the REX (Request to Exit) and REN (Request to Enter) Inputs on all</p>

	<p>Force Input Review</p> <p>PIN +1 Duress</p> <p>Save Review to USB</p> <p>Suppress Location Review</p> <p>Prevent Keypad Editing</p>	<p>Doors on this Module. When enabled, the Normally Open contacts of the switch can be wired directly into the REX and/or REN Inputs with no EOL resistors. In V16.0.0 or later this option is enabled by default for Integriti IAC, ILAM and SLAM Modules.</p> <p>Force Input Review. Overrides any Input “No Review” settings forcing all Inputs to log activity to Review. This option may be useful as a temporary setting while commissioning or troubleshooting.</p> <p>PIN+1 Duress. Enables any security PIN Code to be incremented by 1 to generate a Duress Alarm at a Terminal. e.g. Normal PIN is 1234. Use 1235 for Duress. Normal PIN is 6789. Use 6780 for Duress.</p> <p>USB Review. Save review data to a USB Drive if one is attached.</p> <p>Suppresses review event entries for User location changes. This option must not be enabled when features that require User location information are in use. e.g. Muster reporting.</p> <p>When enabled, programming changes are not allowed from the keypad. e.g. An LCD Terminal. V16.0.0 or later only.</p>
	<p>AC Holdoff Time</p>	<p>The AC Fail Holdoff time, is the period of time required to pass before the control module or any other module in the system that has an on-board power supply or is connected to an Integriti Smart Power Supply via the 10-way cable, registers an AC fail. This allows for brief AC mains supply outages to occur without triggering an AC Fail Alarm.</p> <p>Firmware V4.2.0 or later provides a default value of 30 sec.</p> <p>To change the holdoff time, enter a value in Hours, Minutes and Seconds. A value of up to 18 Hrs, 12 Mins and 15 Seconds can be entered.</p>
	<p>Warning Time.</p>	<p>Global Area Defer Arming warning time for all deferred arming Areas managed by this Controller. Determines the Warning Time that will be provided prior to an Area Arming when it has a Defer Arm Timer running.</p> <p>The Warning time starts when the Defer timer expires. Therefore, if no User action is taken, the total time that the Area is Timed Off is the Defer time + the Warning Time.</p> <p>Enter a value in Hours, Minutes and Seconds up to a maximum of 1 Hour, 49 Minutes and 13 Seconds.</p>

	<p>Three Badge Wait (Controller Firmware V3.3.0 or later)</p>	<p>Global “Three Badge (3 Swipe) Arming” wait time for all Readers managed by this Controller. This is the maximum time allowed between the first and third presentation of the User credential (e.g. Card) for a Three Badge Arming operation.</p> <p>If this option is not programmed, the default wait time of 5 seconds will be used.</p>
	<p>Dual Wait Time.</p>	<p>Determines the length of the wait timer for Dual User and Card & PIN operations.</p> <p>Enter a value in Hours, Minutes and Seconds up to a maximum of 18 Hours, 12 Minutes and 15 Seconds.</p>
	<p>Maximum Review Level</p> <p>Everyone User - Essential User - Standard User - Detailed Installer - Standard Installer - Detailed Inner Range - Debug</p>	<p>Sets the Maximum Level of Review that will be saved. Selecting the Review Level determines how much detail is provided in the Review Log. Higher Review Levels will log more events to provide additional detail.</p> <p>Lower levels will allow the Review log to cover a longer period of time, but will provide less detail.</p> <p>NOTE: Do not change the default setting unless you understand the ramifications.</p> <p>Lowest Level of detail.</p> <p>Most detailed Level. Recommended, especially during system installation and commissioning.</p>
	<p>Minimum PIN Code Length</p> <p>Maximum PIN Code Length</p>	<p>Forces all PIN Codes to be at least the specified length. A setting of 4 or less is NOT recommended. Minimum PIN code lengths are required in many standards and project specifications. Check if any such requirements apply to your site.</p> <p>Prevents the use of PIN Codes longer than the specified length.</p> <p>A value between 0 and 8 can be entered. 0 means ignore. For a fixed PIN Code length, set both options to the same value.</p> <p>NOTE: Firmware prior to V4.3 only offers a ‘Fixed PIN Code length’ option which determines a fixed number of PIN digits for User access codes.</p>
	<p>Maximum Software Connections</p>	<p>This option defines the maximum number of unique Integrati Systems this Controller will allow connections to. The setting will normally be 1 or possibly 2. e.g. One permanent Integrati Pro system management connection with a 2nd connection allowed for temporary connection of Integrati CS by the Installer when necessary.</p>

Connectivity:	<p>Rings to Answer</p> <p>Fax Bypass time (mS)</p> <p>Ring Cadence time</p>	<p>Set the number of rings before the Controller's Modem will answer the call. (ISC only)</p> <p>If normal answer call operation is required, then the Fax Bypass time below must be set to 0. If Fax Bypass operation is required, then the Fax Bypass time must be programmed.</p> <p>If Fax timed bypass operation is required, this option must be programmed to specify the amount of time during which the Controller will answer incoming calls instantly, after detecting that rings have stopped before the number of "rings to answer" is reached. V3.3.6 or later only.</p> <p>Fax Timed Bypass is enabled by programming this option to a non-zero value. The "Rings to Answer" option must also be programmed. When enabled, then if a call is made to the Controller that stops ringing before the "rings to answer" is exceeded, the Controller will enter a state (for the period of time programmed in this option) where it will answer any phone calls immediately. If "rings to answer" is exceeded the Controller will not answer the line, allowing the Fax machine to answer.</p> <p>Timeout used for ring cadence detection. Recommended setting is 00.0 (automatic) where the ring cadence time is determined by other system settings. If a different value is programmed, the setting should be less than 6 seconds.</p>
	<p>Serial Reader Settings</p> <p>Serial Channel</p> <p>Baud Rate</p> <p>Data Bits</p> <p>Parity</p> <p>Stop Bits</p>	<p>IAC ONLY.</p> <p>Not currently used. The Serial Reader Port settings are determined by the Reader type selected in 'Readers' programming for this Controller.</p>
Lockout Settings	User Lockout	Set this option to lockout all Users with the "Lockout Enabled" option set while any Area is Armed.

<p>Daylight Saving</p>	<p>DLS Change By</p> <p>DLS Midnight Offset</p> <p>Start Month</p> <p>Start Day -First Sunday of the Month -Second Sunday of the Month -Third Sunday of the Month -Fourth Sunday of the Month -Last Sunday of the Month</p> <p>End Month</p> <p>End Day</p>	<p>The amount of time, in hours and minutes, to adjust the clock by at the specified start and end times. A value of 1 hour is normally used. V4.2.0 or later only.</p> <p>Specifies how long after midnight the change will take effect. This is normally 3am (i.e. 3 hour offset) at the start of daylight saving and 2am (i.e. 2 hour offset) at the end of daylight saving. This option allows one offset to be set for both, so choose wisely.</p> <p>Select the month in which daylight saving will start. There are 12 months to choose from.</p> <p>Select which Sunday of the month daylight saving will begin on. There are 5 options to cater for every possibility.</p> <p>Select the month in which daylight saving will end. Options are as per 'Start Month'.</p> <p>Select which Sunday of the month daylight saving will end on. Options are as per 'Start Day'.</p>
<p>Battery Test Settings</p>	<p>Day of Week</p> <p>Sunday Monday Tuesday Wednesday Thursday Friday Saturday Every Day</p>	<p>Select the Day of the Week on which the System Battery Test will commence. One option may be selected.</p> <pre> \ \ > Battery testing will be performed on the selected day. / / </pre> <p>Battery testing will be performed every day. V4.3 or later.</p>
	<p>Weeks between Tests</p>	<p>Battery Test frequency. Program the number of Weeks to elapse between each Battery Test.</p> <p>A value between 0 – 255 may be entered. A setting of 0 disables Battery Testing. A setting of 1 to 4 weeks is typical. If the system is being installed to a specific standard, ensure that the Battery Test settings comply with the standard.</p>
	<p>Battery Test Hour</p>	<p>Program the Hour for the Start of the Battery Test. Hours. Enter a value between 0 - 23.</p>
	<p>Battery Test Minute</p>	<p>Program the Minute for the Start of the Battery Test. Minutes. Enter a value between 0 - 59.</p> <p>e.g. To start Battery Testing at 1:15 PM program as follows: Battery Test Hour: 13 Battery Test Minute: 15</p>

Time Report	Hour of the Day	<p>Program the Hour of the Day that the Periodic Test Report will be sent to the Monitoring Station.</p> <p>Note that the Time Report System Input must be assigned to an Area with an appropriate Process Group.</p>
	Day of Week Sunday Monday Tuesday Wednesday Thursday Friday Saturday	<p>Program the Day of the Week that the Periodic Test Report will be sent to the Monitoring Station.</p> <p>Select one or more days on which the Test Report will be triggered.</p>
Default Modules	Default RF Reader	<p>Defines the default RF Expander Module that will be used for enrolling Wireless Remotes. e.g. Paradox REM devices, Visonic Remotes or Inovonics Pendants/Remotes.</p>
LAN Module Options	LAN Fail Delay (V17.0.0 or later)	<p>Allows a de-bounce value to be programmed for the Module LAN Fail monitoring. This prevents the LAN Fail System Input from being triggered when a Module goes off-line, but recovers immediately, or quickly afterwards.</p> <p>Enter a delay time in Seconds. If the Module is lost, but is found before the delay time expires, then the System Input will not be triggered. The value programmed here applies to all Modules connected to this Controller.</p> <p>This feature is particularly useful to prevent LAN Fail reporting when a Module briefly goes offline as a result of re-booting after a firmware update. For this purpose, a value of 3 seconds should be suitable.</p>
	Poll Time	Not Relevant to Control Modules.
	Battery Installation Date (V17.0.0 or later)	Allows the Installer to make a record of the date and time when the Battery was installed. This data is used by the 'Battery Needs Replacement' feature below.
	Battery Ambient Temperature (V17.0.0 or later)	Allows the Installer to enter the average ambient temperature value of the environment in which the Battery is installed. This data is used by the 'Battery Needs Replacement' feature below.
	Battery Needs Replacement (V17.0.0 or later)	This flag will be set automatically by the system when the Battery is determined to be nearing the end of its service life based on the 'Battery Installation Date' and 'Battery Ambient Temperature' values entered above.

	Battery Test Time	<p>Enter a Battery Test Time in Hours and Minutes. Determines the duration of battery test time for the main Control Module C01. (Battery test times for other Modules are set within the options for each individual Module)</p> <p>If the Controller is an IAC, this option determines the battery test time for an Integriti Smart PSU connected to the IAC.</p> <p>Enter a value in Days, Hours and Minutes. Battery Test times are determined by the Battery capacity, the normal total load (which includes the Module itself, and its peripherals), and the battery charge required to be retained at the end of the test (to allow for AC failure occurring shortly after the end of a battery test). e.g. For a 7.0 AH battery required to deliver 1.2 Amps during an AC Failure, a battery test time of 3 hours would discharge the battery to just under half its capacity.</p> <p>A Value of up to 45 days, 12 Hours and 15 Minutes may be entered.</p>
	LAN Module Type	<p>This option allows the Installer to view or select the type of Module connected for this Controller address.</p> <p>The correct type will normally be automatically chosen when the Module is first connected to the system. If the Module is being programmed prior to being connected to the system, the type will need to be selected.</p>
	Integriti Controller	<p>At present, only the option 'Integriti Controller' is relevant for a Control Module.</p>
	Unibus Devices	<p>Lists the Unibus devices connected to this Controller. The Unibus devices IDs are normally automatically entered when the device is first connected to the system.</p>
SkyTunnel	<p><u>TCP Options V17.0.3 or later.</u></p> <p>SkyTunnel Address 1</p> <p>SkyTunnel Port 1</p> <p>SkyTunnel DNS 1</p> <p>SkyTunnel Address 2</p> <p>SkyTunnel Port 2</p> <p>SkyTunnel DNS 2</p> <p>SkyTunnel Address 3...</p> <p>SkyTunnel Address 4...</p>	<p>In firmware V17.0.3 or later, up to four TCP paths can be defined as follows:</p> <p>Enter or view the IP Address of the Integriti Server PC for the primary SkyTunnel TCP connection.</p> <p>Enter or view the Server TCP Port Number for the primary SkyTunnel TCP connection. The default Port Number does not normally need to be changed. A different Port number is only required to be entered if the customer has their own dedicated SkyTunnel server. Select the required DNS Name from the list for the primary SkyTunnel TCP connection. DNS names are programmed separately.</p> <p>Sets up the TCP options for the secondary SkyTunnel TCP connection. Options are the same as those described for the Primary TCP options above.</p> <p>Sets up the TCP options for the tertiary SkyTunnel TCP connection.</p> <p>Sets up the TCP options for the quaternary SkyTunnel TCP connection.</p>

	<p><u>TCP Options up to V17.0.1</u></p> <p>Primary TCP options</p> <p>Server IP Address</p> <p>TCP Port</p> <p>DNS Name</p> <p>TCP Mode</p> <p>Retries</p> <p>Connection Timeout</p> <p>Connection Attempt Timeout</p> <p>Secondary TCP options</p>	<p>In firmware up to V17.0.1 up to two TCP paths can be defined as follows:</p> <p>Sets up the Primary TCP options for SkyTunnel communications.</p> <p>Enter or view the IP Address of the Integriti Server PC.</p> <p>View or enter the Server TCP Port Number. The default Port Number does not normally need to be changed. A different Port number is only required to be entered if the customer has their own dedicated SkyTunnel server.</p> <p>Select the required DNS Name from the list. DNS names are programmed separately.</p> <p>Determines whether SkyTunnel will run as a Server, a Client or neither on this Controller.</p> <p>The number of times to retry connecting upon a failed attempt before connection attempts is aborted. Only applicable to the “Client” TCP Mode if selected above.</p> <p>Not yet implemented.</p> <p>Not yet implemented.</p> <p>Sets up the Secondary TCP options for SkyTunnel communications.</p> <p>Options are the same as those described for the Primary TCP options above.</p>
	SkyTunnel Password	Allows the SkyTunnel password to be changed.
	<p>SkyTunnel Options</p> <p>Disable SkyTunnel</p> <p>Disable Web via SkyTunnel</p> <p>Disable IRIP via SkyTunnel</p>	<p>When set, this Controller will never connect via SkyTunnel.</p> <p>Prevent web interface (ie: smartphone app) from connecting via SkyTunnel.</p> <p>Prevent the Integriti software connecting via SkyTunnel.</p>
	SkyTunnel Online Input	<p>An unused Zone Input may be assigned to monitor the “Online” status.</p> <p>The Input will be sealed while the SkyTunnel connection is online and in alarm when offline.</p> <p>Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p> <p>Note that the Input for monitoring the online status of SkyTunnel <u>Reporting</u> is <u>not</u> programmed here. A separate “Online Input” is provided in the SkyTunnel Reporting Comms Task options.</p>

OSDP Options (IAC Only)	OSDP Options Local Feedback Disable Auto Addressing Lockdown Bus Proximity Feedback	<p>The Reader will respond immediately when a card is read. Disables all auto addressing on this bus. This option may be necessary when the bus is being shared with some other OSDP devices.</p> <p>Disables addressing of unknown modules. While locked down, you will be unable to add new Readers to this Module. V4.2.0 or later only. This option no longer available in V17 or later.</p> <p>When enabled, SIFER Readers will click and flash when a card is detected until the card is close enough to read. This option is useful during commissioning to determine if any Readers have limited read range due to the installation environment or interference, etc. V4.2.0 or later only.</p>
	Crypt Mode Default Custom None	Select the mode of encryption on the OSDP bus for this Module.
Peer-to-Peer Reporting	Controller Firmware V3.2.1 or later required. <ol style="list-style-type: none"> 1. Peer-To-Peer Reporting. Reportable events can be sent to another Integriti Controller. 2. Foreign Entities. The state of an Entity on one Controller can be used in operations on one or more other Controllers. 3. Locations. Enables Global features such as Global Anti-passback. 	<p>When multiple Integriti Controllers are installed on the same site or within the same system, the Peer-to-Peer feature allows those Controllers to share information and data in a number of ways.</p> <p>Allows for a nominated Integriti Controller to receive relevant Review messages from one or more other Controllers for reporting to a Central Monitoring Station. <i>See the Peer-To-Peer Reporting Comms Task format for more information.</i></p> <p>“Foreign Entities” can be defined to target an Entity on a different Controller. The Foreign Entity can then be selected in programming wherever a general Entity can be assigned. e.g. The ‘Optional Trigger’ option in a Named Action.</p> <p>“Locations” can be defined and then assigned to the Inside and/or Outside of any Doors that are to be included in Global Anti-passback processing.</p> <p>Note that the reliability of Peer-To-Peer operations is dependent on the network over which the Controllers will communicate with each other. The Peer-To-Peer features should only be used when necessary, and the quality of the network connections should be taken into consideration when deciding on their implementation.</p>

	<p>Peer-to-Peer settings.</p> <p>Multicast IP Address</p> <p>Port</p> <p>Encryption Key</p> <p>Time Window (secs)</p> <p>Peer-to-Peer ID</p>	<p>This is the IP address that peer-to-peer messages will be multicast to.</p> <p>This is the Port that peer-to-peer messages will be multicast to.</p> <p>All Controllers in the Peer-to-Peer relationship will need to share the same encryption key.</p> <p>The number of seconds of difference allowed for timestamps.</p> <p>This number identifies Controllers in the peer-to-peer system. Each Controller connected in a Peer-to-Peer relationship must have a unique ID.</p>
	<p>Peer-to-Peer options.</p> <p>Receive Alarms</p> <p>Receive State</p> <p>Send State</p> <p>Locations</p>	<p>Receive Alarms from other Controllers for reporting to a Monitoring Station. If this option is enabled, all Controllers that will send alarms to this Controller must have the appropriate "Report Type" selected in every Process Group that is used with Zone Inputs <u>and</u> in which reporting is enabled. (Process Groups that are only used for System Inputs do not require a Report Type to be programmed)</p> <p>Receive the state of foreign entities. Foreign Entities are entities on a different Controller. In any Controller where the state of any entity on another Controller needs to be monitored, a "Foreign Entity" must be created for each entity to be monitored.</p> <p>Transmit the state of foreign entities.</p> <p>Allows User Locations to be sent to linked Controllers. This option is required if peer-to-peer is to be used for features such as global anti-passback.</p>
Readers	IAC only.	<p>Parameters are programmed for up to 16 Readers that may be connected to an IAC and/or its associated UniBus 2 Door Expander Boards.</p> <p>Up to 8 Readers can be connected via the on-board Wiegand/Clock&Data ports. (UniBus expansion boards required if more than 2)</p> <p>Depending on the type of Reader, up to 8 or 16 Serial Readers (SIFER, OSDP, Salto, Aperio, Intego or Tecom) can be connected via the 'Reader RS485' Port. <i>See the table at the beginning of 'Intelligent Reader Module' programming.</i> Note that when a Serial Reader type is selected for a Reader, all other Serial Readers on this IAC must be of the same type.</p> <p><i>See "Readers" in 'Reader Module' programming for details of the options available.</i></p>

Door Access Control	IAC only.	<p>There are 8 logical Doors on an Integriti Access Controller (IAC). Door Access Control programming is used to assign the Door and define the Door hardware, control and monitoring options for each logical Door number on the IAC.</p> <p>The parameters are programmed for each of the 8 Doors that may be connected to the IAC and/or its associated UniBus 2 Door Expander Boards.</p> <p><i>See “Door Access Control” in ‘Intelligent Reader Module’ programming for details of the options available.</i></p>
Lift Access Control	IAC only.	<p>Up to 8 Lift Cars may be assigned to an IAC and its associated UniBus Boards.</p> <p>Access control for the nominated Lifts will be provided by this Module.</p>
Basic Details	Controller ID	Records the ID for this Control Module.

Controller – Connection Details

Entity/Feature	Option	Description
Module Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.
Basic Details	Serial Number	Records the Controller Serial Number.
Miscellaneous Options	Class 5 (V4.3.0 or later)	<p>This option is enabled if the Controller is an Infiniti Class 5 Control Module.</p> <p>Infiniti Class 5 Controllers support special features that enable an intruder alarm system to be installed in compliance with the requirements of AS2201.1: 2007 Class 5.</p>
Connectivity	Connection Mode Auto Manual Disabled	<p>The Controller will automatically attempt to connect to the Integriti Software.</p> <p>The connection needs to be manually initiated at the Integriti Software. The Comms Task will not attempt to connect to the server if it is disconnected.</p> <p>Integriti Software connection to this Controller is disabled. The Controller won't try to connect to the server at all if the Comms Task is programmed.</p>
	Port-forwarding Port	<p>Normally left blank for the server's listening port. (Recommended default setting)</p> <p>If this Controller is behind a port forwarding device, set this option to the port the Controller should use to connect to.</p>

	<p>Connection Path</p> <p>TCP USB Serial IModem EModem SkyTunnel Phantom</p>	<p>Selects the preferred method of connection between the Integrati Controller and the Software.</p> <p>Onboard Ethernet Port Onboard “USB-P” Port UniBus UART Serial Port Onboard PSTN Modem External PSTN Modem SkyTunnel</p>
	<p>Connection Timeout</p>	<p>Program a connection timeout time in milliSeconds.</p> <p>The connection will be closed if the Controller does not send at least one packet within this time.</p> <p>The default setting of 30000 should be retained unless advised otherwise.</p>
	<p>Connection Poll Time</p>	<p>Program a Poll time in milliSeconds.</p> <p>This is the maximum amount of time between heartbeat messages and must not exceed the Connection Timeout time above.</p> <p>The default setting of 10000 should be retained unless advised otherwise.</p>
	<p>Modem / Serial Port</p>	<p>The Computer Serial Port that a PSTN Modem is connected to when a Modem connection is to be available.</p>
	<p>Modem Configuration String</p>	<p>Optional modem configuration string if a special string is required to configure the modem.</p>
	<p>Modem Phone Number</p>	<p>The telephone number for the PSTN Modem</p>
	<p>SkyTunnel Password</p>	<p>The Code used to establish connectivity via SkyTunnel. This can be found via MENU, 8, 0 at an LCD Terminal.</p>
	<p>Integrati CS User authentication</p> <p>Username</p> <p>PIN</p>	<p>These records are required to establish a remote Integrati CS connection to the Controller. i.e. Via an Ethernet, SkyTunnel or Dialler connection. Note that the nominated User will not be allowed to connect if currently disabled (e.g. expired) or locked out in the Integrati system.</p> <p>Enter the User name. This must be a valid User that exists in the Integrati System and has the “Installer Access” option enabled under Remote Access Permissions in their Menu Group. This is typically the Installer, however, another User may be assigned, or a User may be programmed in the system specifically for this purpose. Note that the Username is case-sensitive and must therefore be entered exactly as it is programmed in the system.</p> <p>Enter the “Security PIN” number for the User selected in the Username record. A PIN number of “01” is not allowed unless via a SkyTunnel connection in which case the SkyTunnel password provides additional security.</p>

Synchronisation	Review Synchronisation Mode	Select a Review Synchronisation Mode to determine the point from which Review will be synchronised, and how much Review will be synchronized.
	All Historical Review	Will synchronize Review from the oldest event to the newest event. Note that if the Controller has accumulated a large Review log, this may take some time.
	From Now	Will synchronize Review from the point of time of the connection being established between the Controller and the software.
	Continuous	Will synchronize Review from the last event that the Controller sent in the previous connection session.
	Don't Sync Review	Review will not be synchronized.
	Don't Sync Time Upon Connection	Option to not synchronise the Controller and Server time upon connection.
	Time Zone	Defines the Time Zone of the location that the Controller is installed in.
	Enable Data Synchronisation	Select to allow data synchronisation between the Controller and the Server.
	Data Sync Mode	Determines how conflicting changes are resolved in an entity has been altered while the Controller is offline.
	Merge Changes	Changes from the Controller and the Software will both be accepted.
	Disallow Changes from Controller	Changes to the Controller will not overwrite the data in the Software.
	Prefer Controller Changes	Changes in the Controller will overwrite the data in the Software.
	Prevent State Syncing	Select to prevent the state of anything connected to the Controller from being synchronised.
Version	Protocol Version	Records the Controller's protocol version
	Firmware Version	Records the version of the Firmware currently installed on the Controller. The firmware version number is in 4 parts. e.g. V16.0.1.10989 The structure is as follows. vv . f . i . bbbbbb where: vv = Major firmware update (V1 to 4) or Year (V16 or later) f = Feature release. i = Intermediate release. bbbbbb = Firmware Build.
Smart Card	Smart Card Serial Number	The Serial Number of the Smart Card installed in the Controller.

Input Programming

Entity/Feature	Option	Description
Create/Find Input		Select Input to program
Input Name		Program a text name of up to 32 characters in length to describe the type, location and/or purpose of the Input. e.g. Workshop PIR Detector Staff Entry Door Reed Switch Despatch Roller Door PE Beam Storeroom Smoke Detector Laboratory Temperature Sensor
Input Type	Normal Analogue Count Up Count Down Previous Input Count Up Previous Input Count Down	Select Zone Type. Normal Digital EOL Zone Input. Analogue Zone Input. Event Counter Input, counting up. Event Counter Input, counting down. Event Counter Input, contributing an up count to the previous Zone Input ID. Event Counter Input, contributing a down count to the previous Zone Input ID.
Optional (Input) Actions	Alarm Action	The Alarm Action allows an Input to be programmed to provide direct control of another entity. Once the required Entity is selected, the options relevant to the control of that Entity type will be displayed. <i>See 'Action Programming' for further details.</i>

<p>Input Options</p>	<p>Summary Zone. Ignore physical Input.</p> <p>Swap Alarm and Seal</p> <p>No Test on Exit.</p> <p>Auto Isolate on exit.</p> <p>Zone Test enabled. (Self-test/Walk Test)</p> <p>No Review.</p> <p>Isolate All only.</p> <p>No Xmit Restore Review Each Period</p>	<p>Zone Input Options.</p> <p>This Zone will be included in the overall Input summary. Ignore the physical Zone state. Used when the Zone is only to be triggered by an Action or similar operation. e.g. A 'Fail' 'Online' or 'Backup' Input is assigned in a Comms Task. Swap the Alarm and Seal states. Enable for Normally Open alarm contacts on Zone Inputs. V4.3.1 or later also allows Module Cabinet Tamper Input states to be swapped. The system will not check that this zone is sealed when arming an Area to which it is assigned. e.g. Perimeter Door or Barrier that is used to exit the premises and must remain open until after arming. Auto Isolate on arming. Auto-isolate will be allowed on the Input if the Input is unsealed when an Area to which it is assigned is being turned On. If selected, this Zone will be enabled for Zone Self-Test and User Walk Test. Controller Firmware V3.2.1 or later recommended if Zone Self-Test is enabled. V4.2.3 or later firmware is recommended if there are Walk-Test Inputs that are assigned to more than one Area. Activity on this Input will not be saved to Review. Note: If programmed for reporting, 'Xmit' events will still be saved. In V16.0.3 or later this now includes input count change events when the Input is a 'Count' type. Only a User with the "Isolate All" permission can isolate this Input. Input Restores will not be reported for this Input. If the Input is processed as an analogue or counter Input, the analogue or counter value will be logged to Review at the nominated "Log Frequency". See "Analog & Counting" options below.</p>
<p>Reporting</p>	<p>SIA Type (Controller Firmware V3.2.1 or later only)</p>	<p>Select the SIA Type if required. It is only necessary to assign a SIA Type to an Input if it requires a different SIA Type to:</p> <ol style="list-style-type: none"> a) The default SIA Type defined in the SIA Mapping Table. b) The optional 'SIA Type' programmed in the Process Group associated with this Input. c) The optional 'Report Type' programmed in the Process Group associated with this Input. <p>If set to "None", the Process Group SIA Type or the default SIA Type will be used.</p> <p><i>See "Alarm Message reporting priorities" in Process Group programming for more information.</i></p> <p>This option is only relevant to the 'Alarm' state on 'Zone' Inputs and will not alter the CID Event Code for System Inputs or for other states on Zone Inputs.</p> <p>The list of SIA Types and descriptions is found under 'SIA Type' in Process Group programming.</p>

	Contact ID Message (Event Code) Number	<p>Program the Contact ID Event Type to be used when reporting Alarms on this Zone Input if required.</p> <p>It is only necessary to assign a Contact ID Message to an Input if it requires a different message to the one defined in Process Group programming via the “Contact ID Message” or “Report Type” or the default Message in the Contact ID Mapping Table.</p> <p><i>See “Alarm Message reporting priorities” in Process Group programming for more information.</i></p> <p>The Event Type is a number between 000 and 999. A list of Contact ID Event Codes is provided in the document “Integriti Contact ID Common Messages”. If left at 000, an appropriate default Contact ID Event Code will be used depending on the Process Group assigned to the Input.</p> <p>This option is only relevant to the ‘Alarm’ state on ‘Zone’ Inputs and will not alter the CID Event Code for System Inputs or for other states on Zone Inputs.</p> <p><i>See: “Integriti Contact ID Common Messages”. “Integriti Contact ID Input Mapping”.</i></p>
Analogue & Counting	Analogue Calibration	<p>Select the Analogue Input calibration parameters.</p> <p>Predefined Calibrations are programmed separately, and once programmed, can then be assigned to relevant Inputs.</p>
	Count Calibration	<p>Select the Counter Input calibration parameters.</p> <p>Predefined Calibrations are programmed separately, and once programmed, can then be assigned to relevant Inputs.</p>
	Analogue / Count Log Frequency	<p>Program a frequency in Hours, Minutes and Seconds, to determine how often the Analogue or Counter value on this Input is saved to Review.</p> <p>0 = No logging. The logging frequency can be set to a value between 1 Second (most frequent logging frequency) and 18 Hours (the least frequent).</p>
	Analogue Hysteresis	<p>Sets the sensitivity to changes in analogue values to trigger an Input analogue value update.</p> <p>NOTE: Not used for legacy Concept 3000 Analogue Modules. For Concept 3000 Analogue Modules, this option is set in the relevant Module programming.</p>
Assign the Input to an Area.	Don't forget to assign your Inputs to at least one Area	Assigning Zones and System Inputs to Areas is performed in Area programming.

Area Programming

Entity/Feature	Option	Description
Create/Find Area		Select the Area you wish to edit.
Area Name		Program a text name of up to 32 characters in length. This feature can be used to describe the location and/or function, etc. of the Area.
Reporting Options	<p>Report Openings. Report Closings. Close at Exit Start.</p> <p>Report Openings after Alarm.</p> <p>Report 24 Hour Open/Close. Exclude from General Open/Close</p>	<p>Central Monitoring Station reporting options.</p> <p>Report Opening. Report Closing. Report the closing event at the beginning of the exit delay, instead of at the end. Only report Openings for this Area if an Alarm report has occurred since Closing. Report Open/Close on the 24 Hour (Tamper) part of the Area. Do not include this Area as part of a General Area Open/Close report.</p>
	Client Code	<p>Determines the Account code to be sent when reporting events from this Area. An Account Code (Client Code) may be entered for any Areas where the Account Code needs to be different from the one programmed in the relevant Comms Task.</p> <p>Account Codes are typically provided by the Central Monitoring Station. The number of digits required will depend on the reporting format.</p> <p>Enter a Decimal value between 0 – 65535, or a Hexadecimal value between 0 – FFFF. (Hexadecimal available in Controller Firmware V3.2.1 or later only)</p>
	SMS Number (Controller firmware V4.2.0 or later only)	<p>An optional telephone number for SMS alarm messages may be programmed for an Area. If programmed, this number will override any SMS number programmed for alarm messages in a GSM Comms Task or in a Process Group.</p>
General Area Options	Remote Arming Suppresses Exit Delay. (Controller firmware V4.3.0 or later only)	<p>When enabled, the 'Exit Delay' will only start if arming from a keypad. e.g. LCD Terminal, Graphic Terminal, etc. Arming via other methods such as Integriti software, Automation Comms Task, 3-badge arming, etc. will not start the exit delay timer.</p>
	Use 2 Stage Arming From Terminals. (Controller firmware V16.0.0 or later only)	<p>This option is relevant to EN50131/BS8243 compliance and allows the Installer to specify which Area/s are required to comply with the 2-stage arming procedure. <i>Refer to the Integriti Application note; "Recommended Installation Procedures For EN50131 Grade 3 Compliance."</i></p> <p>NOTE: Prior to V16, this feature was enabled for all Areas by the "Enable EN50131 Processing" option in the Control Module Details 'General Behaviour' options.</p>

	Test for Users when Arming.	<p>Provides a warning if any Users are considered to still be in the Area when it is about to be armed.</p> <p>This option only applies when the Arming operation is being performed at an LCD Terminal or Colour Graphic Terminal.</p> <p>When an Area is Armed successfully, the number of Users in that Area is set to zero.</p>
	Force Area Pre-Arm Walk Test	<p>If there are any Inputs in the Area that must be tested before the next arming, force a pre-arm walk test when the Area is armed at an LCD or Graphic Terminal.</p> <p>V4.2.3 or later firmware is recommended if there are Walk-Test Inputs that are assigned to more than one Area.</p>
	Sub Area	<p>Allows a sub Area to be defined.</p> <p>The Sub Area will be controlled by the state of its associated Area.</p> <p>Sub-Area programming allows a one or more Areas to control the state of a common Area.</p> <p>e.g. The common Area (Sub-Area) will disarm when the first Area it is associated with disarms, and will only rearm when all of the Areas it is associated with are armed.</p>
	<u>Defer Arming Options</u> Defer Area. Defer Time	<p>Allows this Area to be timed off (deferred) by a User with the appropriate permission settings.</p> <p>e.g. When a User turns the Area off, the defer timer is started. If a User turns the Area off again while the defer timer or warning timer is still running, the defer timer will be re-started (i.e. arming deferred). If the timer + warning timer is allowed to expire, the Area will automatically re-arm.</p> <p>For this feature to operate, the Area must be defined as a Defer Area by enabling this option.</p> <p>Determines how long this area will remain Off (Disarmed) when turned off and a Defer timer is triggered.</p> <p>Enter a value in Hours, Minutes, Seconds.</p> <p>Maximum value is 1 hr, 49 min, 13 sec.</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) The User' Menu Group or the Action that performs the Disarm operation must also have the Defer operation enabled. 2) The warning time is programmed in the Controller 'General Behaviour' settings. <p>Firmware V3.2.2 or later allows Defer Arm of an Area regardless of whether it is currently armed or disarmed. Prior to V3.2.2 firmware, Defer Arm can only be performed on an Area that is currently armed.</p>

	<u>Pulse Counting Options</u> Max Pulse Count Pulse Time	For all Inputs in this Area that are programmed as a “Pulse Zone” via their Process Group, the nominated Pulse Count value must be reached within the programmed Pulse Time in order to trigger an alarm. Determines the number of pulse counts required within the pulse time to generate an alarm. Enter a value of up to 255. Determines the pulse count time to apply to Inputs in this Area that are programmed as Pulse Zones. Enter Pulse Time in Hours, Minutes, Seconds. A value of up to 1 h, 49 m, 13 s can be entered. The Pulse Count Timer starts when the first ‘Pulse Zone’ Input is triggered. If the timer expires, and the Pulse Count is not reached, the Pulse Counter is reset and no alarm is triggered.
	Test Time.	Sets the maximum time for Zone Walk Testing. Enter a value in Hours, Minutes, and Seconds. Maximum value is 1 hr, 49 min, 13 sec.
	Arm Self-Test Count	Determines the number of times this Area must be switched ON before a Zone self-test is performed. If left at 0, Zone Self-Test is disabled. If set to a non-zero value, then every nominated number of arms, at the end of exit delay, any input that has “Zone self-test” enabled and has not had a seal to alarm transition since the last Zone Self-Test will assert the ZST fail state, or de-assert the ZST fail state if it passed. In addition a review message will be saved.
	<u>Re-arm options</u> Re-arm Time Re-arm Qualifier Invert Re-arm Qualifier.	The Re-arm options provide a feature whereby the Area can be programmed to automatically re-arm if a specified period of Input inactivity has elapsed. Program a re-arm time. If there is no Input activity in this Area for the nominated period of time, the Area will re-arm. If left at 0, the Area will never re-arm automatically. A Re-arm Qualifier may be assigned to the re-arm operation. This entity must be valid for Rearm to occur. e.g. Another Area must already be On. Additional options may be presented depending on the Qualifier Type selected. If enabled, the Re-arm Qualifier must be Invalid for Area Re-arm to occur.
	Battery Test on Area Arm	Forces a short Battery Test on all Batteries in the System on an Area Arming.

	Arm 2 nd Stage Delay	Allows a 2 nd Stage Arm delay time to be entered. When 2 nd Stage Arm is started, the process will be delayed by this time before Inputs are tested to allow any Input contacts to settle. (e.g. Because someone just left the Area and closed the Door). “Arm 2 nd Stage Delay” is only relevant to systems in which “Enable EN50131 processing” has been selected in the Control Module options. <i>See Control Module and Process Group programming for more details.</i>
	Hold-up Confirmation Time (Controller Firmware V4.2.2 or later only)	If EN50131 Confirmed (verified) alarm logic is being used with Hold-up alarms, then the hold-up confirmation time is programmed here. The Holdup Confirmation Time is the maximum time between independent holdup alarms that can be counted as a confirmed holdup alarm. This option must be set to a value of at least 8 hours. A value of up to 18 hours may be entered.
	Soak Test Time	Program the duration required to Soak test Inputs. <i>See “ISOLATE/SOAK TEST AN INPUT” for details.</i>
Entry / Exit	Entry Delay Timer	Sets the Entry delay period upon triggering an entry zone. Enter a value in Hours / Minutes / Seconds. Maximum value is 1 hr, 49 min, 13 sec.
	Exit Delay Timer	Sets the Exit delay period on Area arming if required. Enter a value in Hours / Minutes / Seconds. Maximum value is 1 hr, 49 min, 13 sec.
Siren Programming	Siren Modules	Determines what sirens will sound when an Input programmed to activate sirens is triggered. Sirens are selected by selecting one or more of the Modules that support Siren outputs. At present, the Integriti Security Controller, Zone Expander Modules and Graphic Terminals can be assigned. Note that the Graphic Terminal only supports Siren tones via its built-in speaker and cannot be used to drive a Horn Speaker or Piezo Screamer. Up to 8 Siren Modules may be assigned to an Area. Additional Sirens may be assigned via the Siren Action or Area Process Actions if required.
	Siren Time:	Determines the siren activation time for sirens assigned to this Area. Check local regulations for any limits on the length of time that Sirens are allowed to run. Enter a value in Hours, Minutes, Seconds. Maximum value is 1 hr, 49 min, 13 sec.
	Siren Holdoff Time:	Determines the Siren Holdoff time for sirens assigned to this Area. The Siren Holdoff time is the amount of time that Siren activation will be delayed. Enter a value in Hours, Minutes, Seconds. Maximum value is 1 hr, 49 min, 13 sec.

	<p>Internal Siren Mode:</p> <p>No Siren Instant Siren Siren on 2nd Hit</p> <p>Siren on Backup Siren if got confirm pin.</p>	<p>Determines how the Internal Sirens will work if required.</p> <p>No Internal Sirens. Triggered instantly. Triggered on the 2nd hit on any Input programmed to activate Sirens. Only triggered if the Backup Comms Task has been triggered. Only triggered if the confirm pin for this Area is activated to indicate a verified alarm condition.</p>
	<p>External Siren Mode</p> <p>No Siren Instant Siren Siren on 2nd Hit Siren on Backup Siren if got confirm pin.</p>	<p>Determines how the External Sirens will work if required.</p> <p>Options are the same as for Internal Siren Mode above.</p>
	<p>Max Siren Triggers</p>	<p>Determines the number of siren activations that can occur in this area before sirens become disabled. The trigger count applies to one arming cycle. Sirens will automatically be re-enabled when the Area is disarmed.</p>
	<p>Siren Action</p>	<p>You may select another Entity type or additional Siren that will be controlled when the Siren Activates &/or Deactivates.</p> <p>After an entity type is chosen, the additional options relevant to control of that type of entity will be displayed.</p>
User Counting	<p>Count Action</p>	<p>Select Count Action - Select the Entity type that will be controlled when the Counter reaches/exceeds the High Count and/or reaches/drops below the Low Count.</p> <p>After an entity type is chosen, the additional options relevant to control of that type of entity will be displayed.</p>
	<p>User Trigger Count High</p>	<p>Determines the Trigger Count High value for Area User Counting. The Count Action will be asserted if the Count value reaches or goes above this value.</p>
	<p>User Trigger Count Low</p>	<p>Determines the Trigger Count Low value for Area User Counting. The Count Action will be De-asserted if the Count value reaches or goes below this value.</p>
Area State Actions		<p>Programs the Actions that will occur when the corresponding Area state is Asserted and/or De-asserted.</p> <p>After an entity type is chosen, the additional options relevant to control of that type of entity will be displayed.</p> <p><i>See Action Programming in “Generic Programming Operations” for more details.</i></p>
	<p>Close Action</p>	<p>Select Close Action - Select the Entity type that will be controlled when this Area is Armed / Disarmed</p>
	<p>Entry Action</p>	<p>Select Entry Action - Select the Entity type that will be controlled when this Area’s Entry Delay Starts / Ends</p>
	<p>Exit Action</p>	<p>Select Exit Action - Select the Entity type that will be controlled when this Area’s Exit Delay Starts / Ends</p>

	Walk (Zone) Test Action	Select Test Action - Select the Entity type that will be controlled when this Area Starts / Ends Input testing
	Warning Action	Select Warn Action - Select the Entity type that will be controlled when this Area starts / ends the Defer Arming Warning Timer.
	Isolate Action	Select Isolate Action - Select the Entity type that will be controlled when Inputs in this Area are Isolated / De-isolated.
	Unseal Action	Select Unseal Action - Select the Entity type that will be controlled when Inputs in this Area are Unsealed / Sealed
Process Alarm Actions (Area Input Actions)	Process Action 1 (Strobe) Process Action 2 Process Action 3 Process Action 4 Process Action 5 Process Action 6 Process Action 7 Process Action 8	<p>Programs the Actions that will occur when at least one of the Input states specified in the corresponding Process Group Input Action are Asserted and/or De-asserted.</p> <p>Up to 8 Area Input Actions are available.</p> <p>Select an Entity type that will be controlled by the Area Input Process Action. After an entity type is chosen, the additional options relevant to control of that type of entity will be displayed.</p> <p>For an Area Input Process Action to operate, the corresponding Input Action/s must be enabled in the Process Group.</p> <p>Note that some of the default Process Groups have Action 1 (Typically used for Strobe control) and Action 2 already defined for the Alarm state and Tamper state respectively where relevant.</p>

<p>Event Tones</p>	<p>Exit Tone Entry Tone Arm Problem Tone Arm Fail Tone Arm OK Tone Warn Tone</p>	<p>Select the Siren Tone to be sounded for any of the Area Event Tone options required.</p> <p>The Siren Tones available are listed and described in ‘Siren Programming’ under Process Group programming.</p> <p>Note that different siren tones have different priorities so that if more than one Area triggers the same Siren, the highest priority Siren Tone will be sounded. <i>See ‘Siren Tone’ in Process Group programming for the Siren Tone priorities.</i></p> <p>Siren tone to sound during Exit Delay period. Siren tone to sound during Entry Delay period. Siren tone to sound if there is a problem during the arming procedure. e.g. Unsealed Zones. Siren tone to sound if the Area failed to Arm. e.g. Select the “Chirp: Arm Fail” tone to sound if this Area fails to arm via a Reader 3-badge or Button arming attempt. Note: For this option to work with 3-badge or button arming: <ul style="list-style-type: none"> - V3 Stream requires Firmware V3.3.13 or later. - V4 or later requires Firmware V4.1.0 or later. Siren tone to sound when the Area successfully Arms. Siren tone to sound during the Defer Arm warning period.</p> <p>CAUTION: Legacy Concept 3000/4000 Expander Modules.</p> <ol style="list-style-type: none"> 1) If Controller Firmware is prior to V4.2.0.23848, this feature <u>must not</u> be used with Sirens on legacy Concept 3000/4000 Expander Modules. 2) If Controller Firmware is V4.2.0.23848 or later, only the “Bell”, “Sweep”, “Fire” & “Evacuation” tones are supported and will sound for 30 seconds. 3) If Controller Firmware is V4.2.3 or later, any tone can be selected and will sound for 30 seconds. However, tones not supported by the Module (e.g. Chirp tones) will be replaced with one of the supported tones listed in note 2 above as follows: Chirp: Arm Fail = Bell Chirp: Arm Success = Sweep Chirp: Beep = Fire Chirp: Double Beep = Evacuation Exit Delay = Fire Warning = Evacuation.
<p>Verify Options</p>		<p>The following options apply to systems installed to comply with the requirements of EN50131/BS8243.</p> <p><i>Refer to the Integriti Application note; “Recommended Installation Procedures For EN50131 Grade 3 Compliance.”</i></p>

	Confirmed Alarm Options	<p>These options allow the alarm confirmation logic to be customized for each Area and are applicable only to EN50131 markets. Controller Firmware V4.2.2 or later only.</p>
	No Confirm On During Entry Delay	<p>If selected, then alarms on inputs in this Area while the Area is in entry delay will not generate a confirmed alarm. i.e. If unlocking the entry Door starts the entry delay. If Entry Delay expires without the Area being disarmed, then the primary zone will be treated as the first activation in the sequential confirmation logic and the confirm timer will start as normal. Any other alarms that occurred on other inputs in the Area while the entry delay timer was running would be processed normally, but would not count towards a confirmed intruder alarm.</p>
	Prevent Confirm After Entry	<p>Once a Primary Zone has triggered entry delay, enabling this option will disable all confirmation logic until the next arming, even after entry delay has expired. Inputs are otherwise processed normally except that they can't generate a confirmed intruder alarm. This option is used where forcing the entry Door could start the entry timer.</p> <p>IMPORTANT (EN50131/BS243): Your attention is drawn to the fact that by allowing this method of unsetting, if an intruder succeeds in forcing the initial entry door, the police will not be called, regardless of the intruder's further progress through the supervised premises. This method of unsetting the intruder alarm system might be unacceptable to your insurers.</p>
	Lockout This Area Allowed	<p>Enable for any Areas where the UK Lockout function (if enabled) is required to operate. i.e. Where arming must be prevented if the Area has previously generated a fault, tamper or confirmed intruder alarm. Enabling this option will prevent the area from being armed via an LCD Terminal, Integriti Graphic Terminal, Card Reader, etc., until the lockout is cleared by an authorized User. e.g. An Engineer, Control Room, or by a special action such as "Clear Lockout".</p>
	Isolate at End of Confirm Time	<p>At the expiry of the Confirm timer, isolate all unsealed inputs in this Area. This option is normally enabled in all Intruder Alarm Areas.</p>
	Extended Entry	<p>If the entry delay timer expires, start the Warning Tone and extend entry delay a further 30 seconds. Delays reporting of alarms that occurred during entry after expiry of entry timer by 30 seconds as mandated by BS8243.</p>

	Verify Group	<p>If this Area is reported via the EN 32 Pin Comms Task, a Verify Group number must be assigned to enable alarm confirmation logic for this Area.</p> <p>Pins generated by this Area belong to the nominated Verify Group. A Verify Group number assigned to an Area must correspond to the verify group number programmed in the relevant Group in the EN32pin Comms Task.</p> <p>If all areas are grouped together for the purpose of input processing and reporting, then group 0 may be used.</p> <p>If the STU has enough pins and more than one set of Area pins are to be processed, or where there is more than one STU connected, then additional Verify Group numbers can be implemented.</p> <p>An EN 32 Pin Comms Task will only report Pin states from Areas which have a matching Verify Group assigned. Areas that share a Verify Group number, will also confirm each other's alarms.</p>
	Confirm Time	<p>Program the Confirmed Alarm Time in Hours, Minutes and Seconds.</p> <p>Program the Confirmed Alarm Timer period to be used in the sequential confirmation logic.</p> <p>The Confirm Time is the maximum time between independent alarms that can be counted as a confirmed alarm.</p> <p>Recommended settings for this timer are from 30 to 60 minutes in accordance with BS8243. If this Area is assigned to a Verify Group with other Areas also assigned, the Confirm Time should be set to the same value for all Areas in the Group</p>
	Pending Indication Auxiliary	<p>This option allows an Auxiliary or Auxiliary List to be assigned that will turn on when there are indications (Terminal messages) in the system waiting to be inspected by a User.</p> <p><i>See Important Notes on this option in the Integriti Application note; "Recommended Installation Procedures For EN50131 Grade 3 Compliance."</i></p>

Inputs	<p>Area Input assignment.</p> <p>+ Add</p> <p>- Remove</p> <p>Change Process Group</p>	<p>The 'Inputs' dialogue allows you to add, remove and modify inputs for processing in an Area.</p> <p>Click on the 'Add' button to select one or more Input/s to be assigned to this Area, then select the Process Group that will be used for the Input/s.</p> <p>To remove an input from the Area, select one or more inputs from the list of inputs in the Area, and then click on the 'Remove' button.</p> <p>To change the way an input is processed in the Area, select one or more inputs from the list of inputs in the Area, click on the 'Change Process Group' button, then select a new Process Group.</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) An Input can be assigned to a maximum of eight (8) different Areas. Additional pairs of Input and Process Group selections are made for each Area that the Input is assigned to. 2) System Inputs can be assigned to an Area as described above or via the 'Assign System Inputs' Wizard. <i>See below.</i>
--------	--	---

	<p>Assign System Inputs</p> <p><u>Module Selection pane.</u></p> <p>All Modules Online Modules Secured Modules</p> <p>Clear Selection Select All</p> <p>Module List</p> <p><u>Process Group pane.</u></p> <p>System Input types selection</p> <p>Detect from existing</p> <p>Reset to defaults</p> <p>Exclude Alarm</p> <p>Update Existing</p> <p>Analyse</p> <p>OK</p>	<p>The 'Assign System Inputs' Wizard allows the installer to choose one or more types of System Inputs and one or more Modules in order to bulk assign the related System Inputs to the Area.</p> <p>In some systems all system inputs are simply assigned to a "System Area". Alternatively, several different Areas may be used for different types of System Inputs. e.g. Tamperers, Power problems, Comms problems and Access Alarms. Since one or more types of System Inputs can be selected, either option is simple to achieve with this feature.</p> <p>Show all Modules that are enrolled on the LAN. Show only Modules that are currently on-line. Show only Modules that are currently on-line and have been secured on the LAN.</p> <p>Clear all Module selections in the Module List. Select all Modules in the Module List.</p> <p>Use the Module list to check that all expected Modules are present and select &/or de-select specific Modules to be included in the operation.</p> <p>The nominated inputs are normally assigned using appropriate Process Groups from the default Process Groups available. <i>See the table; "Integrati Default Process Group Contact ID Event Codes and typical applications" at the end of Process Group programming for examples of the System Inputs that relate to each of the default Process Groups.</i></p> <p>Select one or more types of System Inputs to be included in the operation.</p> <p>The 'Detect from existing' option allows the Process Groups to be chosen according to how System Inputs have already been manually assigned to Areas in the system.</p> <p>Resets the System Input type and Process Group relationships to the factory default.</p> <p>Prevents inputs that are currently in the alarm state from being included in the operation.</p> <p>System Inputs not matching the specified criteria are removed from the Area and existing System Inputs already in the Area are updated to reflect this policy.</p> <p>Analyses the system based on the specified criteria to determine the number of each type of System Input that will be included in the operation. The results are displayed in brackets alongside each System Input type.</p> <p>When all selection criteria have been chosen, click on the OK button to start the 'Assign System Inputs' operation.</p>
--	---	--

Modules

ID Letter	Module Type	Description	F'ware
		The following Modules are currently supported in Integriti Controller Firmware: The default Module name displayed in the navigation pane is shown in brackets. "nn" is the Module number.	Min. Cont. F'ware Version Req'd
C	Control Module	Integriti Security Controller (ISC) Integriti Access Controller (IAC)	- V4.0.2
T	LCD Terminal	Elite X Keypad. (EliteXTerm: nn) Elite X-SIFER Keypad. (EliteXTerm: nn) Concept 3/4000 Elite LCD Terminal. (C3K-LcdTerm: nn) Concept 3/4000 Terminal Emulator. (C3K-LcdTerm: nn)	<i>See below</i> V17.0.1 V1 V1
G	Graphic Terminal (Prisma)	Integriti Graphic Terminal. (GraphicTerm: nn) Integriti Prisma-SIFER Terminal. (GraphicTerm: nn)	V1.2 V4.3.0
E	Expander (Wired Expander)	Integriti 8-32 Zone Expander. (WiredExp: nn) Integriti 16-Zone Expander. [Obsolete] (WiredExp: nn) Infiniti 8-Zone Encrypted (Class 5) Expander. (WiredExp:nn) Concept 3/4000 Universal Expander, 32Z. (C3K-BigExp: nn) Concept 3/4000 Universal Expander, 16Z. (C3K-SmallExp: nn) Concept 3/4000 Mini Expander. (C3K-MiniExp: nn) Concept 3/4000 Analogue Module. (C3K-Alog: nn)	V2.5.2 V3.0 V4.3.0 V1 V1 V1 V1
F	Radio Expander	Integriti Inovonics RF LAN Expander. (RadioExp: nn) Concept 3/4000 Visonic Wireless I/F. (C3K-RadioExp: nn) Concept 3/4000 Paradox Wireless I/F. (C3K- RadioExp: nn)	V17.0.0 V1 V1
S	Encrypted Expander	Not yet implemented. Note: The 8-Zone Encrypted (Class 5) Expander is enrolled as a 'Wired Expander' (E).	
R	Reader	Integriti Standard LAN Access Module (2 Door). i.e. SLAM. (2DoorRdr: nn) Concept 3/4000 2-Door Access Module. (C3K-2DAM: nn) Concept 3/4000 Single Door Access Module. (C3K-2DAM: nn) Concept 3/4000 Weatherproof Terminal. (C3K-2DAM: nn)	V4.0 V1 V1 V1
I	Intelligent Reader	Integriti Intelligent LAN Access Module. i.e. ILAM/Salto (8DoorRdr: nn) Concept 3/4000 Intelligent 4-Door Access Module. (C3K-IRdr: nn)	V3.1.4 V2.5.0
P	LAN Power Supply	Concept 3/4000 LAN Power Supply Module. (C3K-PwrSupply: nn)	V1.1

LCD Terminal

LCD Terminal programming is relevant to the following hardware Modules:

- Elite X Keypad. NOTE: EliteX is supported in all Controller firmware versions, but requires V17.0.0 or later for full feature support. *See the latest Integriti Product Catalogue or the EliteX Keypad Installation Manual for details.*
- Elite X-SIFER Keypad. (V17.0.1 or later only)
- Concept 3/4000 / Integriti Elite LCD Terminal.
- Concept 3/4000 Terminal Emulator Module.

Note that some configuration options for Elite, EliteX and EliteX-SIFER Terminals are done from the Terminal Keypad. These options are described under 'Commissioning' in the Installation manuals for each of those products.

Entity/Feature	Option	Description
Create/Find LCD Term		'Add New' or select a record to Alter.
LCD Terminal Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.
General Options	Associated Area	Determines the Associated Area for this LCD Terminal. Used in conjunction with other LCD Terminal options.
	Associated Area List	Determines the Associated Area for this LCD Terminal. Used in conjunction with other LCD Terminal options.
	LCD Terminal Options No Keypad Beep. No Immediate Entry Disarm Single Area Tenancy Exit Display. Exit Beep. Require Card+PIN to Login	Select the general LCD Terminal options required. No feedback beep when keys are pressed. Note that some alerts will still cause the keypad to beep. No Area Off allowed if the Entry Timer for the Associated Area still has <u>more than</u> 30 seconds remaining. Terminal is used in a single Area Tenancy. Only Area operation is allowed. Show Exit Timer countdown for the associated Area. Beep during exit timer for the associated Area. Exit display/beep options Cont. F/ware V2.5 or later only. Card AND PIN is required to logon to this LCD Terminal. This option is an enhancement of the Reader 'Terminal Logon' feature that allows a User to logon to the Terminal with their access credential (card). To use this option: - The 'Reader Purpose' for the Reader to be used in the logon operation must be set to 'Log On'. - This LCD Terminal must be assigned in the Reader 'PIN Device' option. Requires Controller firmware V4.3.0 or later. V17.0.1 or later required for EliteX-SIFER Keypad.
	LED Mode. None Area Array	Select the default LED operation for this LCD Terminal. LEDs are controlled by the associated Auxiliary only. LEDs will display Area status by default.
	EOL for Zones	Select the End of Line Resistor Scheme for an Elite X Keypad. This option is normally left blank allowing the default 'Concept3K' EOL scheme to be used. See "Inputs" in the Controller "Module Details" programming for details of the EOL Scheme options. NOTE: This option is only relevant to the EliteX Keypads. Other LCD Terminal type modules (e.g. Elite Terminal) that are compatible with Integriti, do not support EOL Resistors.

<p>Logged Off Display Options.</p>	<p>Idle Display</p> <p>System Ready System Time Single Area Area Array</p>	<p>This message will be displayed on the LCD whilst logged off.</p> <p>The text “System Ready” is displayed The current system time and date is displayed. The status of the Associated Area is displayed A status array for the Associated Area and the subsequent 7 Areas is displayed.</p> <p>NOTE: V4.1.0 or later. The display of any logged-off Terminal is auto-refreshed at midnight every day to update any level messages and time displays.</p>
	<p>Display options</p> <p>Display Alarm Messages. Display Status Messages. Display LCD Messages. Display Input Levels. Display Single Message. Display Area Arm Warning.</p>	<p>Select the types of messages that the LCD Terminal is allowed to accept. <i>Also see note in ‘Idle Display’ above.</i></p> <p>Area Alarm Messages allowed. Area Alarm Message Categories must also be programmed. Select whether terminal will display System Status messages such as Power Supply, Battery, Communication or LAN Network problems. Select whether terminal will display custom LCD Messages. An LCD Message, if Valid, will override the selected Idle Display. Input Level messages allowed. Terminal will display a Single Message for the Associated Area. (Limited Messages) Restricts the LCD Messages to the Defer Arm Warning (“Area about to turn on”) and LCD Message 1 broadcasts.</p>
	<p>Alarm Message Categories</p>	<p>Message Categories 1-8 determine which Area Zone state messages will be displayed on this LCD terminal.</p> <p>Messages will be displayed for Zones that have a matching category set in their Process Group.</p>
<p>Logged Off Keys</p>	<p>Up/Down Arrow Mode</p> <p>None Area Array Area Text</p>	<p>Select the Up/Down Arrow key operation for Area Status.</p> <p>No Area status available via the Up/Down Arrow keys. Up/Down Arrow keys will display Area status as an array of 8 Areas per screen. Up/Down Arrow keys will display Area status as a text message, one Area at a time.</p>
	<p>Logged Off Operations.</p> <p>Allow Quick Alarm Review Allow Named Actions</p> <p>Allow Aircon Control Allow Show Info Allow Logged Off Panic</p>	<p>Select the LCD Terminal operations allowed when logged off.</p> <p>Quick Alarm Review allowed via <MENU>, <1>. Named Actions allowed via the > key. Note that the named action must have the “Allow Logged Off Access” option enabled. Aircon Control (Not yet implemented) System Information allowed via <MENU>, <2> . The LCD Terminal “Panic” System Input can be triggered by pressing the <HELP> key 3 times in succession. Note that since this is a “logged off” operation, the LCD Terminal rather than the User will be identified in Review and Reporting messages.</p>

Access Control	Associated Door	Select a Door to be associated to this LCD terminal. The Door nominated will be controlled and monitored by this terminal.
	Access Control Options. Access Only. No Lock. (V1 to V2 only) Zone 2 Rex Zone 2 Opposite Side	This Terminal may only be used for access control. CAUTION: Once set, you will not be able to access other operations or Menus from this Terminal. Set to 'Y' if there is no lock hardware for this Door. LCD Terminal Zone 2 functions as the Exit (REX) button LCD Terminal Zone 2 REX/REN button is on the Opposite side of the Door to where this Terminal is installed.
	Door Hardware Hardware Type Lock Number Unibus DIP Switch Number Enable Reed Input Enable Tongue Input.	Not relevant to LCD Terminals. Not required for LCD Terminals. Not relevant to LCD Terminals. Allow Door Reed Switch logic for this Door. Allow Tongue Sense logic for this Door.
	Reader On-Board (Wiegand) Unibus Door Module Etc. Number / Serial Number	The remaining Access Control options relate to Reader operation. Note that some of the options are not relevant to LCD Terminals. Elite Terminal / EliteX Keypad: Not used. EliteX-SIFER Keypad: Set to "SIFER". Not required for an EliteX-SIFER Keypad.
	Reader 01 Purpose Control a Door Control a Lift Log On Area Toggle Access Locker / Locker Bank	Reader Purpose defines how the Reader will be used. EliteX-SIFER Keypad Only. Door access control. Lift access control. Terminal Logon. A Valid Card presentation logs the User on to the associated LCD Terminal. Controller Firmware V3.1.0 or later recommended if this feature is used. Area On/Off only. No access control operations. "Keypad Area" below must be programmed. Locker access control.
	Reader 01 Location None Inside Door 1 Outside Door 1	Determines the location of the Terminal in relation to the associated Door; Inside or Outside. Only the Door 1 options are relevant to an LCD Terminal.
	Keypad Area.	Reader Keypad Area. Select the Area to control when the Reader purpose is "Area Toggle". EliteX-SIFER Keypad Only.
	Locker / Bank	Select the Locker or Bank of Lockers that this Reader grants access to. EliteX-SIFER Keypad Only.

	<p>Card Format.</p> <p>Direct Entry Wiegand 26Bit Wiegand (H10301) etc...</p>	<p>This screen allows the Card Format to be selected. Card Formats are programmed separately. A wide range of default Card Formats are available.</p> <p>Elite Terminal / EliteX Keypad: Not used. EliteX-SIFER Keypad: Set to “SIFER Site Code” or “SIFER Direct 88”</p> <p><i>See the table under “Card Formats” in the ‘Access Control’ section for the full list of default card formats and their details.</i></p>
	<p>Any Card Mode.</p>	<p>If enabled, any card of the correct type will be allowed access and the card data will be logged to Review.</p> <p>EliteX-SIFER Keypad Only.</p>
	<p>PIN Device (Entity for PIN Code Entry)</p>	<p>Select a Module/Reader to be used for entering the PIN Code when Card + PIN is required.</p> <p>EliteX-SIFER Keypad Only. Requires Controller firmware V17.0.1 or later.</p>
	<p>Wiegand PIN Mode.</p> <p>None Motorola HID Reader MR Access Model Reader 26 Bit Wiegand Keypad IR Weatherproof Terminal 26 Bit Wiegand Keypad Forced</p>	<p>Select the PIN data mode if a “Reader” was selected in the “PIN Device” option above.</p> <p>EliteX-SIFER Keypad Only.</p> <p>No PIN entry requirement. Motorola/Indala ARK-501 HID 5355 or iClass with 4 Bit Burst PIN output format. MR Access Magnetic Swipe & PIN code Reader 26 Bit Wiegand Keypad. Inner Range Weatherproof Terminal. 26 Bit Wiegand Keypad Forced.</p>
	<p>Reader Arming Mode</p> <p>No Reader Arming User Area w/button Area Empty</p> <p>Exit Area w/button Entry Area w/button</p> <p>Exit Area on 3 Swipes Entry Area on 3 Swipes</p> <p>Arm Users ‘Tenancy Area’ on 3 Swipes.</p>	<p>Select the Area Arming Mode if the Reader is to be used for Area Arming on Access Control operations.</p> <p>No Arming. Not relevant to LCD Terminals. Arm the Exit Area (Area you are leaving) if the Area User Count decrements to zero when access is granted. V4.2.0 or later recommended. Not relevant to LCD Terminals. Not relevant to LCD Terminals.</p> <p>The following options are for EliteX-SIFER Keypad Only. Arm the Exit Area if Card presented 3 times within 5 seconds. Arm the Entry Area if Card presented 3 times within 5 seconds. Arm the User’s Tenancy Area if Card presented 3 times within 5 seconds. (Controller F/ware V3.2.1 or later only)</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) Exit Area / Entry Area. The Exit Area is the Area you are leaving. i.e. The Area the Reader is installed in. The Entry Area is the Area on the opposite side of the Door to where the Reader is installed. 2) 3 Swipe Arming. V3.3.0 firmware or later provides a Controller option for setting a different “Three Badge Wait” time.

	Ask PC	This option allows User Credentials presented at this Reader to be utilized in the Active User Rotation Module (AURM) feature and/or the Operator Challenge feature if necessary. <i>AURM</i> See the “Enable AURM” option in the Controller General Behaviour options for more details. <i>OPERATOR CHALLENGE</i> See the Integriti Software “Guide - Operator Challenge” document for more details.
	Skip Known Review (V16.0.0 or later)	Enable this option to prevent card data review entries for cards that are associated with a User in the Controller. Do not enable this option if you require the Card ‘Last Used’ field updates to be maintained or if the Card Expiry feature is being used in the system.
Security (Incorrect PIN Lockout)	Lockout attempts	The number of incorrect PIN entries before the LCD terminal is Locked Out. The number of tries must occur within the Attempts Time.
	Lockout Time	Defines how long this LCD terminal will reject PIN operations once the number of Lockout Attempts has been reached within the Attempts Time.
	Attempt Timeout (V1 to V4.0.0 only)	PIN attempts Timer. The amount of time in which the Lockout Attempts must be reached before the LCD terminal becomes Locked Out. This is the time required to elapse before the lockout count is reset after an illegal PIN has been entered.
LAN Module settings	LAN Poll Time	Enter a Poll Time in Minutes, Seconds. The Poll time is the maximum amount of time a module can remain out of communication with the Control Module.
	Battery Installation Date Battery Ambient Temperature Battery Needs Replacement Battery Test Time	Battery options are not applicable to LCD Terminals.
	LAN Module Type C3K LCD Terminal EliteX Terminal	This option allows the Installer to view or select the type of LCD Terminal connected for this LCD Terminal address. The correct type will normally be automatically chosen when the Module is first connected to the system. If the Module is being programmed prior to being connected to the system, the type will need to be selected. At present, the options ‘C3K LCD Terminal’ and ‘EliteX Terminal’ are relevant LCD Terminal types.
	Unibus Devices	Not applicable to LCD Terminals.
	Enable on LAN Disable on LAN	This operation is available by Right-clicking on the Module in the “Navigation” Pane. Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting or performing service.

Extra Restrictions.	<p>What</p> <p>When</p>	<p>Up to 6 Permissions can be assigned to an LCD Terminal to place additional restrictions on the operations allowed to be performed.</p> <p>e.g. A limited permission set may be required at particular LCD Terminals during certain times of the day, or while a particular Area is armed or disarmed.</p> <p>Defines the entity for this Permission. e.g. Menu Group, Area List, etc.</p> <p>Defines when the entity is valid for this Permission. e.g. Time Period, Area state, etc.</p> <p><i>See Permission programming in “Generic Programming Operations” for details.</i></p>
---------------------	-------------------------	--

Integriti Colour Graphic Terminal (Prisma)

Note that some configuration options for Integriti Prisma Terminal and Prisma-SIFER Terminal are done from the Terminal Keypad. These options are described under ‘Commissioning’ in the Installation manuals for each of those products.

The text presented on the LCD display of Integriti Graphic Terminals may be translated into other languages. Note that this applies to text generated within the module such as the assignable button labels, menus, prompts, help, etc.

Text generated by the Controller for display on a Graphic Terminal such as messages, review events, etc. are translated using a separate software utility.

Contact Inner Range Technical Support for details.

Entity/Feature	Option	Description
Create/Find Graphic Terminal		‘Add New’ or select a record to edit. Controller firmware V4.2.4 or later recommended.
Module Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.
General Options	Associated Area	Determines the Associated Area for this Terminal. Used in conjunction with other Terminal options.
	<p>Graphic Terminal Options</p> <p>No Keypad Beep.</p> <p>Entry Display.</p> <p>Entry Beep.</p> <p>Exit Display.</p> <p>Exit Beep.</p> <p>Require Card+PIN to Login.</p>	<p>Select the general Terminal options required.</p> <p>No feedback beep when keys are pressed.</p> <p>Show Entry Timer countdown for the associated Area.</p> <p>Beep during entry timer for the associated Area.</p> <p>Show Exit Timer countdown for the associated Area.</p> <p>Beep during exit timer for the associated Area.</p> <p>Card AND PIN is required to logon to this Graphic Terminal. This option is an enhancement of the Reader ‘Terminal Logon’ feature that allows a User to logon to the Terminal with their access credential (card).</p> <p>To use this option:</p> <ul style="list-style-type: none"> - The ‘Reader Purpose’ for the Reader to be used in the logon operation must be set to ‘Log On’. - This Graphic Terminal must be assigned in the Reader ‘PIN Device’ option. <p>Requires Controller firmware V4.3.0 or later.</p>

	<p>LED Mode.</p> <p>None Area Array (Red / Off)</p> <p>Area Array (Red / Green)</p> <p>Auxiliary</p> <p>Idle Entities</p>	<p>Select the default LED operation for the eight LEDs across the top of the Graphic Terminal.</p> <p>For the purposes of this option, the LEDs are numbered 1 to 8 from Left to Right.</p> <p>No LED control. LEDs will display Area status by default with Red LEDs only. (Red = Armed)</p> <p>LEDs will display Area status by default with Red and Green LEDs. (Red = Armed)</p> <p>LEDs are controlled by their associated Auxiliary only. Graphic Terminal Auxiliaries 9 to 16 are used for this purpose. i.e. LED 1=Gnn:X09, LED 2=Gnn:X10, etc.</p> <p>When the Terminal is logged off, the LEDs will display the current state of up to eight entities selected in the “Idle Entities” option described below. If more than eight Entities are selected, the LEDs will display the status of the first eight.</p>
	EOL Index (EOL [End-Of-Line] Resistor Scheme for Zone Inputs)	Select the End Of Line Resistor scheme to be used for the Zone Inputs on this Integriti Graphic Terminal.
	Air-Conditioner	Air-Conditioner to be controlled by this Terminal.
	Air-Conditioner Zone	Air-Conditioning Zone to be controlled by this Terminal.
Logged Off Display	Idle Entities.	<p>Up to 10 entities may be chosen for which the Graphic Terminal will display the current state.</p> <p>Currently, Areas are the only Entity relevant to this option.</p> <p>Via the Screen: NOTE: If using this option, only 6 Entities may be selected. The state of the selected Entities will be displayed in the selected circumstances on the Colour Graphic Screen when the Terminal is logged off and the “Idle Entities” setting is chosen in one or more of the Logged Off Display options.</p> <p>Via the LEDs: The state of up to 8 of the selected Entities will be displayed on the LEDs when the Terminal is logged off and the “Idle Entities” setting is chosen in the “LED Mode” option.</p>
	<p>Idle Display.</p> <p>System Ready System Time Single Area Idle Entities</p> <p>Time Digital</p> <p>Time Analogue</p> <p>Zones Icons</p>	<p>This message will be displayed on the Graphic Terminal Colour display whilst logged off.</p> <p>The Integriti logo is displayed. The current system time and date is displayed. The status of the Associated Area is displayed The Icons, Names and Status of up to 6 selected “Idle Entities” is displayed. <i>See “Idle Entities” above.</i> Time & Date is displayed as a large digital clock with the date displayed below. Time is displayed in analogue (clock face) format in the top left of the screen. Not currently supported. Four logged off menu icons are displayed. (PIN Code, Review, Information and Control)</p>

	Idle Area Off Display.	This alternative message will be displayed on the Graphic Terminal if an associated Area has been assigned to the Terminal, and that Area is Off. Options as above.
	Display options Display Alarm Messages. Display Status Messages. Display LCD Messages. Display Input Levels. Display Area Arm Warning.	Select the types of messages that the Terminal is allowed to accept. Area Alarm Messages allowed. Area Alarm Message Categories must also be programmed. Select whether terminal will display System Status messages such as Power Supply, Battery, Communication or LAN Network problems. Select whether terminal will display custom LCD Messages. An LCD Message, if valid, will normally be displayed in addition to the selected Idle Display. If "Idle Entities" has been chosen for the Idle display, and there are 4 or more Idle Entities selected, LCD messages cannot be displayed. Input Level messages allowed. (Limited Messages) Restricts the LCD Messages to the Defer Arm Warning ("Area about to turn on") and LCD Message 1 broadcasts.
	Alarm Message Categories	Message Categories 1-8 determine which Area Zone state messages will be displayed on this Terminal. Messages will be displayed for Zones that have a matching category set in their Process Group.
Logged Off Keys	Logged Off Key Operations. Allow Quick Alarm Review Allow Named Actions Allow Aircon Control Allow Show Info Allow Logged Off Panic	Select the Terminal operations allowed when logged off. Quick Alarm Review allowed via <MENU>, <2>. Named Actions allowed via <MENU>, <1>. Note that the named action must have the "Allow Logged Off Access" option enabled. Aircon Control allowed via <MENU>, <3>. System Information allowed via <MENU>, <4>. The Terminal "Panic" System Input can be triggered by pressing the <HELP> key 3 times in succession. Note that since this is a "logged off" operation, the Terminal rather than the User will be identified in Review and Reporting messages.
Access Control	Associated Door	Select a Door to be associated to this Terminal. The Door nominated will be controlled and monitored by this terminal.
	Access Control Options. Access Only. No Lock. (V1 to V2 only)	This Terminal may only be used for access control. CAUTION: Once set, you will not be able to access other operations or Menus from this Terminal. Set to 'Y' if there is no lock hardware for this Door
	Door Hardware Hardware Type Lock Number Unibus DIP Switch Number Enable Reed Input Enable Tongue Input.	The Graphic Terminal has no physical I/O. Door Hardware options are not currently relevant to Graphic Terminals.

	Dual Code Wait Time.	Enter a Dual Code Time in Minutes and Seconds. Determines how long this Terminal will wait for the second PIN Code in a dual PIN entry.
	Reader On-Board (Wiegand) Unibus Door Module SIFER Etc. Number / Serial Number	The remaining Access Control options relate to Reader operation. Note that some of the options are not relevant to Graphic Terminals. Select 'SIFER' for Prisma-SIFER Terminals. The Reader number option is not relevant to Graphic Terminals.
	Reader 01 Purpose Control a Door Control a Lift Log On Area Toggle Access Locker / Locker Bank	Reader Purpose defines how the Reader will be used. 'Log On' and 'Area Toggle' are only relevant to Prisma-SIFER Terminals. Door access control. Lift access control. Not relevant to Graphic Terminals. Terminal Logon. A Valid Card presentation logs the User on to the associated Graphic Terminal. Controller Firmware V3.1.0 or later recommended if this feature is used. Area On/Off only. No access control operations. The "Keypad Area" option below must also be programmed. Locker access control.
	Reader 01 Location None Inside Door 1 Outside Door 1	Determines the location of the Terminal in relation to the associated Door; Inside or Outside. Only the Door 1 options are relevant to a Graphic Terminal.
	Keypad Area.	Reader Keypad Area. Select the Area to control when the Reader purpose is "Area Toggle".
	Locker / Bank	Select the Locker or Bank of Lockers that this Reader grants access to. Prisma-SIFER Terminals only.
	Card Format. SIFER Direct 88 SIFER Site Code etc...	This screen allows the Card Format to be selected. Card Formats are programmed separately. A wide range of default Card Formats are available. Prisma-SIFER Terminals support the 'SIFER Direct 88' and 'SIFER Site Code' formats. <i>See the table under "Card Formats" in the 'Access Control' section for the full list of default card formats and their details.</i>
	Any Card Mode.	If enabled, any card of the correct type will be allowed access and the card data will be logged to Review. Prisma-SIFER Terminals only.
	PIN Device (Entity for PIN Code Entry)	Select a Module/Reader to be used for entering the PIN Code when Card + PIN is required. Prisma-SIFER Terminals only.

	<p>PIN Mode.</p> <p>None Motorola HID Reader MR Access Model Reader 26 Bit Wiegand Keypad IR Weatherproof Terminal 26 Bit Wiegand Keypad Forced</p>	<p>Select the PIN data mode if a Reader was selected in the “PIN Device” option above.</p> <p>No PIN entry requirement. Motorola/Indala ARK-501 HID 5355 or iClass with 4 Bit Burst PIN output format. MR Access Magnetic Swipe & PIN code Reader 26 Bit Wiegand Keypad. Inner Range Weatherproof Terminal. 26 Bit Wiegand Keypad Forced.</p> <p>Prisma-SIFER Terminals only.</p>
	<p>Reader Arming Mode</p> <p>No Reader Arming User Area w/button</p> <p>Area Empty</p> <p>Exit Area w/button</p> <p>Entry Area w/button</p> <p>Exit Area on 3 Swipes Entry Area on 3 Swipes</p> <p>Arm Users ‘Tenancy Area’ on 3 Swipes.</p>	<p>Select the Area Arming Mode if the Reader is to be used for Area Arming on Access Control operations. Prisma-SIFER Terminals only.</p> <p>No Arming. Arm the User Area if the “Arm” button is pressed while the Card is presented. Arm the Exit Area (Area you are leaving) if the Area User Count decrements to zero when the Card is presented. V4.2.0 or later recommended. Arm the Exit Area if the “Arm” button is pressed while the Card is presented. Arm the Entry Area if the “Arm” button is pressed while the Card is presented. Arm the Exit Area if Card presented 3 times within 5 seconds. Arm the Entry Area if Card presented 3 times within 5 seconds. Arm the User’s Tenancy Area if Card presented 3 times within 5 seconds. (Cont F/ware V3.2.1 or later only)</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) SOME OF THESE OPTIONS NOT RELEVANT TO GRAPHIC TERMINAL. e.g. ARM BUTTON OPERATION. 2) Exit Area / Entry Area. The Exit Area is the Area you are leaving. i.e. The Area the Reader is installed in. The Entry Area is the Area on the opposite side of the Door to where the Reader is installed. 3) 3 Swipe Arming. V3.3.0 firmware or later provides a Controller option for setting a different “Three Badge Wait” time.
	<p>Ask PC</p>	<p>This option allows User Credentials presented at this Reader to be utilized in the Active User Rotation Module (AURM) feature and/or the Operator Challenge feature if necessary.</p> <p><i>AURM</i> See the “Enable AURM” option in the Controller General Behaviour options for more details.</p> <p><i>OPERATOR CHALLENGE</i> See the Integriti Software “Guide - Operator Challenge” document for more details.</p>

	Skip Known Review (V16.0.0 or later)	<p>Enable this option to prevent card data review entries for cards that are associated with a User in the Controller.</p> <p>Do not enable this option if you require the Card 'Last Used' field updates to be maintained or if the Card Expiry feature is being used in the system.</p>
Security (Incorrect PIN Lockout)	Lockout attempts	<p>The number of incorrect PIN entries before the Terminal is Locked Out.</p> <p>The number of tries must occur within the Attempts Time.</p>
	Lockout Time	Defines how long this Terminal will reject PIN operations once the number of Lockout Attempts has been reached within the Attempts Time.
	PIN Attempt Timeout	<p>PIN attempts Timer.</p> <p>The amount of time in which the Lockout Attempts must be reached before the Terminal becomes Locked Out.</p> <p>This is the time required to elapse before the lockout count is reset after an illegal PIN has been entered.</p>
LAN Module settings	LAN Poll Time	Enter a Poll Time in Minutes, Seconds. The Poll time is the maximum amount of time a module can remain out of communication with the Control Module.
	Battery Test Time	Not applicable to Graphic Terminals.
	LAN Module Type	<p>This option allows the Installer to view or change the type of Graphic Terminal connected for this Graphic Terminal address.</p> <p>The correct type will normally be automatically chosen when the Module is first connected to the system.</p> <p>If the Module is being programmed prior to being connected to the system, the type will need to be selected.</p>
	Graphic Terminal	At present, only the option 'Graphic Terminal' is relevant.
	Unibus Devices	Not currently applicable to Graphic Terminals.
	Enable on LAN Disable on LAN	<p>This operation is available by Right-clicking on the Module in the "Navigation" Pane.</p> <p>Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting service.</p>
Extra Restrictions.	What When	<p>Up to 6 Permissions can be assigned to a Graphic Terminal to place additional restrictions on the operations allowed to be performed.</p> <p>e.g. A limited permission set may be required at particular Terminals during certain times of the day, or while a particular Area is armed or disarmed.</p> <p>Defines the entity for this Permission. e.g. Menu Group, Area List, etc.</p> <p>Defines when the entity is valid for this Permission. e.g. Time Period, Area state, etc.</p> <p><i>See Permission programming in "Generic Programming Operations" for details.</i></p>

Expander

Expander programming is relevant to the following Modules:

- Integriti 8-32 Zone Expander.
- Integriti 16-Zone Expander.
- Infiniti 8-Zone Encrypted (Class 5) Expander
- Concept 3/4000 Universal Expander, 32 Zone (B).
- Concept 3/4000 Universal Expander, 16 Zone (E).
- Concept 3/4000 Mini Expander.
- Concept 3/4000 Analogue Module.

Entity/Feature	Option	Description
Create/Find Expander		'Add New' or select a record to edit.
Module Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.

Inputs	EOL for Zones... (EOL [End-Of-Line] Resistor Configuration for Zone Inputs)	<p>Select the End Of Line Resistor Configuration to be used for the Zone Inputs on this Integriti Expander.</p> <p>A config. can be selected for each block of 8 Zone Inputs: Block 1: Zones 1 to 8 Block 2: Zones 9 to 16 Block 3: Zones 17 to 24 Block 4: Zones 25 to 32</p> <p>This option is normally left blank allowing the default 'Concept3K' EOL configuration to be used.</p> <p><i>See "Inputs" in the Controller "Module Details" programming for details of the EOL Scheme options.</i></p> <p>Note that this option is only relevant to:</p> <ul style="list-style-type: none"> • Integriti 8-32 Zone Expander. • Integriti 16-Zone Expander (No longer available). • Infiniti 8-Zone Encrypted (Class 5) Expander. • Concept 3/4/5000 Universal Expander V8.0 or later. P/N: 995004EUPCB&K (Europe only) <p><u>Infiniti 8-Zone Encrypted (Class 5) Expander</u> One block of 8 Zone Inputs is supported on a Class 5 Expander and all are Infiniti ELM RS485 connections. i.e. Block 1: Zones 1 to 8. However, an EOL Configuration must still be chosen to indicate how the alarm and tamper contacts are wired to the ELM device. A 'Class 5..' configuration may be selected (if available), or a new EOL configuration may be programmed depending on how the ELM devices will be wired. <i>Refer to the 'Infiniti Class 5 Installer Manual' & 'Infiniti Encrypted LAN Expander Installation Manual' for details.</i></p> <p><u>Concept 3000/5000 Expanders.</u> With the exception of the Universal Expander listed above, legacy Concept 3000/4000 Universal Expanders Rev H or later have EOL scheme selection available via on-board DIPswitch options.</p> <p>Other legacy Concept 3000/4000 Expanders that are compatible with Integriti, do not have selectable EOL.</p>
Advanced Settings.	Analogue Hysteresis	<p>Enter an Analogue Hysteresis value.</p> <p>This is the sensitivity to changes in analogue values to initiate a change of state.</p> <p>NOTE: Used for legacy Concept 3000 Analogue Modules only. For Integriti Expanders, this option is set in the relevant Input programming.</p>
	C3K Analogue Mode Standard Freezer (temp -55 to 70 deg C)	<p>This option sets the mode for Concept 3000/4000 Analogue Modules.</p> <p>0 to 5V input or Inner Range Serial Temperature Sensor (0-127 deg C, 0.5deg/bit) Temperature only. -55 to 70 deg C, 0.5deg/bit using Inner Range Serial Temperature Sensor. Controller Firmware V4.1.0 or later only.</p>

Obsolete Options	AC Hold-Off Time	<p>Specifies the period that an AC Fail condition may exist before the AC Fail System Input is triggered for this Module.</p> <p>Only required in Controller Firmware up to V3.0. In Controller Firmware V3.1 or later, this option is programmed in the General Controller Programming.</p>
LAN Module settings	Poll Time	<p>Enter a Poll Time in Minutes, Seconds.</p> <p>The Poll time is the maximum amount of time a module can remain out of communication with the Control Module.</p>
	Battery Test Time	<p>Enter a Battery Test Time in Hours and Minutes.</p> <p>Determines the battery test time for this Module.</p> <p>For an Integriti 8-Zone LAN Expander, this is the battery test time for an Integriti Smart power supply connected to the Module.</p> <p>For some guidelines on setting the Battery test time, see 'Battery Test Time' in Controller - Module Details.</p>
	LAN Module Type	<p>This option allows the Installer to view or change the type of LAN Expander Module connected for this Expander address. All Module types are shown in the drop-down list, but only relevant Module types for 'Expander' are listed here.</p> <p>The correct type will normally be automatically chosen when the Module is first connected to the system.</p> <p>If the Module is being programmed prior to being connected to the system, the type will need to be selected.</p> <p>The following types are relevant to Expander programming:</p> <p>Concept 3000/4000 Analogue Module. Concept 3000/4000 Mini Expander (8Z) Module. Concept 3000/4000 Expander Module 'E' type. Concept 3000/4000 Expander Module 'B' type. Infiniti 8-Zone Encrypted (Class 5) Expander. V4.3 or later. Integriti 8-32 Zone LAN Expander (current) or Integriti 16 Zone LAN Expander (obsolete)</p>
	Unibus Devices	<p>Define the Unibus devices installed on relevant types of Integriti Expander Modules.</p> <p>The Unibus devices IDs are normally automatically entered when the device is first connected to the system.</p> <p>Not relevant for any Concept Expanders or the Class 5 Expander.</p>
	Enable on LAN Disable on LAN	<p>This operation is available by Right-clicking on the Module in the "Navigation" Pane.</p> <p>Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting service.</p>

Radio Expander (RF/Wireless Expander)

Radio Expander programming is relevant to the following Modules:

- Concept 3/4000 Visonic Wireless LAN Module.
- Concept 3/4000 Paradox Wireless LAN Module.

- Integriti Inovonics Wireless LAN Expander. Controller Firmware V17 or later only.

Entity/Feature	Option	Description
Create/Find Radio (RF) Module.		'Add New' or select a record to edit.
Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.
Inputs	EOL	Not relevant to RF Expanders.
Advanced Options	OK Feedback Action None Control Area Control Area List Control Aux Control Aux List etc.	Allows an entity to be chosen to provide feedback for "OK" indication. e.g. A Siren Chirp, or an Auxiliary that controls a Beeper. When an action entity is selected additional options will be displayed to program the remaining action settings. <i>See Action programming in "General Programming Operations for programming details.</i>
	RF Poll Time.	Enter a Transmitter Poll Time. The Poll time is the maximum amount of time an RF device can remain out of communication with the RF Expander Module. Visonic or Paradox: The value entered is in Hours. Inovonics: The value entered is in Minutes. AU/NZ Transmitters send a poll every 4 minutes, so a value of 6 (1 missed poll) to 10 minutes (2 missed polls) is suggested. EU Transmitters send a poll every 12 minutes, so a value of 18 to 30 minutes is suggested. <i>Check relevant standards and regulations.</i>
	US Jamming	Enable US Jamming detection algorithm.
Logging	Log Missed RF. Log RF Zone Details. Log RF Remote Details.	An event is logged to Review to indicate re-synchronizing of a Fob that is slightly out of sync with the Receiver. Logs Wireless Sensor activity to Review. Logs Wireless Remote activity to Review. This option no longer available.
Remotes	Enable RF Remotes	Enable RF Remotes and log all RF Remote button presses to review.

Sensor Registry.	RF Sensor ID 1 to 32 (HEX)	<p>View, Enter or Select the RF device IDs for registration with this module. The device ID is entered in HEXADECIMAL format.</p> <p>Up to 32 devices can be registered to each Module. Each device is assigned to a Zone Input on the RF Expander Module allowing alarm and tamper conditions to be monitored.</p> <p>Note that some transmitter types such as Remotes, Smoke Detectors, etc. may not provide tamper monitoring. <i>Refer to manufacturers information for details.</i></p> <p>A device cannot be registered to more than one Zone.</p> <p>Additional Transmitter conditions such as Poll Fail, Low Battery and RF Jam, where available, will be reported on the associated RF Expander Module System Inputs. Review Events will be saved to identify the specific device on which the problem has occurred.</p> <p>If the device ID is known, it can be entered manually in the field for the nominated RF Expander Zone Input.</p> <p>Otherwise, clicking on the selection button <...> on the right end of an RF Sensor ID field will open the 'Sensor ID Picker' window.</p> <p>This window allows you to view real-time RF Transmitter review events to select the Transmitter ID to be assigned to this Zone Input.</p> <p><i>For Inovonics Transmitters and Repeaters, see additional notes below.</i></p>
------------------	----------------------------	--

	RF Sensor Notes.	<p>Inovonics Transmitters. <i>For a list of compatible Inovonics Transmitters see the 'Integriti/Inception Inovonics RF Expander Module Application Note'.</i></p> <p>When an Inovonics Transmitter with 2 or more alarm inputs or button functions is enrolled as a Zone Input, the Integriti system cannot differentiate between the different inputs or button functions.</p> <ul style="list-style-type: none"> - An alarm on <u>either</u> of the Inputs on an EN1212 or EN1941 general purpose transmitter will cause an alarm state on the associated Zone Input. - A High-temp <u>or</u> Low-temp condition on an EN1752 Temperature Detector will cause an alarm state on the associated Zone Input. - <u>Any</u> button or combination of buttons on an EN1224 or EN1236D Pendant will cause an alarm on the associated Zone Input. <p>(Note that different Pendant button functions are recognized when a Pendant Transmitter is enrolled as a 'Remote'. See 'RF Remotes' for details.)</p> <p>Inovonics Repeaters. The device ID of any Inovonics Repeaters used in the system can be registered to RF Expander Module Zone Inputs to allow monitoring of faults or power problems. Cabinet Tamper will be reported on the nominated Zone Input, while Poll Fail, Mains Fail, Low Battery and RF Jam will be reported on the associated RF Expander Module System Inputs. Review Events will be saved to identify the specific Repeater on which the problem has occurred.</p>
LAN Module	Poll Time	Enter a Poll Time in Minutes and Seconds. The Poll time is the maximum amount of time a module can remain out of communication with the Control Module.
	Battery Test Time	Not relevant to the current range of RF Expander Modules.
	LAN Module Type	<p>This option allows the Installer to view or change the type of Radio Expander Module connected for this Radio Expander address. All Module types are shown in the drop-down list, but only relevant Module types for 'Radio Expander' are listed here.</p> <p>The correct type will normally be automatically chosen when the Module is first connected to the system. If the Module is being programmed prior to being connected to the system, the type will need to be selected.</p> <p>C3K RF Expander RF Expander</p> <p>Concept 3000/4000 Visonic RF Expander or Paradox RF Expander. Integriti Inovonics RF LAN Expander.</p>
	Unibus Devices	Not relevant to the current range of RF Expander Modules.
	Enable on LAN Disable on LAN	<p>This operation is available by Right-clicking on the Module in the "Navigation" Pane.</p> <p>Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting service.</p>

Reader Module (2 Door)

Reader Module programming is relevant to the following 2-Door and Single Door Modules:

- Integriti SLAM. (Standard LAN Access Module). Controller Firmware V4.0 or later only.
- Concept 3000/4000 2-Door Access Modules.
- Concept 3000/4000 Single Door Access Modules.
- Concept 3000/4000 Weatherproof Terminal.

Depending on the Reader Module type and the Reader type, up to 4 Readers can be connected to a 2 Door Reader Module.

- 1 or 2 Readers can be connected via the on-board Wiegand/Clock&Data ports.
- Up to 2 or 4 Serial Readers (as listed in the table below) can be connected via the 'Reader RS485' Port. (SLAM only)

Note that when a Serial Reader type is selected for a Reader, any other Serial Readers on that Module must be of the same type.

Reader Type	Integriti Modules			Legacy C3000/4000 Modules		
	SLAM	Min SLAM F'ware	Min ISC/ IAC F'ware	2-Door	1-Door	W'proof Term
Wiegand Reader / Keypad	2			2	1	1
SIFER Reader	4	V2.0	V4.0	0	0	0
SIFER Keypad	4	V2.0	V16.0.1	0	0	0
OSDP Reader	4	V2.0	V4.2.0	0	0	0
Salto	2	V2.1.2	V4.2.4	0	0	0
Aperio Wireless Lock Reader	2	V2.1.0	V4.1.3	0	0	0
Intego	2	V2.1.1	V4.2.0	0	0	0
Tecom	4	V3.0.6	V17	0	0	0

Entity/Feature	Option	Description
Create/Find Reader Module		'Add New' or select a Record to edit.
Module Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.

<p>Readers. These options are programmed separately for each Reader.</p>	<p>Reader Type</p> <p>On-Board (Wiegand)</p> <p>Unibus Door Module SIFER</p> <p>OSDP</p> <p>Salto</p> <p>Aperio</p> <p>Wiegand Keypad Intego Tecom</p>	<p>Select the type of Reader for each Reader number required. Some Reader options that follow the Reader type selection will be dependent on the type selected.</p> <p>The options unique to each Reader Type are provided in the heavy-bordered cells immediately following this option.</p> <p>Options common to all Reader Types then follow.</p> <p>Note that when a Serial Reader type is selected for a Reader, all other Serial Readers on this SLAM must be of the same type. i.e. SIFER, OSDP, Salto, Aperio, Intego or Tecom.</p> <p>Wiegand or Clock & Data Reader on the host Reader Module board.</p> <p>Not relevant to SLAM.</p> <p>SIFER Reader or SIFER Keypad on the host module Reader RS485 port.</p> <p>Third party OSDP Reader on the host module Reader RS485 port.</p> <p>Salto Reader via a Salto Router on the host module Reader RS485 port. Controller firmware V4.2.4 or later required to support Salto on SLAM.</p> <p>Aperio Wireless Lock Reader via an Aperio Hub on the host module Reader RS485 port. Note: At present, Aperio Readers cannot be used for Lift control or Terminal Logon. <i>See the document 'Integriti Application Note – Aperio Integration' for full details on integrating Aperio Wireless Locks.</i></p> <p>Wiegand Keypad Reader on host Reader Module board.</p> <p>Intego Reader via the host module Reader RS485 port.</p> <p>Tecom TS0870 series Smart Card Readers on the host module Reader RS485 port. V17 or later only. Requires SmartCard licence. <i>Refer to the Integriti Application Note: "Tecom TS0870 Series Smart Card Reader Integration" for a detailed description of installation and programming requirements for Tecom Readers.</i></p>
	<p><u>On-Board (Wiegand)</u></p> <p>Number</p>	<p>Options for the 'On-Board (Wiegand)' type.</p> <p>The Wiegand Reader Port number to be used on the host Reader Module. Reader Module (2-Door) or ILAM: Enter a setting of 1 or 2. C3/4K Intelligent Reader: Enter a setting of 1 to 8.</p>
	<p><u>Unibus Door Module</u></p> <p>Dip Switch Number</p> <p>Number</p>	<p>Options for the 'Unibus Door Module' type. ILAM only. Not relevant to SLAM.</p> <p>The DIP switch number of the Unibus Door Module. Unibus Door modules on ILAMs use a setting of 2, 3 or 4. The Wiegand Reader Port number to be used on the nominated Unibus Door module. Enter a setting of 1 or 2.</p>

	<p><u>SIFER or OSDP</u></p> <p>Serial Number / Number</p> <p>Volume Maximum Brightness</p> <p>Feedback Mode</p> <p>-Area state – ‘Keypad Area’ -Area state – Same side -Area state – Other side -Door state -Associated Locker state</p> <p>Main LED Colour / LED Colour</p> <p>Small LED Colour</p> <p>LED Area State options.</p> <p>Show Area Status Arm/Disarm Show Area Status Isolated</p> <p>Show Area Status Entry Delay Show Area Status Exit Delay Show Area Status Had Alarm</p> <p>Suppress DOTL Tone</p>	<p>Options for the ‘SIFER’ or 3rd party ‘OSDP’ Reader types.</p> <p>Enter or select the SIFER Reader Serial Number or OSDP Reader Number. <i>See Note below.</i> Reader Beeper Volume. (SIFER only) Reader LED maximum brightness. (SIFER only)</p> <p>Visual feedback mode for the LED. For SIFER Reader, these options apply to the small LED. State of the area defined in the ‘keypad area’ option. State of the area on the same side of the Door as the Reader. State of the area on the other side of the Door to the Reader. State of the Door associated with this Reader. State of the Locker associated with this Reader.</p> <p>Select a colour for the main LED from the range of: - 23 colours provided for SIFER. - 5 colours provided for OSDP. (V4.2.0 or later only)</p> <p>Select a colour for the small LED from the range of 23 colours provided. (SIFER only)</p> <p>The following options can be enabled if the ‘Feedback Mode’ has been set to one of the “Area State...” options above. For SIFER Reader, these options apply to the small LED. SIFER OR OSDP OPTIONS: Armed = Green. Disarmed = Red. No sound. Amber. No sound. (V17.0.3 or later only) SIFER ONLY OPTIONS: Slow flashing green and slow chime sound during entry delay. Slow flashing green and slow chime sound during exit delay. Fast flashing red and alarm sound.</p> <p>Select this option to prevent the Reader beeper from sounding during a DOTL (Door Open Too Long) condition. V4.2.0 or later only.</p> <p>NOTE: SIFER Serial Number / OSDP Reader Number. Click on the selection button to view the Readers connected to this Module. The selection pane will open and will show all Readers connected categorized as either “Available” or “In Use”. The Serial Number, Firmware Version and other data is displayed for every Reader. To see the list of the Readers connected to all IAC, SLAM and ILAM Modules in the system, uncheck the “Module ID...” filter box at the bottom of the pane. This feature can be useful when wanting to check if any Readers are missing and if the firmware is up to date on all Readers.</p>
	<p><u>Salto</u></p> <p>Number</p>	<p>Options for the ‘Salto’ type.</p> <p>The ‘logical number’ of this reader on its host device.</p>

	<p>Reader Purpose</p> <p>Control a Door Control a Lift Log On</p> <p>Area Toggle Access Locker / Locker Bank</p>	<p>Reader Purpose defines how the Reader will be used.</p> <p>Door access control. Lift access control. Terminal Logon. A Valid Card presentation logs the User on to the associated LCD Terminal. Controller Firmware V3.1.0 or later recommended if this feature is used. Area On/Off only. No access control operations. Locker access control.</p>
	<p>Reader Location</p> <p>None Inside Door 1 Outside Door 1 Inside Door 2 Outside Door 2 Inside Door 3...etc.</p>	<p>Determines which Door the Reader is associated with, and the location of the Reader in relation to the Door; Inside or Outside.</p> <p>Typically, Access Control Readers are Entry Readers, and are therefore located 'Outside' the nominated Door.</p> <p>A Reader can also be located 'Inside' the nominated Door when the Reader is an Exit Reader, or when there are Readers on both sides of a Door.</p> <p>If the Reader Type is "Aperio", the Door number used in the Reader Location setting must match the Reader number. e.g. If Reader 3 an 'Aperio' type, then its 'Location' must be set to "Outside Door 3".</p> <p>Reader is not associated with a Door. Reader is located Inside the 1st Door. Reader is located Outside the 1st Door. Reader is located Inside the 2nd Door. (2-Dr Modules only) Reader is located Outside the 2nd Door. (2-Dr Modules only)</p> <p>Options for Doors 3 to 8 are not relevant to Reader Modules.</p>
	<p>Keypad Area.</p>	<p>Reader Keypad Area. Select the Area:</p> <ul style="list-style-type: none"> - To control when the Reader purpose is "Area Toggle". - To display if the "keypad area" option is selected in the SIFER/OSDP Reader 'Feedback Mode'.
	<p>Locker / Bank</p>	<p>Select the Locker or Bank of Lockers this Reader grants access to.</p>
	<p>Card Format.</p> <p>Direct Entry Wiegand 26Bit Wiegand (H10301) etc.</p>	<p>This option allows the Card Format to be selected.</p> <p>Card Formats are programmed separately and are used to define the Card Type, bit length and Site Code parameters (if relevant) within a single Entity.</p> <p>A wide range of default Card Formats are available.</p> <p>If the required format is not in the list, additional Card Formats can be added via Card Format programming.</p> <p><i>See the table under "Card Formats" in the 'Access Control' section for the full list of default card formats and their details.</i></p> <p>If a Reader is required to support 2 or more Card Formats an option is available in 'Card Format' programming to define an "Alternate Card Format" that will be used if the card data does not match the total number of bits defined for that format. <i>See 'Card Formats' for more details.</i></p>

	Any Card	Any card of the correct type will be allowed access and the card data will be logged to Review.
	PIN Device (Entity for PIN Code Entry)	Select a Module/Reader to be used for entering the PIN Code when Card + PIN is required. Controller Firmware V3.1.0 or later recommended if this feature is used with an Elite LCD or Integriti Prisma Graphic Terminal.
	Wiegand PIN Mode. None SIFER / OSDP / Motorola HID Reader MR Access Model Reader 26 Bit Wiegand Keypad IR Weatherproof Terminal 26 Bit Wiegand Keypad Forced	Select the PIN data mode if a Reader” was selected in the “PIN Device” option above. No PIN entry requirement. SIFER Keypad, 3 rd Party OSDP Reader with Keypad or Motorola/Indala ARK-501 HID 5355 or iClass with 4 Bit Burst PIN output format. MR Access Magnetic Swipe & PIN code Reader 26 Bit Wiegand Keypad. Inner Range Weatherproof Terminal. 26 Bit Wiegand Keypad Forced. This reader can only be used for PIN codes. If enabled, any 26 bit Wiegand data received from this Reader will be processed as a PIN Code regardless of the Site Code. Cards will not be able to be used at this Reader. If disabled, only 26 bit Wiegand data with Site Code 255 (FF) will be processed as a PIN Code and any other Site Code will be processed as a Card. Normally a 26bit Wiegand Keypad has the site code \$FF (255) with the card number representing the PIN code. If the reader sends some other site code with a PIN or \$FF is actually a site code used by the system, then this option can be used to force any 26bit card number to be treated as a PIN code.

	<p>Arming Mode</p> <p>No Reader Arming User Area w/button</p> <p>Area Empty</p> <p>Exit Area w/button</p> <p>Entry Area w/button</p> <p>Exit Area on 3 Swipes Entry Area on 3 Swipes</p> <p>Arm Users 'Tenancy Area' on 3 Swipes.</p>	<p>Select the Area Arming Mode if the Reader is to be used for Area Arming on Access Control operations.</p> <p>No Arming. Arm the User Area if the "Arm" button is pressed while the Card is presented. Arm the Exit Area (Area you are leaving) if the Area User Count decrements to zero when the Card is presented. V4.2.0 or later recommended. Arm the Exit Area if the "Arm" button is pressed while the Card is presented. Arm the Entry Area if the "Arm" button is pressed while the Card is presented. Arm the Exit Area if Card presented 3 times within 5 seconds. Arm the Entry Area if Card presented 3 times within 5 seconds. Arm the User's Tenancy Area if Card presented 3 times within 5 seconds. (Cont F/ware V3.2.1 or later only)</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) Exit Area / Entry Area. The Exit Area is the Area you are leaving. i.e. The Area the Reader is installed in. The Entry Area is the Area on the opposite side of the Door to where the Reader is installed. 2) 3 Swipe Arming. V3.3.0 firmware or later provides a Controller option for setting a different "Three Badge Wait" time. 3) 3 Swipe Arming with C3/4k Weatherproof Terminals. V17.0.1 firmware or later recommended.
	Ask PC	<p>This option allows User Credentials presented at this Reader to be utilized in the Active User Rotation Module (AURM) feature and/or the Operator Challenge feature if necessary.</p> <p><i>AURM</i> <i>See the "Enable AURM" option in the Controller General Behaviour options for more details.</i></p> <p><i>OPERATOR CHALLENGE</i> <i>See the Integrati Software "Guide - Operator Challenge" document for more details.</i></p>
	Skip Known Review (V16.0.0 or later)	<p>Enable this option to prevent card data review entries for cards that are associated with a User in the Controller.</p> <p>Do not enable this option if you require the Card 'Last Used' field updates to be maintained or if the Card Expiry feature is being used in the system.</p>
Door Access Control	Door 1 (First Associated Door)	<p>Select the first Door to be assigned to this Reader Module. The Door nominated will be controlled and monitored by this Module.</p>

	<p>Door 1 Hardware.</p> <p>Hardware Type</p> <ul style="list-style-type: none"> - On-Board - Unibus Door Module - Salto - Aperio - Intego - Tecom <p>Lock Number</p> <p>Unibus DIP Switch Number</p> <p>No Lock. (V1 to V2 only)</p> <p>Enable Reed Input</p> <p>Enable Tongue Input</p>	<p>Note: Unibus options are not relevant to SLAM.</p> <p>This setting defines the location of the Door hardware I/O. e.g. Lock Relay, monitoring inputs, status outputs, etc. Door hardware is on the host Reader Module. Door hardware is on a Unibus 2-Door Expander Board. Door hardware is a Salto Lock. Door hardware is an Aperio Wireless Lock via the on-board Reader RS485 Port. Door hardware is an Intego Lock. Door hardware is a TS0870 Reader. Note that this only applies when the Reader is connected via RS485 and only supports lock relay control via the Reader's yellow wire (open collector only) &/or REX button input via the Reader's violet wire. On-board or UniBus hardware is preferred. <i>See the Integriti Application Note: "Tecom TS0870 Series Smart Card Reader Integration" for details.</i></p> <p>Program the lock number of the associated Module or Device selected above.</p> <ul style="list-style-type: none"> -For an on-board lock, enter a value of either 1 or 2. -Aperio Lock: Not required. -Tecom Reader: Enter the Reader LAN Address. <p>Program the DIP Switch setting for the Unibus 2-Door Expander associated with this Door.</p> <p>No Lock. Set to 'Y' if there is no lock hardware for this Door Reed Switch. Allow Door Reed Switch logic for this Door. The state of the Reed Switch Input will be utilized in functions such as Forced Door, DOTL, Interlocking, etc. Tongue Sense. Allow Tongue Sense logic for this Door. The state of the Tongue Sense Input will be utilized in functions such as Forced Door, DOTL, Interlocking, etc.</p>
	Door 2 (Second Associated Door)	<p>Select the second Door to be assigned to this Reader Module if required.</p> <p>If this Reader Module is providing Entry and Exit Readers for the same Door, then a second Door is not assigned. The Door nominated will be controlled and monitored by this Module.</p>
	Door 2 Hardware.	<i>See Door 1 Hardware above.</i>
	<p>General Door options.</p> <p>Disable SLAM Cache</p> <p>No Valid / Invalid Outputs (formerly 'No LEDs')</p> <p>Override EOL</p>	<p>Disable the off-line Card Cache for Doors controlled by this Reader Module.</p> <p>Disable Valid/Invalid indication via the 'VAL'/'INV' Outputs. The Valid/Invalid open collector outputs will only be controlled by the associated Auxiliary.</p> <p>Overrides the EOL Resistor requirement for the REX (Request to Exit) and REN (Request to Enter) Inputs on all Doors on this Module. When enabled, the Normally Open contacts of the switch can be wired directly into the REX and/or REN Inputs with no EOL resistors.</p> <p>In V16.0.0 or later this option is enabled by default for Integriti IAC, ILAM and SLAM Modules.</p>
Lift Access Control	Lift Car 1 (First Associated Lift)	<p>Select the first Lift to be assigned to this Reader Module. The access control Reader interface for the nominated Lift will be provided by this Module.</p>

	Lift Car 2 (Second Associated Lift)	Select the second Lift to be assigned to this Reader Module. The access control Reader interface for the nominated Lift will be provided by this Module. Note that Reader Modules for Lift Control are often installed in the Lift Car. This means that a second Lift Car is usually not assigned to a Reader Module.
Offline Operation	Card Cache Time None 1 Hour 4 Hours 8 Hours 1 Day 2 Days 4 Days 1 Week 2 Weeks 1 Month 2 Months 4 Months	Select the period for which a Cached Card will be retained in the Cache from the last time it was used. Integrati Modules only. Not relevant for Concept 3/4000 Reader Modules. NOTE: If the Card Cache functionality is required, check that the “Disable SLAM Cache” option under ‘Door Access Control’ has not been enabled.
	Button Cache Time	Select the period for which a Cached Button operation will be retained in the Cache from the last time it was used. Integrati Modules only. Not relevant for Concept 3/4000 Reader Modules. Options are the same as those for Card Cache Time above.
	Offline Function. None First 2 Credentials Pass Use Cached Credentials	Determines which card credentials the reader will process in offline mode. No Card access when Module is offline. Allow access for the first 2 Backup Cards only when Module is offline. Allow access to Cards stored in the local Cache when Module is offline.
	Door 1 Entry dual user Door 2 Entry dual user Door 1 Exit dual user Door 2 Exit dual user Door 1 Entry ren button Door 2 Entry ren button Door 1 Exit rex button Door 2 Exit rex button	Standalone Operation options for the Doors assigned to the Module. These requirements will only be relevant while the Module is Offline. Dual User requirement for Entry at first Door. Dual User requirement for Entry at second Door. Dual User requirement for Exit at first Door. Dual User requirement for Exit at second Door. REN button will operate at first Door. REN button will operate at second Door. REX button will operate at first Door. REX button will operate at second Door.

Inputs	EOL for Zones. (EOL [End-Of-Line] Resistor Scheme for Zone Inputs)	Select the End of Line Resistor Scheme for an Integriti Standard (2-Door) LAN Access Module (SLAM). This option is normally left blank allowing the default 'Concept3K' EOL scheme to be used. <i>See "Inputs" in the Controller "Module Details" programming for details of the EOL Scheme options.</i> Note that this option is only relevant to the Integriti 2-Door Reader Module (SLAM). Legacy Concept 3000/4000 Reader Modules that are compatible with Integriti, do not have selectable EOL.
LAN Module	Phantom Module	Defines this Reader Module as a 'phantom' module, meaning that no hardware exists for this module. HLI or Software 'phantom card reads' can use the Reader addresses of the Readers on this module. This feature requires a licence.
	LAN Poll Time	Enter a Poll Time in Minutes, Seconds. The Poll time is the maximum amount of time a module can remain out of communication with the Control Module
	Battery Test Time	Enter a Battery Test Time in Hours and Minutes. Integriti Modules only. Not relevant for Concept 3/4000 Reader Modules. Determines the battery test time for an Integriti Smart power supply connected to this Module. For some guidelines on setting the Battery test time, see 'Battery Test Time' in Controller - Module Details.
	LAN Module Type C3K Two Door Reader Two Door Reader	This option allows the Installer to view or change the type of LAN Reader Module connected for this Reader Module address. All Module types are shown in the drop-down list, but only relevant Module types for 'Reader' are listed here. The correct type will normally be automatically chosen when the Module is first connected to the system. If the Module is being programmed prior to being connected to the system, the type will need to be selected. Concept 3000/4000 2-Door Reader, Single Door Reader or Weatherproof Terminal. Integriti SLAM.
	Unibus Devices	Not relevant to Reader Modules. Integriti SLAM does not support Unibus devices.
	Enable on LAN Disable on LAN	This operation is available by Right-clicking on the Module in the "Navigation" Pane. Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting service.

Connectivity	Serial Reader Settings Serial Channel Baud Rate Data Bits Parity Stop Bits	Integriti SLAM only. Not relevant to Concept hardware. Not currently used. The Serial Reader Port settings are determined automatically and do not need to be programmed when a Serial Reader type is selected in 'Readers' programming for this Module. i.e. SIFER, OSDP, Salto, Aperio, Intego or Tecom.
OSDP Options	OSDP Options Local Feedback Disable Auto Addressing Lockdown Bus Proximity Feedback	The Reader will respond immediately when a card is read. Disables all auto addressing on this bus. This option may be necessary when the bus is being shared with some other OSDP devices. Disables addressing of unknown modules. While locked down, you will be unable to add new Readers to this Module. This option no longer available in V17 or later. When enabled, SIFER Readers will click and flash when a card is detected until the card is close enough to read. This option is useful during commissioning to determine if any Readers have limited read range due to the installation environment or interference, etc. V4.2.0 or later only.
	Crypt Mode Default Custom None	Select the mode of encryption on the OSDP bus for this Module.

Intelligent Reader Module

Intelligent Reader Module programming is relevant to the following hardware Modules:

- Integriti ILAM
- Concept 3/4000 Intelligent 4-Door Access Module (IFDAM) V5.0 or later.
- Concept 3/4000 Intelligent 2-4 Door Access Module (I2DAM) V5.0 or later.

Depending on the Reader Module type and the Reader type, up to 16 Readers can be connected to an Integriti 8 Door Reader Module, or up to 8 Readers to a C3/4K Intelligent Reader Module.

- Up to 8 Readers can be connected via the on-board Wiegand/Clock&Data ports. (Expansion boards required if more than 2)
- Up to 8 or 16 Serial Readers (as listed in the table below) can be connected via the 'Reader RS485' Port. (ILAM only)
Note that when a Serial Reader type is selected for a Reader, any other Serial Readers on that Module must be of the same type.

Reader Type	Integriti ILAM				Legacy C3/4K I2DAM*/IFDAM**	
	Mother-board	With Unibus Expander/s	Min ILAM F'ware	Min ISC/IAC F'ware	Mother-board	With Expansion board/s
Wiegand Reader / Keypad	2	8			2*/4**	8
SIFER Reader	16	n/a	V2.0	V4.0	0	0
SIFER Keypad	16	n/a	V2.0	V16.0.1	0	0
OSDP Reader	16	n/a	V2.2.0	V4.2.0	0	0
Salto	8	n/a	V2.2.0	V3.0.0	0	0
Aperio Wireless Lock Reader	8	n/a	V2.1.1	V4.1.3	0	0
Intego	8	n/a	V2.2.0	V4.2.0	0	0
Tecom	16	n/a	V3.0.4	V17	0	0

NOTE: In earlier firmware some of the Reader programming and Door Hardware programming was found under the headings 'Door Mapping' and 'Reader Mapping'. If your system is one of these earlier versions, you may need to refer to Rev 3.3 of the Integriti Programming Reference.

Entity/Feature	Option	Description
Create/Find Intelligent 4-Door Access Module		'Add New' or select a record to edit. Integriti ILAM requires Integriti Controller Firmware V3.0.0 or later. V3.1.4 or later recommended. Concept 3/4000 Intelligent 4-Door Access Module must be V5.0 or later and the Integriti Controller Firmware must be V2.5.0 or later.
Module Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.
Readers. These options are programmed separately for Readers 1 to 16.	There are 16 logical Readers on an Integriti Intelligent LAN Access Module (ILAM), or 8 logical Readers on a Concept Intelligent Door Access Module (IFDAM or I2DAM).	The Reader details are programmed by defining the type, purpose, mapping/associations, formatting and functional parameters for each logical Reader to be used. Note that when a Serial Reader type is selected for a Reader, all other Serial Readers on this ILAM must be of the same type. i.e. SIFER, OSDP, Salto, Aperio, Intego or Tecom.
	Reader Type On-Board (Wiegand) Unibus Door Module SIFER OSDP Salto Aperio Wiegand Keypad Intego Tecom	Select the type of Reader for each Reader number required. See "Reader Type" in 'Reader Module' programming for more details. Wiegand or Clock & Data Reader on the host Intelligent Reader Module motherboard, or on a C3/4K IFDAM/I2DAM Expansion board. Wiegand or Clock & Data Reader on an Integriti Unibus Door Expander. SIFER Reader or SIFER Keypad on the ILAM Reader RS485 port. OSDP Reader on the ILAM Reader RS485 port. Salto Reader via a Salto Router on the ILAM Reader RS485 port. Aperio Reader via an Aperio Hub on the ILAM Reader RS485 port. Wiegand Keypad Reader on the host Intelligent Reader Module motherboard, or on a C3/4K IFDAM/I2DAM Expansion board. Intego Reader via the ILAM Reader RS485 port. Tecom TS0870 series Smart Card Readers on the ILAM Reader RS485 port. V17 or later only.
	Reader Options	Reader options that follow the Reader type selection will be dependent on the type selected. The options unique to each Reader type are provided in the heavy-bordered cells immediately following the 'Reader Type' option in 2-Door Reader Module programming.

	<p>Reader Purpose</p> <p>Control a Door Control a Lift Log On</p> <p>Area Toggle Access Locker / Locker Bank</p>	<p>Reader Purpose defines how the Reader will be used.</p> <p>Door access control Lift access control Terminal Logon. A Valid Card presentation logs the User on to the associated LCD Terminal. Controller Firmware V3.1.0 or later recommended if this feature is used. Area On/Off only. No access control operations. Locker access control.</p>
	<p>Reader Location</p> <p>None Outside Door 1 Outside Door 2 Outside Door 3 etc. Inside Door 1 Inside Door 2 Inside Door 3 etc.</p>	<p>Determines which Door each Reader is associated with, and its location in relation to the Door; 'Inside' or 'Outside'. Typically, Access Control Readers are Entry Readers, and are therefore located 'Outside' the nominated Door. A Reader can also be located 'Inside' the nominated Door when the Reader is an Exit Reader, or when there are Readers on both sides of a Door.</p> <p>If the Reader Type is "Aperio", the Door number used in the Reader Location setting must match the Reader number. e.g. If Reader 3 an 'Aperio' type, then its 'Location' must be set to "Outside Door 3".</p> <p>Reader is not associated with a Door. Reader is located Outside the nominated Door.</p> <p>Reader is located Inside the nominated Door.</p>
	<p>Keypad Area.</p>	<p>Reader Keypad Area. Select the Area:</p> <ul style="list-style-type: none"> - To control when the Reader purpose is "Area Toggle". - To display if the "keypad area" option is selected in the SIFER/OSDP Reader 'Feedback Mode'.
	<p>Locker / Bank</p>	<p>Select the Locker or Bank of Lockers this Reader grants access to.</p>
	<p>Card Format.</p> <p>Direct Entry Wiegand 26Bit Wiegand (H10301) etc.</p>	<p>This screen allows the Card Format to be selected. Card Formats are programmed separately. A wide range of default Card Formats are available.</p> <p>If the required format is not in the list, additional Card Formats can be added via Card Format programming.</p> <p><i>See the table under "Card Formats" in the 'Access Control' section for the full list of default card formats and their details.</i></p> <p>If a Reader is required to support 2 or more Card Formats an option is available in 'Card Format' programming to define an "Alternate Card Format" that will be used if the card data does not match the total number of bits defined for that format. <i>See 'Card Formats' for more details.</i></p>
	<p>Any Card Mode.</p>	<p>Any card of the correct type will be allowed access and the card data will be logged to Review.</p>

	<p>PIN Device (Entity for PIN Code Entry)</p>	<p>Select a Module/Reader to be used for entering the PIN Code when Card + PIN is required. Controller Firmware V3.1.0 or later recommended if this feature is used with an Elite LCD or Integriti Prisma Graphic Terminal.</p>
	<p>Wiegand PIN Mode.</p> <p>None SIFER / OSDP / Motorola</p> <p>HID Reader MR Access Model Reader 26 Bit Wiegand Keypad IR Weatherproof Terminal 26 Bit Wiegand Keypad Forced</p>	<p>Select the PIN data mode if a Reader” was selected in the “PIN Device” option above.</p> <p>No PIN entry requirement. SIFER Keypad, 3rd Party OSDP Reader with Keypad or Motorola/Indala ARK-501. HID 5355 or iClass with 4 Bit Burst PIN output format. MR Access Magnetic Swipe & PIN code Reader 26 Bit Wiegand Keypad. Inner Range Weatherproof Terminal. 26 Bit Wiegand Keypad Forced. This reader can only be used for PIN codes. If enabled, any 26 bit Wiegand data received from this Reader will be processed as a PIN Code regardless of the Site Code. Cards will not be able to be used at this Reader. If disabled, only 26 bit Wiegand data with Site Code 255 (FF) will be processed as a PIN Code and any other Site Code will be processed as a Card. Normally a 26bit Wiegand Keypad has the site code \$FF (255) with the card number representing the PIN code. If the reader sends some other site code with a PIN or \$FF is actually a site code used by the system, then this option can be used to force any 26bit card number to be treated as a PIN code.</p>
	<p>Reader Arming Mode</p> <p>No Reader Arming User Area w/button</p> <p>Area Empty</p> <p>Exit Area w/button</p> <p>Entry Area w/button</p> <p>Exit Area on 3 Swipes Entry Area on 3 Swipes</p> <p>Arm Users ‘Tenancy Area’ on 3 Swipes.</p>	<p>Select the Area Arming Mode if the Reader is to be used for Area Arming on Access Control operations.</p> <p>No Arming. Arm the User Area if the “Arm” button is pressed while the Card is presented. Arm the Exit Area (Area you are leaving) if the Area User Count decrements to zero when the Card is presented. V4.2.0 or later recommended. Arm the Exit Area if the “Arm” button is pressed while the Card is presented. Arm the Entry Area if the “Arm” button is pressed while the Card is presented. Arm the Exit Area if Card presented 3 times within 5 seconds. Arm the Entry Area if Card presented 3 times within 5 seconds. Arm the User’s Tenancy Area if Card presented 3 times within 5 seconds. (Cont F/ware V3.2.1 or later only)</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) Exit Area / Entry Area. The Exit Area is the Area you are leaving. i.e. The Area the Reader is installed in. The Entry Area is the Area on the opposite side of the Door to where the Reader is installed. 2) 3 Swipe Arming. V3.3.0 firmware or later provides a Controller option for setting a different “Three Badge Wait” time.

	Ask PC	<p>This option allows User Credentials presented at this Intelligent Reader Module to be utilized in the Active User Rotation Module (AURM) feature and/or the Operator Challenge feature if necessary.</p> <p><i>AURM</i> <i>See the “Enable AURM” option in the Controller General Behaviour options for more details.</i></p> <p><i>OPERATOR CHALLENGE</i> <i>See the Integrati Software “Guide - Operator Challenge” document for more details.</i></p>
	Skip Known Review (V16.0.0 or later)	<p>Enable this option to prevent card data review entries for cards that are associated with a User in the Controller.</p> <p>Do not enable this option if you require the Card ‘Last Used’ field updates to be maintained or if the Card Expiry feature is being used in the system.</p>
Door Access Control.	Door 1 to Door 8 assignment. (Associated Doors)	<p>Select the Doors to be assigned to this Intelligent Reader Module. The Doors nominated will be controlled and monitored by this Module.</p>

	<p>Door 1 to Door 8 Hardware.</p> <p>There are 8 logical Doors on an Integrity Intelligent LAN Access Module (ILAM) or 4 logical Doors on a Concept Intelligent Door Access Module (IFDAM or I2DAM).</p> <p>Hardware Type</p> <ul style="list-style-type: none"> - None - On-Board - Unibus Door Module - Salto - Aperio - Intego - Tecom <p>Lock Number</p> <p>Unibus DIP Switch Number</p> <p>No Lock. (V1 to V2 only) Enable Reed Input</p> <p>Enable Tongue Input</p>	<p>The Door Hardware settings are programmed separately for each of the eight Doors.</p> <p>The Door Hardware options define the following parameters for each logical Door to be used:</p> <ul style="list-style-type: none"> - The hardware device type. - The DIP Switch setting on the device (if relevant). - The number of the entity on the device. i.e. Number 1 or 2 if the device supports 2 Readers, or 2 Doors. - The Door monitoring options. <p>This setting defines the location of the Door hardware I/O. e.g. Lock Relay, monitoring inputs, status outputs, etc.</p> <p>Door hardware not present for this Door.</p> <p>Door hardware is on the host Intelligent Reader Module.</p> <p>Door hardware is on a Unibus 2-Door Expander Board.</p> <p>Door hardware is a Salto Lock via the 'RDR RS485' port.</p> <p>Door hardware is an Aperio Wireless Lock via the 'RDR RS485' port.</p> <p>Door hardware is an Intego Lock via the 'RDR RS485' port.</p> <p>Door hardware is a TS0870 Reader. Note that this only applies when the Reader is connected via RS485 and only supports lock relay control via the Reader's yellow wire (open collector only) &/or REX button input via the Reader's violet wire. On-board or UniBus hardware is preferred.</p> <p><i>See the Integrity Application Note: "Tecom TS0870 Series Smart Card Reader Integration" for details.</i></p> <p>Program the lock number of the associated Module or Device selected above.</p> <ul style="list-style-type: none"> -For an on-board lock, enter a value of either 1 or 2. -Aperio Lock: Not required. -Tecom Reader: Enter the Reader LAN Address. <p>Program the DIP Switch setting for the Unibus 2-Door Expander associated with this Door. Only the settings 2, 3 or 4 are relevant to Unibus 2-Door Expanders.</p> <p>No Lock. Set to 'Y' if there is no lock hardware for this Door Reed Switch. Allow Door Reed Switch logic for this Door. The state of the Reed Switch Input will be utilized in functions such as Forced Door, DOTL, Interlocking, etc.</p> <p>Tongue Sense. Allow Tongue Sense logic for this Door. The state of the Tongue Sense Input will be utilized in functions such as Forced Door, DOTL, Interlocking, etc.</p>
	<p>General Door options.</p> <p>No Valid / Invalid Outputs (formerly 'No LEDs')</p> <p>Override EOL</p>	<p>Disable Valid/Invalid indication via the 'VAL'/'INV' Outputs. The Valid/Invalid open collector outputs will only be controlled by the associated Auxiliary.</p> <p>Overrides the EOL Resistor requirement for the REX (Request to Exit) and REN (Request to Enter) Inputs on all Doors on this Module. When enabled, the Normally Open contacts of the switch can be wired directly into the REX and/or REN Inputs with no EOL resistors.</p> <p>In V16.0.0 or later this option is enabled by default for Integrity IAC, ILAM and SLAM Modules.</p>
Lift Access Control.	Lift Car 1 to Lift Car 8 assignment. (Associated Lift Cars)	Select the Lifts to be assigned to this Reader Module. Access control for the nominated Lifts will be provided by this Module.

Offline Operation Offline Options (C3K IFDAM).	Card Cache Time None 1 Hour 4 Hours 8 Hours 1 Day 2 Days 4 Days 1 Week 2 Weeks 1 Month 2 Months 4 Months	Select the period for which a Cached Card will be retained in a C3/4K IFDAM or I2DAM Cache from the last time it was used.
	Button Cache Time	Select the period for which a Cached Button operation will be retained in a C3/4K IFDAM or I2DAM Cache from the last time it was used. Options are the same as those for Card Cache Time above.
	Verbose Review	The C3/4K IFDAM/I2DAM Review Log will include extra detail that may be useful during commissioning and troubleshooting.
Offline Operation (ILAM) Formerly 'Standalone Operation'.	Door 1 Entry dual user Door 2 Entry dual user Door 3... Door 1 Exit dual user Door 2 Exit dual user Door 3... Door 1 Entry ren button Door 2 Entry ren button Door 3... Door 1 Exit rex button Door 2 Exit rex button Door 3... Historic Review download pace time (ms)	Offline Operation options for the Doors assigned to the Integriti ILAM. These requirements will only be relevant while the Module is Offline. The four standalone operation options are programmed separately for each of the eight Doors. Dual User operation required for entry at first Door. Dual User operation required for entry at second Door. Dual User Entry options continue for Doors 3 to 8. Dual User operation required for exit at first Door. Dual User operation required for exit at second Door. Dual User Exit options continue for Doors 3 to 8. REN button operation allowed at first Door. REN button operation allowed at second Door. REN button options continue for Doors 3 to 8. REX button operation allowed at first Door. REX button operation allowed second Door. REX button options continue for Doors 3 to 8. If the Module has been offline and reconnects, the Review Events logged locally while offline need to be transferred to the Controller. These "historic review" messages are "paced" in order to minimise disruption to normal LAN traffic. This pace time setting sets the time the Module waits between sending each review event to the Controller. If the setting is left at 0, the recommended default pace time is used.

Inputs	<p>End Of Line Config.</p> <p>Concept3K 8-State Tecom Compat</p>	<p>Select the End Of Line (EOL) Resistor scheme to be used for the Zone Inputs on this Intelligent LAN Access Module (ILAM). This option is normally left blank allowing the default 'Concept3K' EOL scheme to be used.</p> <p><i>See "Inputs" in the Controller "Module Details" programming for details of the EOL Scheme options.</i></p> <p>Note that this option is only relevant to the Integrity Intelligent LAN Access Module (ILAM). Legacy Concept 3000/4000 Intelligent Reader Modules that are compatible with Integrity, do not have selectable EOL.</p>
Connectivity.	<p>Serial Reader Settings</p> <p>Serial Channel Baud Rate Data Bits Parity Stop Bits</p>	<p>Integrity ILAM only. Not relevant to Concept Intelligent Door Access Modules (IFDAM/I2DAM).</p> <p>Not currently used. The Serial Reader Port settings are determined automatically and do not need to be programmed when a Serial Reader type is selected in 'Readers' programming for this Module. i.e. SIFER, OSDP, Salto, Aperio, Intego or Tecom.</p>
OSDP Options	<p>OSDP Options</p> <p>Local Feedback Disable Auto Addressing</p> <p>Lockdown Bus</p> <p>Proximity Feedback</p>	<p>The Reader will respond immediately when a card is read. Disables all auto addressing on this bus. This option may be necessary when the bus is being shared with some other OSDP devices.</p> <p>Disables addressing of unknown modules. While locked down, you will be unable to add new Readers to this Module. This option no longer available in V17 or later. When enabled, SIFER Readers will click and flash when a card is detected until the card is close enough to read. This option is useful during commissioning to determine if any Readers have limited read range due to the installation environment or interference, etc. V4.2.0 or later only.</p>
	<p>Crypt Mode</p> <p>Default Custom None</p>	<p>Select the mode of encryption on the OSDP bus for this Module.</p>
LAN Module	<p>LAN Poll Time</p>	<p>Enter a Poll Time in Minutes, Seconds. The Poll time is the maximum amount of time a module can remain out of communication with the Control Module</p>
	<p>Battery Test Time</p>	<p>Enter a Battery Test Time in Hours and Minutes. Determines the battery test time for this Module. For an Integrity ILAM, this is the battery test time for an Integrity Smart power supply connected to the Module.</p> <p>For some guidelines on setting the Battery test time, see 'Battery Test Time' in Controller - Module Details.</p>

	LAN Module Type	This option allows the Installer to view or change the type of LAN Reader Module connected for this Intelligent Reader Module address. All Module types are shown in the drop-down list, but only relevant Module types for 'Intelligent Reader' are listed here. The correct type will normally be automatically chosen when the Module is first connected to the system. If the Module is being programmed prior to being connected to the system, the type will need to be selected.
	C3K Four Door Reader Four Door Reader	Concept 3000/4000 Intelligent 4-Door Controller, or Intelligent 2-4 Door Controller. (i.e. IFDAM & I2DAM). Integriti ILAM.
	Unibus Devices	Define the Unibus devices installed on Integriti Intelligent Reader Modules (ILAMs). The Unibus devices IDs are normally automatically entered when the device is first connected to the system. Not relevant for Concept Intelligent Door Access Modules.
	Enable on LAN Disable on LAN	This operation is available by Right-clicking on the Module in the "Navigation" Pane. Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting service.

Concept Intelligent 4-Door Access Module Notes

V5 or later Concept IFDAM Firmware release introduces support for Integriti Controllers V2.0 or later.

To enable Integriti mode.

Before power-up, set Switch 4 on the Options DIPswitch (S1) to ON.

i.e. S1 Switch 4 OFF = Concept 4000. [Will need to have its DB defaulted 1st time, see installation manual.](#)

S1 Switch 4 ON = Integriti Security Controller.

All other switches on S1 are set to OFF, unless the alternate AC Fail Delay time is required via Switch 2.

This setting causes the IFDAM to act similar to an Integriti 2-Door Reader with an offline cache of 2000 Users.

Note that the mode must be selected to match the type of Control Module that the IFDAM is to be used with.

If the mode does not match the Controller, the IFDAM Fault LEDs will indicate "Module Unknown"

(L2 = OFF, L3 = ON).

Operation in an Integriti System.

GENERAL OPERATION:

- Battery testing is operational.
- The fast unlock time option via Switch 8 on DIPswitch S1 is not supported.

ACCESS CONTROL OPERATIONS WHEN ONLINE:

In online mode, operation should be identical to an Integriti Two-Door Reader or Four-Door Reader Module.

ACCESS CONTROL OPERATIONS WHEN OFFLINE:

In offline mode, the IFDAM can use cached User/Button operations to provide access as follows:

- The cache contains up to 2000 User credentials.
- The cache can be cleared by setting Switch 8 on the Options DIPswitch (S1) to ON (as well as Switch 4) and power cycling the IFDAM. If Switch 8 is left on, then every power cycle will clear the cache.

- When a User is granted access whilst online, the User will be cached for that Door. If the cache is full then the oldest User will be replaced by the new User.
- If a User is denied access, then that User will be removed from the cache for that Door. If they are not in the cache for any other Doors on that Module, then they will be removed from the cache completely on that Module. NOTE. Certain types of “access denied” events will not cause the User to be removed from the cache. e.g. Denied because the Door is interlocked, Denied because Area is On and User does not have permission to turn off that Area, etc.
- When a User is added to the cache, if the User programming has the “permanent cache” option set, then that User cannot be replaced by a newer User. The User will remain in the cache until removed by a power cycle with Switch 8 on, or if denied access at a Door and also not in the cache for any of the other Doors on that Module.
- In addition to Users being removed if a new User is added when the cache is full, Users can also be automatically removed if they have been in the cache for too long. This time is programmable between 1 hour and 4 months. Note that permanent Users are not removed by time.
- The caching of Users can also be disabled completely.

Note that Users are only added when online and access is granted.

Users are only removed from the Module cache:

- When access is denied for all the Doors on that Module on which the User had previously had an access granted event.
- Via time for non-permanent Users.
- Using a Switch 8 power cycle.

If Users are deleted from the Integriti Database whilst online, they are not removed from the cache. If Users are created whilst online they are not automatically added to the cache.

REX and REN button operations are also cached separately, per Door as follows:

- Whenever a REX/REN is allowed whilst online, the REX/REN for that Door is added to the cache.
- Whenever a REX/REN is denied whilst online, the REX/REN for that Door is removed from the cache.
- Cached buttons are also removed by time, programmable from 1 hour to 4 months (separate to User cache time) or can be disabled completely.

Whilst offline, whatever is in the cache determines access permissions.

Whatever REX/REN buttons are in the cache will remain operational until they time out.

Whatever Users are in the cache will remain operational until they timeout, unless they are permanent.

“Dual User” and “Card plus PIN” or “PIN only” is not supported in offline mode.

“PIN only” will not work. If a legal card was presented whilst online, even if a PIN was required but was incorrect, the card will still be added to the cache.

No record of User operations is kept whilst off line.

The Door unlock time is set to 5 seconds when offline.

Checking IFDAM Firmware Version.

The IFDAM can be confirmed via an LCD Terminal as follows:

INTEGRITI:

NOTE: ISC Firmware must be V2.0 or later, and IFDAM Firmware must be V5.0 or later.

- Logon to the LCD Terminal and select Module Info. [MENU, 1, 8]
- Press the Down Arrow key (V) as often as required to locate the IFDAM to view. e.g. C3K-IRdr: 03
- Press the OK key. The display will show the current status of the selected IFDAM. e.g. Present and Secure.
- Press the OK key. The display will now show the current firmware version and build number of the selected IFDAM. e.g. 5.0.0_1

LAN Power Supply Module

LAN Power Supply Module programming is relevant to the Concept 3/4000 LAN Power Supply.

Integriti Smart Power Supplies are integrated with their host Module and do not require separate programming.

Calibration

LAN Power Supply Modules are calibrated at the factory during the manufacturing process. The Module does not normally require any further calibration unless the Module's firmware is upgraded, or a repair has been carried out that required components to be replaced.

Any Firmware upgrade or repair work performed by the manufacturer will also include re-calibration of the Module.

In the rare event of a firmware upgrade being performed in the field, a calibration procedure is available from the Distributor. The following equipment is required to perform the calibration procedure:

- A Digital Multimeter capable of measuring 0 to 20V DC and 0 to 1999mA DC.
- Dummy load. 10 to 15 Ohms. 15W. e.g. 12V, 15Watt Automotive lamp.
- Heavy guage (14/020) test leads for connection of Dummy load and Multimeter.

Entity/Feature	Option	Description
Create/Find LAN Power Supply Module		'Add New' or select a record to edit.
LAN Power Supply Name		Program a name of up to 32 characters in length. Use this feature to describe the location and/or purpose of the Module.
Miscellaneous LAN Power Supply Options.	Number of Slaves	<p>Specifies the number of Slave Modules connected to a Master LAN Power Supply Module. Up to 3 Slave Modules can be connected.</p> <p>The default setting of 0 indicates that no Slave Modules are connected and disables the Slave Fail System Input for this LAN Power Supply Module.</p> <p>Slave Modules are connected to provide additional Battery charging current AND/OR Detector current on a LAN Power Supply Module. This is done by connecting additional "Slave" LAN Power Supply Modules to the 2-wire Slave Bus connection provided, and connecting the "+B" and "DET+" outputs of the Slave Module to the "+B" AND/OR "DET+" output of the Master Module.</p> <p>IMPORTANT NOTE: <i>See the Installation Manual for DIPswitch settings, wiring information and additional details.</i></p>
	Battery Overcurrent (milli-amps) Detector Overcurrent (milli-amps)	<p>These options allow the Installer to independently specify the maximum current allowed from the Battery Charger circuit and the Detector Supply circuit before Over-current System Input Alarms are activated.</p> <p>NOT YET IMPLEMENTED</p> <p>The value is programmed in milliAmps, and can be set from 0.1A (100mA) to 9.9 Amps in 100mA increments. A value of 00 means that the Over-current condition is not monitored. <i>See Important Notes below.</i></p>

	<p>Aux 2 Undercurrent</p>	<p>Specifies the minimum current required to prevent a Satellite Siren Tamper Alarm condition. The value should be set from 20 to 50mA in 1mA increments. The default value of 00 means that Aux2 Tamper current is not monitored. NOTE: Any value less than “20” disables Aux2 Tamper current monitoring.</p> <p>NOT YET IMPLEMENTED</p>
	<p>IMPORTANT NOTES: 1. 2. 3.</p> <p>CALCULATING THE MAXIMUM CURRENT AVAILABLE.</p> <p><u>Example 1:</u></p> <p><u>Example 2:</u></p>	<ul style="list-style-type: none"> - If using the Standard version of the Module, or an Enhanced version with <u>no</u> Slave Modules connected, the value should be set to no more than 4A. - If the Enhanced version is used, <u>and</u> Slave Modules are connected, a value of up to 9.9A may be set depending on the number of Slave Modules connected and the wiring configuration. - If the Master/Slave configuration chosen is designed to deliver more than 9.9A on a particular circuit, then Over-current monitoring for that circuit must be disabled. (Set value to 00) <p><i>See examples below.</i></p> <p>The Maximum Battery Current or Detector Current available is calculated as follows: $I_{max} = 2 + 2n$ Where “n” is the number of Slave Supply outputs (“+B” and/or “DET+” outputs) connected to the specified Master output.</p> <p>If one Slave is connected, set to “Charger Only Mode” and +B / -B of the Slave is connected to +B / -B on the Master, then the maximum <u>Battery</u> current available would be $2 + (2 \times 2) = 6A$. “Charger Only Mode” combines the current available from the 2 outputs into the specified output. (In this case, the maximum guaranteed Detector current available would remain at 2A)</p> <p>If three Slaves are connected, set to “Split Mode” and: - +B / -B from all Slaves is connected to +B / -B on the Master. - DET+ / 0V from all Slaves is connected to DET+ / 0V on the Master. Then; The maximum <u>Battery</u> current available would be $2 + (2 \times 3) = 8A$; And the maximum <u>Detector</u> current available would also be $2 + (2 \times 3) = 8A$.</p>

LAN Power Supply Options	Invert Auxiliary 1 Invert Auxiliary 2.	<p>Invert the operation of Auxiliary 1. Invert the operation of Auxiliary 2. Normally set to “Y” when a Satellite Siren is connected to this output. <i>See Note below.</i></p> <p>IMPORTANT NOTE: Auxiliary 2 <u>is not</u> an Open Collector output. It provides a switched +12V output via an on-board relay and can therefore be used to control a Battery-backed Satellite Siren or other similar controlled device.</p> <ul style="list-style-type: none"> - When used for controlling a Battery-backed Satellite Siren, the 12V output normally needs to be <u>present</u> when the Auxiliary is <u>Off</u>, and <u>removed</u> when the Auxiliary is <u>On</u>. Therefore, the “2” option must be set to “Y”. - When controlling a device such as a Strobe or Piezo Siren (where the 12V output needs to be present when the Auxiliary is ON) the “2” option must be set to “n”.
LAN Module	Poll Time	Enter a Poll Time in Minutes and Seconds. The Poll time is the maximum amount of time a module can remain out of communication with the Control Module.
	Battery Test Time	<p>Enter a Battery Test Time in Hours and Minutes. Determines the battery test time for this Module.</p> <p>For some guidelines on setting the Battery test time, see 'Battery Test Time' in Controller - Module Details.</p>
	LAN Module Type	<p>This option allows the Installer to view or change the type of LAN Power Supply Module connected for this LAN PS Module address. All Module types are shown in the drop-down list, but only relevant Module types for 'LAN Power Supply' are listed here.</p> <p>The correct type will normally be automatically chosen when the Module is first connected to the system. If the Module is being programmed prior to being connected to the system, the type will need to be selected.</p>
	C3K PowerSupply	Concept 3000/4000 LAN Power Supply Module.
	Unibus Devices	<p>Define the Unibus devices installed on relevant types of Integriti Expander Modules. Not relevant for Concept LAN Power Supply Modules.</p>
	Enable on LAN Disable on LAN	<p>This operation is available by Right-clicking on the Module in the “Navigation” Pane.</p> <p>Provides a facility to temporarily disable a faulty Module on the LAN and Isolate its Inputs while awaiting service.</p>

Communications Programming

Entity/Feature	Option	Description
Comms Tasks		Program/Edit the Communications Tasks. e.g. Integrity software interface, Alarm reporting, etc.
Telephone Numbers		Program/Edit any Telephone numbers that may be required for Dialler or GSM Comms Tasks.
Telephone Number Lists		Program/Edit any Telephone Number Lists that may be required for Dialler or GSM Comms Tasks.
DTMF Remote Control		Not yet implemented.
Network Interface Controllers (NICS)		Program/Edit Network Interfaces.
DNS Names (DNS Servers)		Program/Edit DNS Names.

Comms Tasks

Important Upgrade Notes.

In V3.0.0 and later Firmware, the “Comms Task Group” programming field in the GSM, SkyTunnel & Securitel Comms Task formats has been moved to the Review Filtering that is available within these Comms Task formats.

To upgrade the Integrity Controller firmware without any loss of functionality, one of the following methods can be taken:

- When upgrading the Integrity Controller firmware via the Integrity System Designer, if the Integrity System Designer is updated first to V3.0.0 or later then it will automatically migrate any existing Comms Task Group programming into the review filtering programming.
- When upgrading the Integrity Controller firmware manually (e.g. using an LCD Terminal and a USB memory stick), the existing programming will need to be re-entered using the LCD Terminal after the firmware update has completed. Before starting the firmware update process take note of the existing Comms Task Group programming. Then after the firmware update process has completed re-enter the Group programming into the review filter programming for the comms task. NOTE: If upgrading to this firmware from V2.5.2 firmware or later, then the Group programming can be entered in the review filter for the comms task before starting the firmware update process.

Comms Task Status Monitoring.

Where relevant to their operation, many Comms Task formats allow unused Zone Inputs to be assigned to monitor status conditions as shown in the following table.

This allows the Installer to assign the nominated Inputs to a “System” or “Comms Monitor” Area with an appropriate Process Group (e.g. “Comms Problem”) for local &/or remote annunciation/reporting or to trigger other actions or operations.

Notes:

- 1) Some of these options were not available prior to firmware V3.3.0
- 2) Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.

Format	Online Input	Fail Input	Backup Input
Integriti	Yes		
Monitor			
Dialler	Yes	Yes	Yes
GSM*	Yes	Yes	Yes
Automation	Yes		
EMS	Yes		
Securitel	Yes		Yes
Intercom	Yes		
BMS	Yes		
EN32Pin			
SkyTunnel Reporting		Yes	Yes
E Modem			
Peer Reporting		Yes	Yes
Intrepid	Yes		
ARC	Yes	Yes	Yes
NEMTEK	Yes		
Modbus	Yes		

*The GSM Comms Task format also provides “GSM Registration Input” and “GSM Signal Input”.

Entity/Feature	Option	Description
Comms Tasks	Comms Task to Program: CT01	Select Communications Task to program. Use <UP>/<DOWN> Arrows to scroll, or use digit keys to enter the number.
Comms Task Setup	Type (format). None Integriti Monitor Dialler GSM Automation EMS	Select the Communications format for this Comms Task. No Comms Task format selected. Integriti Software communications. Monitor Comms Task. Only use if advised by Tech Support. Digital Dialler Alarm Reporting. e.g. IRfast, Contact ID, SIA, etc. Multipath STU or GSM primary or backup reporting. Control, status monitoring and event logging communication protocol for 3 rd Party Systems using the Integriti Automation Protocol. e.g. Home/Building Automation, HVAC, etc. High-level interface for Elevator (Lift) Management Systems.

	<p>Securitel</p> <p>Intercom</p> <p>BMS</p> <p>EN 32 Pin</p> <p>SkyTunnel</p> <p>E Modem</p> <p>Peer Reporting</p> <p>Intrepid</p> <p>ARC (Alarm Reporting & Control)</p> <p>NEMTEK</p> <p>Modbus</p>	<p>Securitel Serial STU format. While the Securitel network is no longer available, the Securitel Serial format is still utilized as the interface to some 3rd Party communicators. (Not supported in V16.0.0 or later)</p> <p>Serial interface to 3rd Party Intercom products to facilitate integrated access control functionality.</p> <p>Allows an Integriti Controller to communicate directly with a 3rd party BMS system. e.g. Clipsal C-Bus.</p> <p>Provides an interface to activate Auxiliaries or Zone Inputs for different types of alarms with Alarm confirmation (verification) logic for "Intruder" alarms. This allows reporting of alarm pin data via:</p> <ul style="list-style-type: none"> - 3rd party communicators that support pin inputs for reporting. e.g. Redcare STU, 8-pin STU, GSM STU, etc. - Integriti Zone Inputs for reporting via any other Comms Task such as Contact ID or IRfast. <p>A service provided by Inner Range that allows:</p> <ul style="list-style-type: none"> - Temporary connection of an Integriti Controller to Integriti software or the Integriti Mobile App provided there is internet connectivity at both ends. - Alarm Reporting. <p>Answers calls from Integriti Software via a separate line connected to an external modem. Not yet supported.</p> <p>Allows an Integriti Controller to perform alarm reporting on behalf of other Integriti Controllers connected via the Peer Reporting Comms Task. e.g. Where multiple IAC and/or ISC Controllers are installed on the same site. Controller Firmware V3.2.1 or later required.</p> <p>Once the required format is selected, ensure that the Comms Task is currently "Idle".</p> <p>Provides an interface to Intrepid fence inputs. Controller Firmware V4.1.0 or later only. V4.3 or later recommended.</p> <p>Controller Firmware V16.0.0 or later only.</p> <p>Provides an interface to NEMTEK fence controllers. Controller Firmware V4.3.0 or later only.</p> <p>Allows an Integriti Controller to communicate directly with a 3rd party system using the Modbus protocol. Controller Firmware V4.3.0 or later only. V16.0.5 or later recommended.</p>
--	---	---

	<p>Mode</p> <p>Normal Backup</p>	<p>Select whether this Comms Task is a normal Task or a Backup Task.</p> <p>This Comms Task is a Primary reporting Comms Task. This Comms Task is a Backup Comms Task to another Comms Task. e.g. It will only be used if the Primary Reporting Comms Task fails to communicate with the monitoring station.</p>
	Backup Comms Task	<p>Specifies the Comms Task number that will be used as the Backup Comms Task if required.</p> <p>The Backup Task will be triggered after the specified number of Attempts on the Primary Task has failed.</p> <p>When programming the nominated Backup Comms Task, it must be set to “Backup” mode.</p>

<u>INTEGRITI FORMAT</u>		<p>The Integrati Comms Task format allows communications with the Integrati Management Software via one or more prioritised communications paths including Ethernet, USB, RS-232 and Modem.</p> <p>Note that if multiple Integrati Comms Tasks are programmed, they cannot normally run simultaneously.</p> <p>Firmware V3.3.1 or later does allow Integrati Pro software and Integrati CS software to connect to an Integrati Controller simultaneously.</p>
Miscellaneous Options.	<p>RS232 Serial Interface Serial Channel (V4.2.0 or later)</p> <p>None Modem Onboard RS485 Reader Port Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) USB Master USB Slave</p>	<p>Select the Port that the Controller will use to connect to the software when configured to use a ‘Serial’ connection. e.g. A temporary connection via the on-board ‘Port 0’ header or a permanent connection via a UniBus UART RS232 Port.</p> <p>No Modem connection. On-board Dialler modem or an External Modem Not relevant to this operation. On-board “Port 0” connection. Unibus UART 1, RS232 Port 1 Unibus UART 1, RS232 Port 2 Unibus UART 2, RS232 Port 1 Unibus UART 2, RS232 Port 2 Unibus UART 3, RS232 Port 1 Unibus UART 3, RS232 Port 2 Unibus UART 4, RS232 Port 1 Unibus UART 4, RS232 Port 2 On-board USB Master Port. On-board USB Slave Port.</p>
Ethernet Connection	Primary Server IP Address	View or Enter the Primary IP Address of the Integrati Server PC.
	TCP Port	View or Enter the Server TCP Port Number. The default Port number (004711) does not normally need to be changed.
	DNS Name	<p>Select required DNS Server Name.</p> <p>DNS Servers are programmed separately.</p>

Redundant Ethernet Connection	Alternate Server IP Address 1 (V17.0.1 or later only)	View or Enter the alternate IP Address of the Integriti Server PC.
	Alternate TCP Port 1	View or Enter the alternate Server TCP Port Number. The default Port number (004711) does not normally need to be changed.
	Alternate Server IP Address 2 Alternate TCP Port 2 Alternate Server IP Address 3 Alternate TCP Port 3	Two more alternate Server IP Addresses and TCP Port numbers are available.
Connectivity Paths	Path 1 Path 2 Path 3 Path 4	Select a primary communications path (Path 1) and any secondary communications paths to be used for communications with Integriti Management Software. The path number defines the priority. The options below are programmed separately for each of the four Communications Paths that can be used in the system.
	Type None TCP (Primary) Redundant Alternate TCP 1 Redundant Alternate TCP 2 Redundant Alternate TCP 3 USB Serial IModem EModem SkyTunnel Phantom	Select the communications path to be used for communications with Integriti Management Software. No Path selected. Ethernet. Alternate Ethernet 1 Alternate Ethernet 2 Alternate Ethernet 3 USB Host Port. RS232 Serial Port. V4.2.0 or later only. Internal Modem. On-board PSTN modem. External Modem. PSTN or GPRS Modem on a UniBus UART Port. Inner Range SkyTunnel service Factory debugging path only.
	Call	The Controller will call the Integriti Management Software Server.
	Answer	The Controller will answer a call from the Integriti Management Software Server.
Advanced Options	Encryption Type None AES128 AES128_Private	Select the type of encryption (if any) to be used. No encryption AES 128 AES 128 Private
	Product Edition None Installer Professional	Select whether the Insight Management Software package is the Professional edition or an Installer edition. Integriti CS Integriti Pro / Integriti Express
	Encryption Key	Optional Site-based encryption key that is used with AES128 Private. Enter the 32 characters encryption key in HEXADECIMAL format.
	Encryption Pairing Code	A unique key generated for the connection between the Server and the Panel.
Modem connection: General	Telephone Number.	Enter a Telephone Number for the Controller's modem to call the Integriti Server back on, when the Integriti Server requests a Call-back type connection.

Modem connection: Internal modem Options	First Telephone Number. Telephone Number 1 Qualifier (When) Invert Qualifier Deny Invert	Select a Telephone Number or Telephone Number List to use as the primary Telephone Number in this Comms Path. If required, select a Qualifier to define when this Telephone Number will be valid. Select Invert Qualifier to enable the Telephone Number when the Qualifier is invalid. If enabled, this option will cause the 'What' entity (i.e. The Telephone number) to be Denied (rather than allowed) when the Qualifier is valid. If enabled, this option will cause the Telephone number to be Allowed when the Qualifier is Invalid.
	Second Telephone Number. Telephone Number 2 Qualifier (When) Invert Qualifier Deny Invert	Select a Telephone Number or Telephone Number List to use as the secondary Telephone Number in this Comms Path. Other options are the same as those for Telephone Number 1 above.
	Maximum Online Time	Determines the maximum time that the Integriti Management Software is allowed to remain connected via this Modem Path. NOT YET IMPLEMENTED.
	Maximum Dial Attempts	Determines the maximum dial attempts this Comms Task will use to contact the Integriti software. When the maximum attempts are reached, the Backup Task, if defined, will be triggered. NOT YET IMPLEMENTED.
	Decadic Dial. Dumb Dial. Long Pace Dial.	Selects Pulse ("decadic") dial when dialling, rather than tone (DTMF) dialing. Selects Dumb dialling. Normally the Comms Task will monitor the line for line faults, dial-tone, busy etc. and make dialling decisions accordingly. When Dumb dialling is selected, the Comms Task does not make "smart" decisions based on sensed tones. All tones sensed and dialer progress are still recorded to review. Forces the Comms Task to wait 60 seconds between any redial attempts.

<p>Modem connection: External modem Options.</p> <p>NOT YET IMPLEMENTED</p>	<p>First Telephone Number.</p> <p>Telephone Number 1</p> <p>Qualifier (When)</p> <p>Invert Qualifier</p> <p>Deny</p> <p>Invert</p>	<p>Select a Telephone Number or Telephone Number List to use as the primary Telephone Number in this Comms Path.</p> <p>If required, select a Qualifier to define when this Telephone Number will be valid.</p> <p>Select Invert Qualifier to enable the Telephone Number when the Qualifier is invalid.</p> <p>If enabled, this option will cause the ‘What’ entity (i.e. The Telephone number) to be Denied (rather than allowed) when the Qualifier is valid.</p> <p>If enabled, this option will cause the Telephone number to be Allowed when the Qualifier is Invalid.</p>
	<p>Second Telephone Number.</p> <p>Telephone Number 2</p> <p>Qualifier (When)</p> <p>Invert Qualifier</p> <p>Deny</p> <p>Invert</p>	<p>Select a Telephone Number or Telephone Number List to use as the secondary Telephone Number in this Comms Path.</p> <p>Other options are the same as those for Telephone Number 1 above.</p>
	<p>Maximum Online Time</p>	<p>Determines the maximum time that the Integriti Management Software is allowed to remain connected via this Modem Path.</p>
	<p>Maximum Dial Attempts</p>	<p>Determines the maximum dial attempts this Comms Task will use to contact the Integriti software.</p> <p>When the maximum attempts is reached, the Backup Task, if defined, will be triggered.</p>
	<p>RS232 Serial Interface Serial Channel</p> <p>None</p> <p>Modem</p> <p>Onboard RS485 Reader Port</p> <p>Uart 0</p> <p>Unibus Uart1(1)</p> <p>Unibus Uart1(2)</p> <p>Unibus Uart2(1)</p> <p>Unibus Uart2(2)</p> <p>Unibus Uart3(1)</p> <p>Unibus Uart3(2)</p> <p>Unibus Uart4(1)</p> <p>Unibus Uart4(2)</p> <p>USB Master</p> <p>USB Slave</p>	<p>Select the Port that the Modem is connected to.</p> <p>No Modem connection. Not relevant to this operation.</p> <p>Not relevant to this operation.</p> <p>On-board “Port 0” connection.</p> <p>Unibus UART 1, RS232 Port 1</p> <p>Unibus UART 1, RS232 Port 2</p> <p>Unibus UART 2, RS232 Port 1</p> <p>Unibus UART 2, RS232 Port 2</p> <p>Unibus UART 3, RS232 Port 1</p> <p>Unibus UART 3, RS232 Port 2</p> <p>Unibus UART 4, RS232 Port 1</p> <p>Unibus UART 4, RS232 Port 2</p>
	<p>Baud Rate</p>	<p>Select from: 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200</p>
	<p>Data Bits</p>	<p>Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits</p>

	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits
	Modem Type PSTN GPRS	
	Modem Initialization String.	Enter a custom modem initialization string if required.
Options.	Permanent Temporary Comms Task Online Input	<p>Sets General Comms Task connection options.</p> <p>If selected, the Controller will try to reconnect with the Integriti Server if it becomes disconnected. i.e. The Controller will try to maintain a permanent connection. If this option is not selected, the Controller will only attempt one connection when the Comms Task is started.</p> <p>If selected, the Comms Task will be deleted upon completion of a communication session. e.g. When the Integriti Comms Task using a modem connection disconnects from the Integriti Server.</p> <p>An unused Zone Input may be assigned to monitor the “Online” status. The Input will be sealed while the Integriti Comms Task is online and in alarm when offline. Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p>

<u>DIGITAL DIALLER FORMATS</u>		The Dialler format allows reporting via a range of Digital Dialler protocols.
	<u>Dialler Common Settings</u>	The following settings are common to all Dialler formats.
Miscellaneous	<p>Status monitoring options.</p> <p>Online Input</p> <p>Fail Input</p> <p>Backup Input</p>	<p>Unused Zone Inputs can be assigned to monitor the status of the Dialler Comms Task. Note that any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p> <p>An unused Zone Input may be assigned to monitor the Dialler On-hook/Off-hook” status and operates as follows: Seal: Dialler is Off-hook (not making a call) Alarm: Dialler is On-hook (making a call)</p> <p>An unused Zone Input may be assigned to monitor the Dialler “Fail” status. An alarm will be triggered on this Input on dialler failure.</p> <p>An unused Zone Input may be assigned to monitor the “Backup” status. An alarm will be triggered on this Input when the Backup Comms Task (if assigned) is triggered.</p>
Reporting	<p>Dialler Format</p> <p>None</p> <p>IRFast</p> <p>Contact ID</p> <p>SIA</p> <p>Four Plus Two</p>	<p>Select Reporting Format for this Comms Task.</p> <p>No format. IR fast. Contact ID. SIA 4+2.</p>
	Client Code	<p>Determines the account code sent when reporting events to the Central Station. This is the default Client Code for this Comms Task which will be used if there is no Client Code programmed in the Area in which the event to report has occurred.</p> <p>If a Client Code has been programmed for an Area, then that Client Code will take precedence when events are reported for that Area.</p> <p>Options are provided to enter the Client Code in Hexadecimal and Decimal formats. Enter a Decimal value between 0 – 65535, or a Hexadecimal value between 0 – FFFF. (Hexadecimal available in Controller Firmware V3.2.1 or later only)</p> <p>Account Codes are typically provided by the Central Monitoring Station. The number of digits required will depend on the reporting format.</p>

	Telephone Number 1 (Primary Telephone Number)	Use this setting to select the primary Telephone Number for this Comms Task if the Telephone number does not need to be qualified in any way. Note: If the Telephone Number needs to be Qualified, use the Telephone Number settings in the Advanced Options instead. A Telephone Number or Telephone Number List may be selected.
	Telephone Number 2 (Secondary Telephone Number)	Use this setting to select the secondary Telephone Number for this Comms Task if the Telephone number does not need to be qualified in any way. Note: If the Telephone Number needs to be Qualified, use the Telephone Number settings in the Advanced Options instead. A Telephone Number or Telephone Number List may be selected.
Review Options	Review Filter	The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.
	Entity 1 Entity 2 Entity 3 Entity 4 Entity 5	Allows up to 5 specific Entities to be nominated for reporting via this Comms Task so that only review entries that reference these entities will get reported.
	Comms Task Groups	Option to allow Input event reporting to be filtered based on the type of Input. Up to 16 separate Comms Task reporting Groups can be established. If one or more Groups are enabled in these options, an Input event will only be reported by this Comms Task if it has: - At least one matching Comms Task Group enabled in its associated Process Group. - No Comms Task Groups enabled in its associated Process Group. If no groups are enabled in these options, any Input events can be reported, regardless of how the Comms Task Group options have been set in the Input's Process Group.
	Review Classification	Select the Review classifications to filter the events reported by this Comms Task. <i>See Menu Group programming for a list of the Review Classifications available.</i>

	<p>Review Level</p> <p>Everyone User - Essential User - Standard User - Detailed Installer - Standard Installer - Detailed Inner Range - Debug</p>	<p>Select the Review Level to filter the events reported by this Comms Task.</p> <p>This option is normally only used for Comms Task formats such as Automation, Printer, BMS, etc. formats.</p> <p>This option determines the amount of detail that will be accepted for this Comms Task.</p> <p>Lowest level of detail.</p> <p>Highest level of detail.</p>
	EN Review	Only EN Review will be used by this Comms Task.
	Historic Review	<p>Allows buffered events that are made redundant by a subsequent event and normally discarded, to be reported. e.g. For an Input that has been Isolated.</p> <p>Normally if you have a lot of queued events and then you get an event such as a closing for the Area those events are in, or an isolate on the Input causing the events, the relevant buffered events are discarded up until the Isolate or Close. If enabled, this option forces those buffered events to be reported. Use this option with caution. Under certain circumstances it can contribute to a run-away dialer condition.</p>
Options	Delay Report Time	<p>Enter a Delayed Report Time in Hours, Minutes and Seconds, if required.</p> <p>Determines the duration of delay when reporting alarms to the Central Station if the Process Group "Delay Report" option is enabled.</p>
	<p>Look Ahead.</p> <p>General Open/Close.</p> <p>Xmit Historic</p>	<p>New Alarm events will be reported ahead of multi-break reports on Inputs that have already been reported.</p> <p>Area Open/Close reporting will only be done on the 1st Area to Open and the last Area to Close, with the exception of Areas with the "Not General Area" option enabled.</p> <p>Sends buffered events for an Input that has since been isolated or is in an Area which has been disarmed.</p> <p>Normally (this option disabled), when there are events buffered for an input, if the input is then isolated or the Area is disarmed, only the final event is sent.</p> <p>When this option is enabled, this functionality is not executed and all buffered events are sent.</p>
	Maximum Online Time (ms)	Program the maximum online time in milliSeconds.
	Maximum Events to send per call.	Program the maximum number of events allowed to be reported per call.
	Maximum Dial Attempts	Determines the maximum dial attempts this Comms Task will use to contact the Central Station.
Advanced Settings		

	<p>Primary Telephone Number.</p> <p>Telephone Number 1</p> <p>Qualifier (When)</p> <p>Invert Qualifier</p> <p>Deny</p> <p>Invert</p>	<p>Allows the primary Telephone Number or Telephone Number List to be selected and paired with a Qualifier to define when it will be used. If a Qualifier is not required, use the Telephone Number settings in the Reporting Options instead.</p> <p>Select a Telephone Number or Telephone Number List to use as the primary Telephone Number in this Comms Task.</p> <p>If required, select a Qualifier to define when this Telephone Number will be valid.</p> <p>Select Invert Qualifier to enable the Telephone Number when the Qualifier is invalid.</p> <p>If enabled, this option will cause the ‘What’ entity (i.e. The Telephone number) to be Denied (rather than allowed) when the Qualifier is valid.</p> <p>If enabled, this option will cause the Telephone number to be Allowed when the Qualifier is Invalid.</p>
	<p>Secondary Telephone Number.</p> <p>Telephone Number 2</p> <p>Qualifier (When)</p> <p>Invert Qualifier</p> <p>Deny</p> <p>Invert</p>	<p>Allows the secondary Telephone Number or Telephone Number List to be selected and paired with a Qualifier to define when it will be used. If a Qualifier is not required, use the Telephone Number settings in the Reporting Options instead.</p> <p>Select a Telephone Number or Telephone Number List to use as the secondary Telephone Number in this Comms Path.</p> <p>Other options are the same as those for Telephone Number 1 above.</p>
	<p>Seize Action.</p>	<p>Select the Line Seize Action.</p> <p>The selected Entity will be controlled when the line is seized / unseized.</p> <p><i>See Action Programming in “Generic Programming Operations” for details.</i></p>
	<p>Pass Action</p>	<p>Select the Comms Pass Action.</p> <p>The selected Entity will be controlled when the dialler successfully sends a report to the Central Station.</p> <p><i>See Action Programming in “Generic Programming Operations” for details.</i></p>
	<p>Dialling options.</p> <p>Dial Decadic.</p> <p>Dumb Dial.</p> <p>Long Pace Dial.</p>	<p>Selects Pulse (“decadic”) dial when dialling, rather than tone (DTMF) dialing.</p> <p>Selects Dumb dialling. Normally the Comms Task will monitor the line for line faults, dial-tone, busy etc. and make dialling decisions accordingly. When Dumb dialling is selected, the Comms Task does not make “smart” decisions based on sensed tones. All tones sensed and dialer progress are still recorded to review.</p> <p>Forces the Comms Task to wait 60 seconds between any redial attempts.</p>

	Handshake Wait Time (mS)	<p>A longer handshake wait time may be programmed if required. The handshake wait time is the time the task will wait for an initial handshake after dialling the Central Station. If left set to 0, the following default time will be used;</p> <p>Contact ID: 20 Seconds. IR fast: 20 Seconds. SIA: 15 Seconds.</p> <p>A value of up to 65 Seconds can be programmed in 1 milliSecond increments. e.g. For a wait time of 35 seconds, enter 35000.</p> <p>The default time listed above is also the minimum time allowed. A programmed time that is less than the default time will be ignored and the default time will be used.</p>
	Acknowledgement Wait Time (mS) (V4.2.0 or later only)	<p>The amount of time that the Panel will wait for the Receiver to Acknowledge an alarm. If left set to 0, the system's default value will be used.</p> <p>A value of up to 65 Seconds can be programmed in 1 milliSecond increments. e.g. For an Ack. time of 10.5 seconds, enter 10500.</p>
	Maximum Time until Backup Task (mS)	<p>The maximum amount of time before the Backup Comms Task will be triggered when the Primary Comms Task fails. If left set to 0, the default time of 60 Seconds will be used.</p> <p>A value of up to 65 Seconds can be programmed in 1 milliSecond increments. e.g. For a Backup Comms Task trigger time of 45 seconds, enter 45000.</p>
	Callback Telephone Number	Select a Telephone Number to use for the Callback function in this Comms Task.
	Client Telephone Number	Record the Panel's telephone number here for reference.

	<u>Dialler Format Settings</u>	<p>These are the settings unique to each of the Dialler formats.</p> <p>The format is chosen in the 'Reporting' options above.</p>
--	---------------------------------------	--

<p>IRFast Settings. (Only displayed if IRFast format selected)</p>	<p>Send Text. Send Contact ID.</p> <p>Send Time.</p> <p>C3K Compatible.</p> <p>300 Baud.</p> <p>XMIT Info.</p> <p>Save time.</p>	<p>Send Review text for each event reported. Send an equivalent Contact ID string for each event reported, using the mapping option selected. This is useful when the automation system cannot understand native IRfast information.</p> <p>Send a text string of the Time/Date the event was recorded into review.</p> <p>The C3K Compatible Map is implemented for reporting Input events to Receivers and/or Automation Software that have not yet been updated for Integrati IRFast mapping.</p> <p>Forces all communications to 300 Baud instead of the default 1200 Baud. This need only be set if there are communication difficulties at 1200 Baud</p> <p>Send miscellaneous panel information before hanging up, including panel serial number, software version and security option settings.</p> <p>Causes the Receiver to Update the panel time and date from its system clock prior to hanging up.</p> <p>NOTE: An IRFast Receiver can set any of the above options to Yes on a per receiver basis. The above options should only be enabled upon instruction from the Central Station.</p>
<p>Contact ID Settings. (Only displayed if Contact ID format selected)</p>	<p>Contact ID Map</p> <p>Standard</p> <p>Access</p> <p>SIMS II</p>	<p>Select Contact ID Mapping for this Comms Task. Determines which zones are uniquely reported. <i>Refer to separate Contact ID Map documentation.</i></p> <p>Standard Mapping oriented towards Intruder Alarm monitoring.</p> <p>Access Mapping oriented towards Access Control with 2-Door Reader Modules.</p> <p>SIMS II Mapping for use with the SIMS II Central Station Automation Software. Allows all Inputs, on up to 35 Modules of every Module Type to be reported uniquely by using the Group Byte to define the Module Number. NOTE: Firmware V4.1.2 or later allows up to 99 Modules of every Module type to be reported with SIMS II mapping. Please check with the Monitoring Station if this capability is available in their Automation Software. (This also applies to V3.3.15 or later in the V3 stream)</p>
<p>SIA Settings. (Only displayed if the SIA format selected)</p>	<p>Map</p> <p>0</p> <p>1</p> <p>2</p>	<p>Hex digits are used for the Address field. Decimal digits will be used for the Address field. Not yet implemented.</p> <p>Note that if the Decimal Map option is selected, the address mapping alters and the maximum number of Modules of any one type is limited to 32. <i>See the 'Integrati SIA DECIMAL Mapping' and 'Integrati SIA HEX Mapping' documents for SIA address mapping.</i></p>

	<p>RTC</p> <p>ASCII</p> <p>Peripheral Identifier Decimal Address Obey Address</p>	<p>If enabled, a time modifier (ti) prefixes every Event Data Code to provide the historical time stamp of the event. Note that this option may considerably slow down the rate of alarm transmission.</p> <p>If enabled an ASCII text block is appended to the data to provide textual information from the system.</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1) This option may considerably slow down the rate of alarm transmission. 2) When this option is selected, the appropriate text for the first event will be sent in an ASCII block. Each subsequent event in the same phone call will only have ASCII text sent if it varies from the previous events. i.e. Only differences are sent to save on transmission time. 3) This option also has the effect of forcing one alarm event per packet. 4) With an opening/closing event, the following ASCII text may be appended if the related Area Communications options are selected. <ul style="list-style-type: none"> “Sys still open” At least one nominated System Area is Open (Off). “24Hr Partition” The 24 Hour (Tamper) part of the Area is Open (Off). <p>Send Peripheral Identifier modifier. Use decimal addresses instead of hexadecimal. Don't output the address of events that can be considered a 'General Fault'. e.g. AC Fail, System Power-up, etc.</p>
<p>Four Plus Two Settings. (Only displayed if the Four Plus Two format selected)</p>	<p>No options at present</p>	

GSM Comms Task Notes

- The format (IRfast or ContactID) used to communicate the normal event data to the FE3000/T4000 STU is determined by the STU. If the STU tells the GSM Comms Task to use IRfast, then IRfast is what the GSM Comms Task sends. Note that the new Integriti IRfast may not be implemented in the Central Monitoring Station whereas the C3K IRfast may be. An option is provided for “C3k compatible IRfast” data to be sent.
- There is currently no option in the Comms Task to disable SMS control commands via an FE3000. Restricting SMS control of an entity is achieved via the User's Menu Group.
- When GSM Comms Task is configured as a Backup Comms Task, under normal “idle” conditions, no events are reported but SMS control messages via an FE3000 are still processed.
- See information following the GSM Comms Task programming for full details of the SMS Command feature.
- The connection between the Integriti Controller and the FE3000/T4000 STU is made via a serial interface, by connecting one of the Integriti Controller's UARTs to the STU.
 - FE3000s are capable of communicating at 600, 1200 or 2400 BAUD. The recommended port configuration for communications between the Integriti Controller and an FE3000 is 1200, N, 8, 1.
 - For the T4000, RS232 Serial communications options must be set to 1200 Baud, 8 Bits, No Parity & 1 Stop Bit.
- If upgrading the Integriti Controller Firmware from a Version prior to V3.0.0, to V3.0.0 or later, see the “Important Upgrade Notes” at the beginning of the “Communications Programming” chapter.

<u>GSM FORMAT</u>		<p>The GSM format allows primary or backup reporting via compatible Fratech Multipath IP STU or FE3000 products.</p> <p>It is used to communicate reportable events to a Central Monitoring Station, to send reportable events via SMS message and/or to receive SMS control messages.</p>
Connectivity	<p>RS232 Serial Interface Serial Channel</p> <p>None Modem Onboard RS485 Reader Port Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) USB Master USB Slave</p>	<p>Select the Port that the Modem is connected to.</p> <p>GSM Format utilizes the following connection options: 1) "Uart 0" with Cable P/N: 996790 Integriti Port 0 to Multipath IP Interface Cable. 2) UniBus UART RS232 Port with Cable P/N: 994092 Serial Interface Cable.</p> <p>No Modem connection. Not relevant to this format. Not relevant to this format. On-board "Port 0" connection. Unibus UART 1, RS232 Port 1 Unibus UART 1, RS232 Port 2 Unibus UART 2, RS232 Port 1 Unibus UART 2, RS232 Port 2 Unibus UART 3, RS232 Port 1 Unibus UART 3, RS232 Port 2 Unibus UART 4, RS232 Port 1 Unibus UART 4, RS232 Port 2 Not relevant to this format. Not relevant to this format.</p>
	<p>Baud Rate</p> <p>1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200</p>	<p>The next four options configure the serial port. The recommended port configuration for communications between the Integriti Controller and an FE3000/T4000 is:</p> <ul style="list-style-type: none"> • 1200 baud • 8 Bits • No Parity • 1 Stop Bit
	Data Bits	Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits
	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits

Reporting	Client Code	<p>Determines the account code sent when reporting events to the Central Station.</p> <p>This is the default Client Code for this Comms Task which will be used if there is no Client Code programmed in the Area in which the event to report has occurred.</p> <p>If a Client Code has been programmed for an Area, then that Client Code will take precedence when events are reported for that Area.</p> <p>Options are provided to enter the Client Code in Hexadecimal and Decimal formats. Enter a Decimal value between 0 – 65535, or a Hexadecimal value between 0 – FFFF. (Hexadecimal available in Controller Firmware V3.2.1 or later only)</p> <p>Account Codes are typically provided by the Central Monitoring Station. The number of digits required will depend on the reporting format.</p>
	SMS Number 1 (Primary SMS Telephone Number)	<p>Use this setting to select the primary Telephone Number for this Comms Task if the Telephone number does not need to be qualified in any way.</p> <p>Note: If the Telephone Number needs to be Qualified, use the Telephone Number settings in the Advanced Options instead.</p> <p>A Telephone Number or Telephone Number List may be selected.</p>
	SMS Number 2 (Secondary SMS Telephone Number)	<p>Use this setting to select the secondary Telephone Number for this Comms Task if the Telephone number does not need to be qualified in any way.</p> <p>Note: If the Telephone Number needs to be Qualified, use the Telephone Number settings in the Advanced Options instead.</p> <p>A Telephone Number or Telephone Number List may be selected.</p>

Options	<p>SMS General Open/Close</p> <p>SMS Xmit Historic</p> <p>Update Time.</p> <p>Save RSSI</p> <p>Alarm Look Ahead.</p> <p>SMS Look Ahead.</p> <p>General Open / Close.</p> <p>Need PIN SMS Error Reply.</p> <p>Xmit Historic</p> <p>Maximum Messages</p>	<p>Enables General Open/Close reporting for SMS Reporting. See “General Open/Close” below for details.</p> <p>Enables Xmit Historic reporting for SMS Reporting. See “Xmit Historic” below for details.</p> <p>The Integrati Controller’s Real-time clock will be updated from the FE3000 status packet every hour on the hour.</p> <p>Save RSSI information to Review allows the Received Signal Strength Information to be logged to Review.</p> <p>New alarms will be reported ahead of multi-break messages for Inputs that have already reported.</p> <p>New SMS alarm messages will be reported ahead of multi-break messages for Inputs that have already reported.</p> <p>Whenever all Areas that are programmed to report Open/Close are turned On, a general Area close is reported. As soon as the first Area is turned Off, a general Area open is reported. In Area Programming, some Areas can be nominated to be ignored in the general Area calculation allowing them to still be reported individually.</p> <p>A PIN Code is required to be sent with SMS commands. If SMS commands are received that result in some sort of error (e.g. Command Syntax, Permissions deny control, etc.) then this option allows an error reply to be sent back to the Sender.</p> <p>Sends buffered events for an Input that has since been isolated or is in an Area which has been disarmed.</p> <p>Normally (this option disabled), when there are events buffered for an input, if the input is then isolated or the Area is disarmed, only the final event is sent.</p> <p>When this option is enabled, this functionality is not executed and all buffered events are sent.</p> <p>Maximum SMS messages allowed to be sent in a 60 second period. Note that messages will bank up if they are occurring faster than this rate.</p> <p>The default setting of 0 means that the maximum messages will be 10 per 60 seconds.</p>
Contact ID.	<p>Contact ID Map</p> <p>Standard Access SIMS II</p>	<p>Select Contact ID Mapping for this Comms Task. Determines which zones are uniquely reported. <i>Refer to separate Contact ID Map documentation.</i></p> <p><i>See ‘Contact ID Settings’ in the ‘Digital Dialler Formats’ Comms Task programming for brief descriptions of the Contact ID Map options.</i></p>

Advanced Settings	<p>First SMS Number.</p> <p>SMS Number 1</p> <p>Qualifier (When)</p> <p>Invert Qualifier</p> <p>Deny</p> <p>Invert</p>	<p>Select a Telephone Number or Telephone Number List to use as the primary Telephone Number in this Comms Task.</p> <p>If required, select a Qualifier to define when this Telephone Number will be valid.</p> <p>Select Invert Qualifier to enable the Telephone Number when the Qualifier is invalid.</p> <p>If enabled, this option will cause the 'What' entity (i.e. The Telephone number) to be Denied (rather than allowed) when the Qualifier is valid.</p> <p>If enabled, this option will cause the Telephone number to be Allowed when the Qualifier is Invalid.</p>
	<p>Second SMS Number.</p> <p>SMS Number 2</p> <p>Qualifier (When)</p> <p>Invert Qualifier</p> <p>Deny</p> <p>Invert</p>	<p>Select a Telephone Number or Telephone Number List to use as the secondary Telephone Number in this Comms Task.</p> <p>Other options are the same as those for Telephone Number 1 above.</p>
	CID Telephone Number	Select a Telephone Number to use for reporting to a Central Station Digital Receiver.
	Service Telephone Number	Select a Telephone Number for the SMS service centre. This number can be obtained from the Network you subscribe to and is mandatory for any SMS operations.
	SMS Control Number	Select a Telephone Number to define a number that is allowed to perform SMS Control operations if the "Need PIN" option is not enabled.

	<p>Status monitoring</p> <p>GSM Reg Input.</p> <p>GSM Signal Input</p> <p>GSM Fail Input</p> <p>GSM Backup Input</p> <p>GSM Online Input</p>	<p>Allows Inputs to be specified for monitoring a number of GSM Comms Task states. Unused Zone Inputs can be assigned to these functions. Any Zones used for this purpose must have the “Ignore Physical” option enabled.</p> <p>This Zone will indicate changes in the state of the GSM modem registration. The Input is alarmed when the modem de-registers and sealed when the modem re-registers.</p> <p>This Zone will be put into Alarm when the FE3000 reports to the Integriti Controller that it has low signal strength. The Zone will restore when the FE3000 reports that the signal strength is satisfactory.</p> <p>This Zone is will be put into Alarm when some error conditions occur between the Integriti Controller and the FE3000.</p> <p>This Zone will indicate when the Backup Comms Task is Triggered.</p> <p>This Zone will be Sealed when communications with the FE3000 are working and in Alarm when they are not.</p>
Review Options	Review Filter	<p>The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.</p> <p><i>See “Digital Dialler Formats” for details of the Comms Task Review Options.</i></p>
	SMS Review Filter	<p>The SMS Review Filter options may be programmed to determine the events that will be reported via SMS based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.</p> <p><i>See “Digital Dialler Formats” for details of the Comms Task Review Options.</i></p>

<p>IRFast Settings. (Only required if IRFast format selected)</p>	<p>Send Text.</p> <p>Send Contact ID.</p> <p>Send Time.</p> <p>C3K Compatible.</p> <p>300 Baud.</p> <p>XMIT Info.</p> <p>Save time.</p>	<p>Send Review text for each event reported. V4.0.1 firmware or later recommended if this option is selected and the 'C3K Compatible' option not enabled. Send an equivalent Contact ID string for each event reported, using the mapping option selected. This is useful when the automation system cannot understand native IRfast information. Send a text string of the Time/Date the event was recorded into review. The C3K Compatible Map is implemented for reporting Input events to Receivers and/or Automation Software that have not yet been updated for Integriti IRFast mapping. Forces all communications to 300 Baud instead of the default 1200 Baud. This need only be set if there are communication difficulties at 1200 Baud Send miscellaneous panel information before hanging up, including panel serial number, software version and security option settings. Causes the Receiver to Update the panel time and date from its system clock prior to hanging up.</p> <p>NOTE: An IRFast Receiver can set any of the above options to Yes on a per receiver basis. The above options should only be enabled upon instruction from the Central Station.</p>
<p>GSM SMS options</p>	<p>Enable SMS Control</p> <p>Allow Help Allow Area Allow Isolate Allow Reset SMS</p> <p>Allow Named Actions Allow Auxiliary Control Allow Status Query Allow On Control</p> <p>Allow Off Control</p> <p>Allow Restricted Status</p>	<p>All SMS Remote Control commands are allowed.</p> <p>If "Enable SMS Control" is <u>not</u> enabled, select the specific types of SMS commands that will be allowed from the list below.</p> <p>Allow the SMS User to request the Help message. Allow Area control. Allow Input Isolate & De-Isolate. Allow the Reset SMS Messages command. This allows buffered SMS messages to be cleared. Allow Named Action control. Allow Auxiliary control Allow the status of an entity to be requested. Allow Entities to be turned On if control of the entity type is enabled. Allow Entities to be turned Off if control of the entity type is enabled. Allow status queries only for the entities that the User has permissions for.</p>

SMS Control

The GSM Comms Task can be used to turn Areas on/off, turn Auxiliaries on/off and to trigger Named Actions via SMS control commands. Inputs can also be Isolated or de-Isolated. The GSM Comms Task can be configured to authenticate an SMS command either via a Telephone Number or via a User PIN.

If only the Telephone Number is used as the authentication method then there is no restrictions applied to the SMS control command. This means that as long as the command syntax is correct the SMS control action is carried out (e.g. any Area can be turned ON/OFF or any Input can be Isolated/de-Isolated etc.).

If a User PIN is provided as part of the SMS control command then the User's permissions governs the level of control that the SMS control command can execute. If the User does not have access to control the entity type in their Remote Access Permissions of their Menu Group, then they cannot control the entity. Some SMS control commands also have additional checks, for example:

- When controlling an Area ON the User must have the Area in their "Area ON List".
- When controlling an Area OFF the User must have the Area in their "Area OFF List".
- When Isolating or De-Isolating an Input the User must have the Input in their "Area OFF List".
- When triggering a Named Action, if the Named Action has an "Action Group" set then the User must have at least one matching "Action Group" set to that of the Named Action.

When a valid SMS control command has been received and processed, an SMS reply will be sent back to the original SMS phone number. In most cases the SMS reply will be the review associated with the action that was performed, however in some circumstances an error reply may be sent or even no reply will be sent.

Examples of these exceptions are:

- SMS Alarms are being sent instead of SMS replies (SMS Alarms are a higher priority than SMS replies)
- The review for the executed action was not detected or the FE3000 was full and unable to accept additional SMS messages.

As with SMS Alarms, if there is an SMS reply message pending to be sent and the FE3000 takes longer than 30 seconds to be free, then the pending SMS reply message will be discarded.

See the following table for the command set.

SMS Control Command Syntax

Command Syntax	Command Description
[<PIN>] ?	Display SMS Help
[<PIN>] A <Area ID> <N/F>	Control an Area using its ID
[<PIN>] A <Area Name> <N/F>	Control an Area using its Name
[<PIN>] A <Area ID> L	List 4 Area Names starting at Area ID
[<PIN>] A <Area Name> L	List 4 Area Names starting at Area Name
[<PIN>] A ?	Display Area Help
[<PIN>] I <Input Address> <I/D>	Isolate an Input using its ID
[<PIN>] I <Input Name> <I/D>	Isolate an Input using its Name
[<PIN>] I <Input ID> <L>	List 4 Input Names starting at Input ID
[<PIN>] I <Input Name> <L>	List 4 Input Names starting at Input Name
[<PIN>] I ?	Display Isolate Help
[<PIN>] P <Named Action Address> <N/F>	Trigger a Named Action using its ID
[<PIN>] P <Named Action Name> <N/F>	Trigger a Named Action using its Name
[<PIN>] P <Named Action ID> <L>	List 4 Named Actions starting at Named Action ID
[<PIN>] P <Named Action Name> <L>	List 4 Named Actions starting at Named Action Name
[<PIN>] P ?	Display Named Action Help
[<PIN>] X <AUX Address> <N/F>	Control an Auxiliary using its ID
[<PIN>] X <AUX Name> <N/F>	Control an Auxiliary using its Name
[<PIN>] X <AUX ID> <L>	List 4 Auxiliary Names starting at Auxiliary ID
[<PIN>] X <AUX Name> <L>	List 4 Auxiliary Names starting at Auxiliary Name
[<PIN>] X ?	Display Auxiliary Help
[<PIN>] R	Reset the SMS buffer to the latest review
[<PIN>] R ?	Display Reset SMS Help

Example SMS Control commands

Example	Example Description
01?	01=User PIN, ?=Display the SMS Help message
01A001N	01=User PIN, A=Area Control, 001=Area #001, N=Turn ON
AHouseF	A=Area Control, House=Area Name, F=Turn OFF
A1L	A=Area Control, 1=Area #1, L=List 4 Area Names starting at Area 1
AHouseL	A=Area Control, 1=Area #1, L=List 4 Area Names starting at House
A?	A=Area Control, ?=Display the Area Help message
01IC01:Z05I	01=User PIN, I=Isolate Control, C01:Z05=Input C01:Z05, I=Isolate
IEntry PIRD	I=Isolate Control, Entry PIR=Input (e.g. C01:Z05), D=Delsolate
IC01:Z05L	I=Isolate Control, C01:Z05=Input C01:Z05, L=List 4 Input Names starting at C01:Z05
IEntry PIRL	I=Isolate Control, Entry PIR=Input (e.g. C01:Z05), L=List 4 Input Names starting at Entry PIR
I?	I=Isolate Control, ?=Display the Isolate Help message
01P001N	01=User PIN, P=Named Action Control, 001=Named Action #001, N=Trigger ON
PUnlockF	P=Named Action Control, Unlock=Named Action Name, F=Trigger OFF
P1L	P=Named Action Control, 1=Named Action #1, L=List 4 Named Action Names starting at 1
PUnlockL	P=Named Action Control, Unlock=Named Action Name, L=List 4 Named Action Names starting at Unlock
P?	P=Named Action Control, ?=Display the Named Action Help message
01XC01:X07N	01=User PIN, X=Auxiliary Control, C01:X07=Auxiliary C01:X07, N=ON
XStrobeF	X=Auxiliary Control, Strobe=Auxiliary (e.g. C01:X07), F=OFF
XC01:X07L	X=Auxiliary Control, C01:X07=Auxiliary C01:X07, L=List 4 Auxiliary Names starting at C01:X07
XStrobeL	X=Auxiliary Control, Strobe=Auxiliary (e.g. C01:X07), L=List 4 Auxiliary Names starting at Strobe
X?	X=Auxiliary Control, ?=Display the Auxiliary Help message
01R	01=User PIN, R=Reset SMS command
R?	R=Reset SMS, ?=Display the Reset SMS Help message

<p><u>AUTOMATION FORMAT</u></p>	<p>NOTE: All letters in valid commands sent to the Automation Comms Task must be uppercase only.</p>	<p>The “Automation” communication format allows the Integriti Controller to connect to a 3rd party Home/Building Automation system via an RS232 Serial or Ethernet connection. The protocol is ASCII based for ease of use and is designed primarily to enable home automation or building management system (BMS) connectivity. Firmware V4.1.0 or later recommended.</p>
<p>Review Options</p>	<p>General Review Options</p> <p>Send Review Acknowledge Review</p> <p>All Review</p> <p>Transfer Checksum</p> <p>Receive Checksum</p> <p>Transmit Auxiliary Transmit Auxiliary Acknowledge No Line Breaks No Headers or Braces in Review Encoded Review</p>	<p>Enables Review streaming output. The Automation Comms Task will expect an acknowledge message to be returned following each Review event sent. This option starts the Comms Task with the review pointer at the oldest event, allowing the user to print all review. Normally review is sent from the time the CT was started. If all review is selected, it is sent from the earliest review record in the buffer, which could date back to when the panel was first manufactured, depending on how many review events have ever been generated and how many review events are licensed.</p> <p>Insert a checksum field in all transmissions. A checksum field comprises a “~” character followed by two hexadecimal digits inserted just prior to the end of frame character “}”.</p> <p>The Automation Comms Task will expect a checksum field in all received packets, and will reject any packet that has a bad checksum.</p> <p>Auxiliary changes will be sent. Send Auxiliary changes with acknowledgement. Do not send line breaks between Review messages. Select this option to only show text in Review messages.</p> <p>Enable to send Review as encoded state changes instead of in the selected ‘Body Format’ (<i>see below</i>) Only use this option if directed to do so by 3rd Party system documentation. V17.0.0 or later only.</p>
	<p>Header Format</p> <p>Tstamp DateTime Sequence LCD Sequence</p> <p>LCD DateTime</p> <p>Sequence DateTime</p>	<p>Select the option for the Review Header format.</p> <p>Timestamp only. Date and Time only. Sequence Number only. (Event ID) Match the sequence number as it would appear on the LCD screen at Menu, 1, 1. Match the Date/Time formatting as it would appear on the LCD screen at Menu, 1, 1. Match the sequence number and Date/Time formatting as it would appear on the LCD screen at Menu, 1, 1.</p>

	DNS Name	Select required DNS Server Name. DNS Servers are programmed separately.
	TCP Mode None Server Client	
	Retries	Program the number of times to retry connecting upon failing to connect. Only applicable to Client "TCP Mode" if selected above.
	Connection Timeout (V3.1.1 or later)	Not used The timeout period can be programmed in 1 Second increments up to a value of 1 Hour, 49 Mins, 13 Secs (6553 Seconds)
	Connection Attempt Timeout	Not used The connection attempt timeout period can be programmed in 1 Second increments up to a value of 1 Hour, 49 Mins, 13 Secs (6553 Seconds)
Timing	Poll Time	Sets the maximum time allowed between received packets before the Automation Comms Task considers the link to have failed and triggers the "Online Input". The poll time can be programmed in 1 Second increments up to a value of 1 Hour, 49 Mins, 13 Secs (6553 Seconds)
	Pacing Time	Adjusts the rate at which Historic Review events are output when the communications link is re-established. The pacing time can be programmed in 1 milliSecond increments up to a value of 5 Mins, 27.675 Secs
	Repeat Time	If the "Acknowledge Review" option has been selected, then for each review event sent, an acknowledge packet must be received before advancing to the next event. If an acknowledge is not received within 5 seconds, the event will be resent after waiting out the Repeat time. The repeat time can be programmed in 1 Second increments up to a value of 1 Hour, 49 Mins, 13 Secs (6553 Seconds)
Options	Online Input	Select an Input to be used to monitor the Online status of the Automation Comms Task communications link. The Input will be sealed while the Automation Comms Task is online and in alarm when offline. An unused Zone Input can be assigned to this function. Any Zone used for this purpose must have the "Ignore Physical Input" option enabled.

EMS Comms Task Notes

The EMS Comms Task supports a number of High-Level Interface protocols for Elevator Management Systems as follows:

Protocol	EMS Protocol to select in Comms Task programming.	Minimum Controller Firmware Version recommended.
Kone Access Control Protocol Rev 1.5	Kone (IP)	V16.0.0
Kone Access Control Protocol Rev 1.8	Kone (IP)	V16.0.0
Kone HLI Access Control Protocol V2.6	Kone (RS232)	V4.3.0
Kone RCG (Remote Call Giving)	Kone (IP)	V16.0.0
Otis RS-232	Otis (RS232)	V16.0.0
Otis V2.0	Otis (IP)	V16.0.0
Otis V3.0	Otis (IP)	V16.0.0
Schindler Port.	Schindler Port	V4.3.0
Thyssen Krupp Destination Selection Control (DSC) Vers 1.0.	ThyssenKrupp DSC (RS232)	V17.0.0

EMS FORMAT		
		<p>The “EMS” communication format allows the Integriti Controller to provide a high-level connection to an Elevator Management System via an RS232 Serial or Ethernet connection.</p> <p>“Lift Groups” must also be programmed to support this feature.</p> <p>The Integriti Controller lift interface allows for one type of lift interface per controller. If a high-level interface is used, only one EMS Comms Task is allowed per Integriti Controller.</p>
Settings	EMS Protocol None Kone (RS232) Kone (IP) Kone RCG (IP) Otis (RS232) Otis (IP) Schindler Port ThyssenKrupp DSC (RS232) NewLift (IP)	Select the EMS communications Protocol for this EMS Comms Task. No protocol selected. Kone EPL HLI Access Control Protocol V2.6. Kone Access Control Protocol Rev 1.5 or 1.8 or RCG Kone RCG. No longer used. Otis RS-232 Otis IP. Schindler Port. Thyssen Krupp Destination Selection Control (DSC) Vers 1.0.
	Online Input	An unused Zone Input may be assigned to monitor the “Online” status. The Input will be sealed while the EMS Comms Task is online and in alarm when offline. Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.

	RS-232 Serial Interface Serial Channel None Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) Modem USB Slave USB Master IAC Onboard RS485	Select the Port that the EMS Comms Task will use. No Modem connection. On-board "Port 0" connection. Unibus UART 1, Port 1 Unibus UART 1, Port 2 Unibus UART 2, Port 1 Unibus UART 2, Port 2 Unibus UART 3, Port 1 Unibus UART 3, Port 2 Unibus UART 4, Port 1 Unibus UART 4, Port 2 Not relevant to this format. USB serial port on Controller. Not relevant to this format. Not relevant to this format.
	Baud Rate	Select from: 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200
	Data Bits	Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits
	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits
ThyssenKrupp Options	Global Lift	Assign the Lift Record that will be used for Thyssen Krupp global permissions.
	ThyssenKrupp Pace Time	Enter the rate limit for messages sent to the Thyssen Krupp system.
	Enable Default Floor	This option enables the 'Default Floor' feature in the Thyssen Krupp system.
High Level Lift Options	VIP Permission Group	Assign the Permission Group that will indicate a VIP User.
	Special Service Permission Group	Assign the Permission Group that will indicate a Special Service User.
	Empty Car Permission Group	Users with this Permission Group may call for empty Lift Cars.
	VIP Call Type	Enter the call type number for VIP calls.
	Special Service Call Type	Enter the call type number for Special Service calls.
	Empty Car Call Type	Enter the call type number for Empty Car calls.
	RCGIF Default Call Type	Enter the call type number for RCGIF.
Otis Options	Otis Version OTIS V2 OTIS V3 Otis Backup Server Present	
Kone IP Options	Kone Version Kone 1.5 Kone 1.8	

	Car Panel Offline Mask	Select a Floor List for the Car Panel Offline Mask. Floors in this list will be set to Free Access when communications is lost with the Kone IP EMS. The mask affects Car Panels only. No longer used from V16.0. Now configured in Lift Car programming.
	Destination Panel Offline Mask	Select a Floor List for the Destination Panel Offline Mask. Floors in this list will be set to Free Access when communications is lost with the Kone IP EMS. The mask affects Destination Panels only. No longer used from V16.0. Now configured in Lift Car programming.
	Offline Lift Group	Select a Lift Group to determine the mapping for the Car Panel Offline Mask and the Destination Panel Offline Mask. No longer used from V16.0.
Schindler Options	User Prefix	Prefix to add when sending User names to the Schindler system. (16 characters)
Primary Ethernet Connection	Primary Server IP Address	View or Enter the IP Address of the Server PC.
	Primary TCP Port	View or Enter the Server TCP Port Number. The default Port number (004711) does not normally need to be changed.
	Primary DNS Name	Select required DNS Server Name. DNS Names are programmed separately.
	Primary TCP Mode None Server Client	Select whether the EMS Comms Task is to run as a Server, a Client or neither. <i>See the Guide: Integriti Communications Tasks –Lift Interfacing (EMS).</i>
	Primary Retries	The number of times to retry connecting upon failing to connect before it disconnects. Only programmed if “Client” TCP mode selected above.
	Primary Connection Timeout	Programmed in Minutes and Seconds. <i>See the Guide: Integriti Communications Tasks –Lift Interfacing (EMS).</i>
	Primary Connection Attempt Timeout	Programmed in Minutes and Seconds. <i>See the Guide: Integriti Communications Tasks –Lift Interfacing (EMS).</i>
Secondary Ethernet Connection	Parameters for the Secondary Ethernet connection.	Options are the same as those for the Primary Ethernet Connection.
Tertiary Ethernet Connection	Parameters for the Tertiary Ethernet connection.	Options are the same as those for the Primary Ethernet Connection.
Quaternary Ethernet Connection	Parameters for the Quaternary Ethernet connection.	Options are the same as those for the Primary Ethernet Connection.

Introduction to Securitel Comms Task.

The Securitel format allows connection to 3rd party communicators that use the Securitel Serial protocol as the interface.

IMPORTANT NOTES:

- 1) **Securitel is not supported in Firmware V16.0.0 or later.**
- 2) **The Securitel network that the protocol was originally developed for is no longer in operation, but the protocol is still used in Australia by some Subscriber Terminal Units (STUs) to report via communications paths such as GSM, GPRS or IP.**

The Securitel network was a “direct-line” alarm transmission network that was supplied and maintained by Telstra Australia. Alarm panels in the field were connected to a Subscriber Terminal Unit (a STU) and the STU would communicate events via the PSTN to Nodes that were hosted by Telstra. These events were then transmitted to a Central Monitoring Station for processing/actioning.

The Alarm panel communicates to the STU via the Securitel communication protocol. The Securitel protocol allows for either Channel/PIN data or Serial data.

The Integriti Securitel format uses Serial data. When an Alarm panel is reporting Serial data to the STU, the event description from the Alarm panel to the STU can describe:

- 255 Inputs being in one of the following states
 - Priority1
 - Priority2
 - Priority3
 - Tamper
 - Trouble
 - Man. Isolate
 - Auto Isolate
- Area 1 to 31 being Open or Close
- General Area Open or Close
- A few other miscellaneous events.

An Integriti Controller can support thousands of Inputs and the STU can only accept an Input number from 1 to 255, so the Securitel Comms Task has the job of collating many Inputs together in an attempt to end up with meaningful event information at the Central Monitoring Station.

See the “Integriti Securitel Comms Task Input Map” document for details.

The Securitel Comms Task also has another collation mechanism that is on a per Area basis. Each time that an Input in an Area reports a new Alarm, Tamper or Isolate, an additional Area Alarm, Area Tamper or Area Isolate can also be generated. When the Area is eventually disarmed, an Area Alarm Restore, Area Tamper Restore or Area Isolate Restore is generated (one Restore event per event type that was reported during this arming cycle).

The Securitel Comms Task has options to report Input events, Area events or both.

When multiple inputs across multiple modules are collated the reporting logic is as follows:

1. If a new input event (e.g. an Alarm) is being reported then the appropriate Securitel Input Number is looked up and the event is sent to the STU.
2. If a new input restore (e.g. going from Alarm to Seal) is being reported, look up all of the other module’s inputs of the same type that the Securitel Input Number is collated with. If all of the inputs found are sealed then the restore event is sent to the STU. If an input(s) is unsealed then when the last input seals then the restore event is sent to the STU.

e.g. There are 4 Expander modules and 1 RF module on the Integriti Controller. Expander 2 has a Cabinet Tamper event, this is reported to the STU immediately. Then Expander 3 has a Cabinet Tamper event, this is reported to the STU immediately. Then Expander 3 has a Cabinet Tamper restore, this is not reported to the STU because Expander 2 still has its Cabinet Tamper unsealed. Expander 2 has a Cabinet Tamper restore and this is reported to the STU indicating that all Expander module Cabinet Tamper inputs are sealed.

<p><u>SECURITEL FORMAT</u></p>	<p>Australia Only.</p>	<p>NOTES:</p> <ol style="list-style-type: none"> 1) If upgrading the Integriti Controller Firmware from a Version prior to V3.0.0, to V3.0.0 or later, see the “Important Upgrade Notes” at the beginning of the “Communications Programming” chapter. 2) Securitel is <u>not supported</u> in Firmware V16.0.0 or later.
<p>Miscellaneous Settings</p>	<p>Auxiliary Action</p> <p>Hard ID</p> <p>Online Input</p> <p>Backup Input</p>	<p>Selects the system Entity to be controlled by the Securitel Command-back Auxiliary.</p> <p>Sets the Securitel Hard ID to be used for this Comms Task. The Hard ID is the Securitel equivalent to the client code used in other formats and is programmable in HEX from 0001 to FFFF. The Hard ID is provided by the Central Monitoring Station. Note that while the Hard ID is a HEX number, the number provided by the Cenral Station will normally only contain Decimal characters. Simply enter the number as it is provided by the Central Station. The “Multiple Area Client Code” option has no effect when selected for securitel. The Hard ID programmed here is always used.</p> <p>Select an Input to be used to monitor the Online status of the Securitel Comms Task communications link. The Input will be sealed while the Securitel Comms Task is online and in alarm when offline. An unused Zone Input can be assigned to this function. Any Zone used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p> <p>An unused Zone Input may be assigned to monitor the “Backup” status. An alarm will be triggered on this Input when the Backup Comms Task (if assigned) is triggered. Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p>
<p>Connectivity</p>	<p>RS232 Serial Interface Serial Channel</p> <p>None</p> <p>Uart 0</p> <p>Unibus Uart1(1)</p> <p>Unibus Uart1(2)</p> <p>Unibus Uart2(1)</p> <p>Unibus Uart2(2)</p> <p>Unibus Uart3(1)</p> <p>Unibus Uart3(2)</p> <p>Unibus Uart4(1)</p> <p>Unibus Uart4(2)</p> <p>Modem</p> <p>USB Slave</p> <p>USB Master</p> <p>IAC Onboard RS485</p>	<p>Select the RS-232 Port that the STU is connected to.</p> <p>No Modem connection.</p> <p>On-board “Port 0” connection.</p> <p>Unibus UART 1, RS232 Port 1</p> <p>Unibus UART 1, RS232 Port 2</p> <p>Unibus UART 2, RS232 Port 1</p> <p>Unibus UART 2, RS232 Port 2</p> <p>Unibus UART 3, RS232 Port 1</p> <p>Unibus UART 3, RS232 Port 2</p> <p>Unibus UART 4, RS232 Port 1</p> <p>Unibus UART 4, RS232 Port 2</p> <p>Not relevant to this format.</p>

	<p>Baud Rate</p> <p>1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200</p>	<p>STUs using the Securitel Communications Protocol are generally capable of communicating to Alarm panels at 300, 1200 or 9600 Baud.</p> <p>The recommended Baud Rate for communications between the Integriti Controller and a STU is 1200 Baud; however, you should check the Installation and/or Configuration information supplied with the STU to ensure a compatible Baud rate is chosen.</p>
	<p>Data Bits</p> <p>5 Bits / 6 Bits / 7 Bits / 8 Bits</p>	<p>The recommended number of Data Bits for communications between the Integriti Controller and a STU is 8.</p> <p>Check the Installation and/or Configuration information supplied with the STU to ensure a compatible option is chosen.</p>
	<p>Parity</p> <p>None Odd Even Force 1 (Mark) Force 0 (Space)</p>	<p>The recommended Parity for communications between the Integriti Controller and a STU is None.</p> <p>Check the Installation and/or Configuration information supplied with the STU to ensure a compatible option is chosen.</p>
	<p>Stop Bits</p> <p>1 Bit / 2 Bits</p>	<p>The recommended number of Stop Bits for communications between the Integriti Controller and a STU is 1.</p> <p>Check the Installation and/or Configuration information supplied with the STU to ensure a compatible option is chosen.</p>
Options	<p>General Open/Close.</p> <p>Don't Report Area Events. Don't Report Input Events</p>	<p>Area Open/Close reporting will only be done on the 1st Area to Open and the last Area to Close, with the exception of Areas with the "Not General Area" option enabled. Area Open/Close events will not be sent by this Comms Task. Input Events will not be sent by this Comms Task.</p>
Review Options	<p>Review Filter</p>	<p>The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.</p> <p><i>See "Digital Dialler Formats" for details of the Comms Task Review Options.</i></p>

Introduction to the Intercom Comms Task.

The Integriti Controller has an Intercom Comms Task to provide a high-level interface to a 3rd party Intercom system. The Integriti system also has an Apartment entity. These features provide an interface that allows an Apartment to grant access to a visitor at a Call Location/Entrance Station.

An Apartment identifies an Intercom System Unit or Tenant Station and can optionally have an Integriti Floor &/or Intercom System Floor defined depending on the type of Intercom system connected. Depending on the type of Intercom system connected, up to 32 Call Locations/Entrance Stations can be defined in the Intercom Comms Task and each can optionally have a Door and/or up to 4 Lift Cars assigned. When the Intercom Comms Task detects that an Apartment has granted access to a Call Location/Entrance Station, the defined Door and Lift(s) are temporarily unlocked/unsecured to allow access.

At present, the Intercom Comms Task supports:

- 1) The Kenwei Intercom system. Controller Firmware V2.0.0 or later.
- 2) The Aiphone GT Series Intercom system. Controller Firmware V17.0.0 or later.

A brief description of each system is provided after the Intercom Format programming details.

<u>INTERCOM FORMAT</u>		The Intercom format allows connection to 3 rd party Intercom products to allow access control operations to be performed from an Intercom Terminal.
Miscellaneous options	Online Input	An unused Zone Input may be assigned to monitor the “Online” status. The Input will be sealed while the Intercom Comms Task is online and in alarm when offline. Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.
Connectivity	RS232 Serial Interface Serial Channel None Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) Modem USB Slave USB Master IAC Onboard RS485	Select the Port that the Modem is connected to. No connection. On-board “Port 0” connection. Unibus UART 1, Port 1 Unibus UART 1, Port 2 Unibus UART 2, Port 1 Unibus UART 2, Port 2 Unibus UART 3, Port 1 Unibus UART 3, Port 2 Unibus UART 4, Port 1 Unibus UART 4, Port 2 Not relevant to this format. Not relevant to this format. Not relevant to this format. Not relevant to this format. Kenwei: The Kenwei Intercom can be connected to an Integriti Controller: <ul style="list-style-type: none"> • Via Port 0 or a UniBus RS-232 Port using an RS485-RS232 Protocol Converter. • Directly to an Integriti Controller RS-485 UniBus UART Port. Aiphone: An Aiphone Intercom Bus Control Unit can be connected to an Integriti Controller: <ul style="list-style-type: none"> • Via an Integriti Aiphone Interface unit (P/N: 994210) to an Integriti Controller RS-485 UniBus UART Port.
	Baud Rate 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200	Select the Baud Rate for the connection to the Intercom system. Kenwei: 9600 Baud. Aiphone: 9600 Baud.

	Data Bits 5 Bits / 6 Bits / 7 Bits / 8 Bits	Select the number of Bits for the connection to the Intercom system. Kenwei: 8 Aiphone: 8
	Parity None Odd Even Force 1 (Mark) Force 0 (Space)	Select the Parity for the connection to the Intercom system. Kenwei: None Aiphone: Odd
	Stop Bits 1 Bit / 2 Bits	Select the number of Stop Bits for the connection to the Intercom system. Kenwei: 1 Aiphone: 1
Options	Intercom Type Kenwei Aiphone	Selects the type of Intercom to be connected. Kenwei Intercom system. Aiphone GT Series Intercom system.
Door / Lift Options	Door / Lift Mappings Call Location number Door to Unlock Lift 1 to Deselect Lift 2 to Deselect Lift 3 to Deselect Lift 4 to Deselect Entrance Station ID	Each Intercom Door/Lift Mapping record allows a Call Location/Entrance Station to be mapped to a Door and/or up to 4 Lifts. Define the Door to be temporarily unlocked. Define the Lift/s to be temporarily De-secured. i.e. The relevant Floor selection button (defined in 'Apartments' programming) in the nominated Lift/s will be enabled for selection. Note: The Unlock and De-secure times may be programmed specifically for this Comms Task if desired. <i>See below.</i> Aiphone: Enter the Entrance Station ID to be used in this mapping record. The Entrance Station ID is obtained from Review when the tenant station is called by the entrance panel. Kenwei: Not used. Up to 32 Door/Lift Mapping records can be programmed. The type of Intercom system connected may limit the number of Entrance Stations that can be connected via a UART port and therefore the number of Door/Lift Mapping records that will be supported in one Comms Task.
	Door Time	Program the Door Unlock Time. This option applies to all Doors controlled by this Comms Task. If left at 0, the Unlock Time setting in the Door programming will be used.
	Floor Time	Program the Floor Button (De-secure) Time. This option applies to all Floors controlled by this Comms Task. If left at 0, the Button Time setting in the Lift programming will be used.

Intercom Comms Task Kenwei Interface.***Description of the Kenwei Intercom system:***

The Kenwei Intercom system consists of Indoor Monitor units and Outdoor Camera units. Distributor modules are used to connect the Indoor and Outdoor units.

The standard Distributor module has a DIP switch that is used as the Floor selection for the Kenwei Intercom system and allows for up to 4 Indoor Monitor units connected to a single Distributor module. There is also a special type of Distributor module that allows for up to 4 Outdoor Camera unit connections. Distributor modules can be connected in series to build up the intercom system to the required size for the installation.

The Kenwei Intercom system addresses the Indoor Monitor units via the Distributor module's Floor and then the terminal location.

e.g. If the Distributor module was set to Floor 17 and the Indoor Monitor was connected to terminal location 3, the Indoor Monitor's address would be 1703.

The Kenwei Intercom system addresses the Outdoor Camera unit as number 1 when it is connected directly to a Distributor module or via the terminal location when connected to a special Outdoor Camera Distributor module.

e.g. If the Outdoor Camera unit was connected to terminal location 3 of an Outdoor Distributor module, the Outdoor Camera's address would be 3.

Refer to the Kenwei Installation manual for full details.

Interface between Integriti and the Kenwei Intercom system:

The Integriti Apartment's Intercom System Floor and an Intercom System Unit equate to Kenwei's Floor and terminal location of an Indoor Monitor unit. The Integriti Intercom Comms Task's Call Location equates to Kenwei's Outdoor Camera address. The Kenwei Intercom system's RS485 LAN communication protocol has been provided to Inner Range. The Kenwei communication traffic is watched for an "unlock the door" command being sent from an Indoor Monitor unit to an Outdoor Camera unit. When this unlock command is observed, the Integriti Intercom Comms Task searches for an Apartment that matches the Kenwei Indoor Monitor's address. If a match is found the defined Door and/or Lift(s) are temporarily unlocked/unsecured to allow access as well as logging an event to review. If no Apartment is found to match the Kenwei unlock command, then only review is logged.

The Kenwei Intercom's communication traffic is watched by connecting to a segment of the Kenwei RS485 LAN (between the serial Distributors) to a UART on the Integriti Controller. The port configuration that is required is 9600,N,8,1.

Limitations of the Integriti to Kenwei interface:

A typical standalone installation of a Kenwei system involves a physical electronic lock and/or a lamp to be directly wired to the Kenwei Outdoor Camera unit. There are 3 ways that access through the door can be granted: via the Indoor Monitor unit, via a key fob access at the Outdoor Camera unit and via a PIN password entry at the Outdoor Camera unit. Key fobs are registered with and PINs are saved to an Outdoor Camera unit.

Using the Kenwei key fob or PIN access from the Outdoor Camera unit cannot be used when using the Integriti to Kenwei interface. This means that the only method to grant access to the Door/Lift(s) is from an Indoor Monitor unit.

To overcome this limitation it would be envisioned that an Integriti access control Reader would be installed alongside the Kenwei Outdoor Camera unit.

Intercom Comms Task Aiphone Interface.***Interface***

The Aiphone GT Series Intercom system consists of Entrance Stations and Tenant Stations interconnected by Bus Control Units.

The Integriti Aiphone Interface (P/N: 994210) provides an optically isolated communication link between an Aiphone GT Series Intercom system and an Integriti Controller.

The unit interfaces the Aiphone 2-wire bus to an Integriti Controller UniBus UART RS485 Port.

The Interface is supplied as a standard 35mm wide (2-Pole) DIN rail unit for convenient installation with the GT Series DIN rail Bus Control Units.

An 'Intercom' Comms Task is programmed to enable the communication link and supports one Aiphone interface. If additional Interface units are required to connect larger intercom systems to Integriti, additional Comms Tasks will need to be programmed.

Operation

The Intercom Comms Task listens to the Aiphone GT system bus for calls from the ‘entrance station’ (lobby/door) to the ‘tenant station’ (apartment).

When the entrance station calls the tenant station, a message is logged to Integriti Review indicating the ID of both intercom stations. (Note: This information is also used to identify the entrance stations and tenant stations for ‘Comms Task’ and ‘Apartment’ programming respectively)

Integriti monitors the relevant events from intercom stations so that when a tenant station grants access to a visitor (unlock button is pressed), the event may then be used to perform Integriti access control operations.
e.g. Integriti can unlock a door &/or provide lift/floor access for visitors based on intercom events.

Programming

The following Integriti system programming is required:

1. Create an ‘Intercom’ Comms Task set to the “Aiphone” Intercom Type. Select the correct UniBus UART port and set for 9600 Baud, 8 Bits, **Odd Parity** & 1 Stop Bit.
In ‘Door/Lift Mappings’, program the Door &/or Lift/s associated with each Entrance Station ID as required. The Entrance Station ID is obtained from Review when a tenant station is called by an entrance station.
Door unlock and Floor button times may also be programmed if required.
2. Program an ‘Apartment’ for each Tenant Station that is to be monitored.
Enter the ‘Intercom System Tenant ID’ (i.e. Tenant Station ID obtained from Review when the tenant station is called by the entrance station) and the associated ‘Floor’.
The other options (‘Intercom System Floor’ & ‘Intercom System Unit’) are not used in an Aiphone interface.
Up to 250 Apartments are supported by an Integriti Controller.

BMS Comms Task Notes.

The BMS Comms Task programming options provide the parameters to establish high-level communications with the 3rd Party product. Actual operations afforded by the interface are programmed separately in ‘Automation Points’.

<u>BMS FORMAT</u>		The “BMS” communication format allows the Integriti Controller to provide a high-level connection to a 3 rd party Building Management System (BMS). e.g. Clipsal C-Bus.
Settings	BMS Protocol	Select the communications protocol for this BMS Comms Task.
	None	No protocol selected.
	C-BUS	Clipsal C-Bus protocol. Controller Firmware V3.1.0 or later recommended.
	Online Input	Select an Input to be used to monitor the Online status of the BMS Comms Task communications link. The Input will be sealed while the BMS Comms Task is online and in alarm when offline.
		An unused Zone Input can be assigned to this function. Any Zone used for this purpose must have the “Ignore Physical Input” option enabled.
TCP Options	Server IP Address	View or Enter the IP Address of the Server PC.

	TCP Port	View or Enter the Server TCP Port Number. The default Port number (004711) does not normally need to be changed.
	DNS Name	Select required DNS Server Name. DNS Names are programmed separately.
	TCP Mode None Server Client	Select whether the BMS Comms Task is to run as a Server, a Client or neither. <i>See the Guide: Integriti Communications Tasks –BMS).</i>
	Retries	The number of times to retry connecting upon failing to connect before it disconnects. Only programmed if “Client” TCP mode selected above.
	Connection Timeout	Programmed in Minutes and Seconds. <i>See the Guide: Integriti Communications Tasks –BMS).</i>
	Connection Attempt Timeout	Programmed in Minutes and Seconds. <i>See the Guide: Integriti Communications Tasks –BMS).</i>
Connectivity (Serial RS-232)	RS-232 Serial Interface Serial Channel None Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) Modem USB Slave USB Master IAC Onboard RS485	Select the Port that the Comms Task will use. No Modem connection. On-board “Port 0” connection. Unibus UART 1, Port 1 Unibus UART 1, Port 2 Unibus UART 2, Port 1 Unibus UART 2, Port 2 Unibus UART 3, Port 1 Unibus UART 3, Port 2 Unibus UART 4, Port 1 Unibus UART 4, Port 2 Not relevant to this format. Not relevant to this format. Not relevant to this format. Not relevant to this format.
	Baud Rate	Select from: 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200
	Data Bits	Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits
	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits

<u>EN 32 PIN FORMAT</u>	V4.2.2 or later only.	The EN 32-Pin format uses up to 32 Auxiliary outputs for different alarm types, system status and alarm confirmation, to activate inputs on a STU that can support 8 or more Pin inputs. This reporting method is to achieve compliance with EN50131/BS8243 requirements.
Group Options		Group options are programmed independently for each of the 8 Groups available. The options are the same for each Group.
	Start Auxiliary	Select the first Auxiliary for this Group. i.e. The relay that connects the first enabled pin (typically "Fire") in the verify group to the STU. The Pin Auxiliaries for this group will be a continuous sequence of Auxiliaries starting at this Auxiliary and continuing up to the number of pins enabled in the Pin Map. Disabled Pins are skipped so that Auxiliaries are not wasted.
	ATS Test Auxiliary	This option is used to define the Auxiliary output that will be used to trigger the "ATS Test" Input on the STU.
	Line Fault Input	Assign the physical Zone Input that is connected to the "Line Fault" output of the STU as per BSIA Form 175. This input must be wired with alarm and seal EOL resistors appropriate for the EOL config assigned to the zone inputs on the module used.
	Single Path Fault Input Dual Path Fault Input	Single Path Fault and Dual Path Faults are typically phantom zones that are placed in every area that participates in a verify group for the purpose of recording path faults to the event log, which are mandatory events. Unused Zone Inputs can be assigned to these options to indicate a Single Path & Dual Path Fault from the STU. Any Zone used for this purpose must have the "Ignore Physical Input" option enabled.
	Pin Map Fire Pin Holdup Pin Intruder Pin (Unconfirmed) Open Pin Isolate Pin Fault Pin Confirm Intruder Pin Confirm Holdup Pin Power Pin Tamper Pin Jam Pin (RF Jam) Battery Pin Mask Pin Soak Fail Pin Soaking Pin Primary ATS Pin Secondary ATS Pin (ATS = Alarm transmission system)	Select the pin types to be used in this Group. The Pins selected will be mapped to an Auxiliary in sequence starting with the nominated "Start Aux". e.g. If C01:X09 is assigned as the Start Pin and the following 10 Pins are enabled: Fire, Intruder, Open Isolate, Confirmed Intruder, Power, Tamper & Battery, then the Pins will be mapped to Auxiliaries as follows: C01:X09 Fire C01:X10 Intruder C01:X11 Open C01:X12 Isolate C01:X13 Confirmed Intruder C01:X14 Power C01:X15 Tamper C01:X16 Battery C01:X17 Primary ATS C01:X18 Secondary ATS

	Verify Group	Defines the Verify Group assigned to this Group. <i>See 'Verify Group' in Area programming for details.</i>
Review Options	Review Filter	The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc. <i>See "Digital Dialler Formats" for details of the Comms Task Review Options.</i>

SKYTUNNEL FORMAT

NOTES:

1)

If upgrading the Integriti Controller Firmware from a Version prior to V3.0.0, to V3.0.0 or later, see the "Important Upgrade Notes" at the beginning of the "Communications Programming" chapter.

2)

In Controller Firmware V3.2.1 or later:

- The SkyTunnel Comms Task is only required if Alarm Reporting via SkyTunnel is required.
- Configuration of the connection between the Integriti Controller and Integriti Software or Integriti Mobile App via SkyTunnel is now done via "Connection Details" in the General Controller programming and the SkyTunnel Comms Task is not required.

SKYTUNNEL FORMAT		
Miscellaneous options	Backup Input Fail Input	An unused Zone Input may be assigned to monitor the "Backup" status. An alarm will be triggered on this Input when the Backup Comms Task (if assigned) is triggered. Any Zones used for this purpose must have the "Ignore Physical Input" option enabled in Input programming. An unused Zone Input may be assigned to monitor the "Fail" status. An alarm will be triggered on this Input when the SkyTunnel Comms Task fails to report a message. Any Zones used for this purpose must have the "Ignore Physical Input" option enabled in Input programming.
Reporting	Alarm Receiver ID	The Alarm Receiver ID is typically provided by the Central Monitoring Station.
	Map Standard Access SIMS II	If Contact ID is to be used as the alarm reporting format, select the Contact ID Map to be used for this Comms Task. Determines which zones are uniquely reported. <i>Refer to separate Contact ID Map documentation.</i> <i>See 'Contact ID Settings' in the 'Digital Dialler Formats' Comms Task programming for brief descriptions of the Contact ID Map options.</i>
	Client Code Prefix	The Client Code Prefix is typically provided by the Central Monitoring Station.

	Client Code	<p>Determines the account code sent when reporting events to the Central Station. This is the default Client Code for this Comms Task which will be used if there is no Client Code programmed in the Area in which the event to report has occurred.</p> <p>If a Client Code has been programmed for an Area, then that Client Code will take precedence when events are reported for that Area.</p> <p>Options are provided to enter the Client Code in Hexadecimal and Decimal formats. Enter a Decimal value between 0 – 65535, or a Hexadecimal value between 0 – FFFF. (Hexadecimal available in Controller Firmware V3.2.1 or later only)</p> <p>Account Codes are typically provided by the Central Monitoring Station. The number of digits required will depend on the reporting format.</p>
	Format None IRFast Contact ID SIA Four Plus Two	<p>Select Reporting Format for this Comms Task.</p> <p>No format. IR fast. Contact ID. SIA 4+2.</p>
Options	Append Text Update Time. Alarm Look Ahead. General Open / Close. IR fast C3k Xmit Historic	<p>Send Review text for each event reported.</p> <p>The Integriti Controller's Real-time clock will be updated</p> <p>New alarms will be reported ahead of multi-break messages for Inputs that have already reported.</p> <p>Whenever all Areas that are programmed to report Open/Close are turned On, a general Area close is reported. As soon as the first Area is turned Off, a general Area open is reported. In Area Programming, some Areas can be nominated to be ignored in the general Area calculation allowing them to still be reported individually.</p> <p>The C3K Compatible Map is implemented for reporting Input events to Receivers and/or Automation Software that have not yet been updated for Integriti IRFast mapping.</p> <p>Sends buffered events for an Input that has since been isolated or is in an Area which has been disarmed. Normally (this option disabled), when there are events buffered for an input, if the input is then isolated or the Area is disarmed, only the final event is sent. When this option is enabled, this functionality is not executed and all buffered events are sent.</p>
Review Options	Review Filter	<p>The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.</p> <p><i>See "Digital Dialler Formats" for details of the Comms Task Review Options.</i></p>

Obsolete	SkyTunnel Password Primary TCP Options Secondary TCP Options	These options are only programmed within the SkyTunnel Comms Task for Controller Firmware prior to V3.2.1. For Controller Firmware V3.2.1 or later, these options are programmed in the General Controller Options. <i>Refer to the General Controller Options for details.</i>
----------	--	---

<u>E-MODEM FORMAT</u> (External Modem)		The “E-Modem” communication format allows the Integriti Controller to communicate with remote Integriti software via an external Modem connected to a UART Port. NOT YET IMPLEMENTED
Connectivity (Serial RS-232)	RS232 Serial Interface Serial Channel None Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) Modem USB Slave USB Master IAC Onboard RS485	Select the Port that the Comms Task will use. No connection. On-board “Port 0” connection. Unibus UART 1, Port 1 Unibus UART 1, Port 2 Unibus UART 2, Port 1 Unibus UART 2, Port 2 Unibus UART 3, Port 1 Unibus UART 3, Port 2 Unibus UART 4, Port 1 Unibus UART 4, Port 2 Not relevant to this format. Appears as a Virtual Comm Port in Windows and may be used for this format. Not relevant to this format. Not relevant to this format.
	Baud Rate	Select from: 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200
	Data Bits	Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits
	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits
Settings	Allow Timed Bypass Rings to Answer	Not yet implemented. Set the number of rings before the External Modem will answer the call.

<p><u>PEER REPORTING FORMAT</u></p>		<p>Peer-To-Peer reporting allows relevant Review messages to be sent to another Controller for alarm reporting. <i>See Peer-To-Peer in General Controller Programming for more information.</i></p> <p>Note that if the network connection is lost, the Controller will resend the message twice (3 attempts in total). If the message still fails to reach the Destination Controller no further attempt will be made to resend that message. i.e. Old alarms will not get reported via Peer-To-Peer on network reconnection.</p> <p>A “Backup Comms Task”, if programmed, can be used to report alarms that have failed to be reported via Peer-To-Peer reporting.</p> <p>Controller Firmware V3.2.1 or later required.</p>
<p>Miscellaneous Options</p>	<p>Client Code</p>	<p>Determines the account code sent when reporting events to the Central Station. This is the default Client Code for this Comms Task which will be used if there is no Client Code programmed in the Area in which the event to report has occurred.</p> <p>If a Client Code has been programmed for an Area, then that Client Code will take precedence when events are reported for that Area.</p> <p>Options are provided to enter the Client Code in Hexadecimal and Decimal formats. Enter a Decimal value between 0 – 65535, or a Hexadecimal value between 0 – FFFF. (Hexadecimal available in Controller Firmware V3.2.1 or later only)</p> <p>Account Codes are typically provided by the Central Monitoring Station. The number of digits required will depend on the reporting format.</p> <p>For Peer-To-Peer Reporting it is recommended that the Client Codes programmed here and/or in Area programming are different to the Client Codes programmed in the other Controllers in the Peer group. If Client Codes are common to two or more Controllers, then the Monitoring Station will not be able to differentiate between Module/Inputs on different Controllers that have the same Module ID.</p>
	<p>Destination Controller ID</p>	<p>Program the Peer-To-Peer ID of the destination Controller. i.e. The Controller that the review messages will be sent to for reporting.</p> <p>The Peer-To-Peer ID for a Controller can be viewed or programmed in the General Controller programming under Peer-to-Peer options.</p>

Options	<p>General Open / Close.</p> <p>Xmit Historic</p>	<p>Whenever all Areas that are programmed to report Open/Close are turned On, a general Area close is reported. As soon as the first Area is turned Off, a general Area open is reported. In Area Programming, some Areas can be nominated to be ignored in the general Area calculation allowing them to still be reported individually.</p> <p>Sends buffered events for an Input that has since been isolated or is in an Area which has been disarmed. Normally (this option disabled), when there are events buffered for an input, if the input is then isolated or the Area is disarmed, only the final event is sent. When this option is enabled, this functionality is not executed and all buffered events are sent.</p>
Review Options	Review Filter	<p>The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.</p> <p><i>See “Digital Dialler Formats” for details of the Comms Task Review Options.</i></p>
	<p>Status Monitoring.</p> <p>Backup Input</p> <p>Fail Input</p>	<p>Unused Zone Inputs may be assigned to monitor the status of the Peer Reporting Comms Task. Note that any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p> <p>An unused Zone Input may be assigned to monitor the “Backup” status. An alarm will be triggered on this Input when the Backup Comms Task (if assigned) is triggered.</p> <p>An unused Zone Input may be assigned to monitor the “Fail” status. An alarm will be triggered on this Input when the Peer Reporting Comms Task fails to report a message to the Destination Controller.</p>

INTREPID FORMAT		
Miscellaneous options	Online Input	<p>An unused Zone Input may be assigned to monitor the “Online” status. Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p>
Connection Details	<p>IP Address</p> <p>Port</p> <p>Username</p> <p>Password</p>	<p>View or enter the IP Address of the Intrepid system.</p> <p>View or enter the Server TCP Port Number.</p> <p>View or enter the User name for the Intrepid system.</p> <p>View or enter the Password for the Intrepid system.</p>

Fence Modules		Up to 17 Intrepid Fence Modules can be monitored by the Comms Task. The type and ID of each Fence Module must be defined, then the required number of Input groups must be assigned to an Integrity Virtual Module.
	Fence Module ID	Enter the Fence Module ID number.
	Type RPM II MTP II AIM II ROM II-16 ROM II-8 PM II Model 330	Select the type of Fence Module for this Fence Module number.
	Inputs	There are 16 Groups of 32 Fence Module Inputs listed, allowing up 512 Inputs to be monitored per Fence Module. i.e. Inputs 1-32, Inputs 33-64, Inputs 65-96, etc. For each group, assign the Integrity Virtual Module that will be used to monitor those Inputs.

<u>ARC (Alarm Reporting & Control) FORMAT</u>		The ARC format allows primary or backup reporting via a proprietary 3 rd party communicator and is a licensed feature.
Connectivity	RS232 Serial Interface Serial Channel None Modem Onboard RS485 Reader Port Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) USB Master USB Slave	Select the UART Port to use. No Modem connection. Not relevant to this format. Not relevant to this format. On-board "Port 0" connection. Unibus UART 1, RS232 Port 1 Unibus UART 1, RS232 Port 2 Unibus UART 2, RS232 Port 1 Unibus UART 2, RS232 Port 2 Unibus UART 3, RS232 Port 1 Unibus UART 3, RS232 Port 2 Unibus UART 4, RS232 Port 1 Unibus UART 4, RS232 Port 2 Not relevant to this format. Not relevant to this format.
	Baud Rate 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200	The next four options configure the serial port.
	Data Bits	Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits
	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits

Settings	<p>Status monitoring.</p> <p>Online Input</p> <p>Fail Input</p> <p>Backup Input</p>	<p>Allows Inputs to be specified for monitoring a number of ARC Comms Task states. Unused Zone Inputs can be assigned to these functions. Any Zones used for this purpose must have the “Ignore Physical” option enabled.</p> <p>This Zone will be Sealed when communications are working and in Alarm when they are not.</p> <p>This Zone will be put into Alarm when an error condition exists.</p> <p>This Zone will indicate when the Backup Comms Task is Triggered.</p>
	<p>Options</p> <p>General O/C</p> <p>Send buffered isolated events</p> <p>Allow arm/disarm control of areas.</p> <p>Generate Polls</p>	<p>Enable this option for Contact ID/IRfast or SMS Area General Open/Close reporting.</p> <p>Buffered isolated events are sent.</p> <p>Allow remote control of areas via this comms task.</p> <p>Causes the Controller to generate polls instead of waiting to receive them.</p>
	<p>Poll Time</p>	<p>Interval at which polls with the connected Receiver are expected.</p>
Reporting	<p>Reporting Format</p> <p>None</p> <p>IRFast</p> <p>Contact ID</p> <p>SIA</p> <p>Four Plus Two</p>	<p>Select the Reporting Format that will be used to send alarm information to the Monitoring Station.</p> <p>No format. IR fast data will be sent. Contact ID data will be sent. SIA 4+2.</p>
	<p>Review Filter</p>	<p>The Review Filter options may be programmed to determine the events that will be reported based on parameters such as specific entities, entity types, Comms Task Groups, Event type, etc.</p> <p><i>See “Digital Dialler Formats” for details of the Comms Task Review Options.</i></p>
	<p>Contact ID Map</p> <p>Standard</p> <p>Access</p> <p>SIMS II</p>	<p>Select the Contact ID Mapping for this Comms Task. Determines which zones are uniquely reported in the Contact ID format.</p> <p>This option is required if the Contact ID format is selected above, or if the IRFast format is selected and ‘Send Contact ID’ is enabled in the IRFast options below.</p> <p><i>Refer to separate Contact ID Map documentation.</i></p> <p><i>See ‘Contact ID Settings’ in the ‘Digital Dialler Formats’ Comms Task programming for brief descriptions of the Contact ID Map options.</i></p>

	Client Code	<p>Determines the account code sent when reporting events to the Central Station.</p> <p>This is the default Client Code for this Comms Task which will be used if there is no Client Code programmed in the Area in which the event to report has occurred.</p> <p>If a Client Code has been programmed for an Area, then that Client Code will take precedence when events are reported for that Area.</p> <p>Options are provided to enter the Client Code in Hexadecimal and Decimal formats. Enter a Decimal value between 0 – 65535, or a Hexadecimal value between 0 – FFFF. (Hexadecimal available in Controller Firmware V3.2.1 or later only)</p> <p>Account Codes are typically provided by the Central Monitoring Station. The number of digits required will depend on the reporting format.</p>
IRFast Settings. (Only required if IRFast format selected)	<p>Send Text.</p> <p>Send Contact ID.</p> <p>Send Time.</p> <p>C3K Compatible.</p> <p>300 Baud.</p> <p>XMIT Info.</p> <p>Save time.</p>	<p>Send Review text for each event reported.</p> <p>Send an equivalent Contact ID string for each event reported, using the mapping option selected. This is useful when the automation system cannot understand native IRfast information.</p> <p>Send a text string of the Time/Date the event was recorded into review.</p> <p>The C3K Compatible Map is implemented for reporting Input events to Receivers and/or Automation Software that have not yet been updated for Integriti IRFast mapping.</p> <p>Forces all communications to 300 Baud instead of the default 1200 Baud. This need only be set if there are communication difficulties at 1200 Baud</p> <p>Send miscellaneous panel information before hanging up, including panel serial number, software version and security option settings.</p> <p>Causes the Receiver to Update the panel time and date from its system clock prior to hanging up.</p> <p>NOTE: An IRFast Receiver can set any of the above options to Yes on a per receiver basis.</p> <p>The above options should only be enabled upon instruction from the Central Station.</p>

<u>NEMTEK FORMAT</u>		V4.3.0 or later only. (V4.3.2 or later recommended)
Configuration	<p>IP Address</p> <p>Port</p> <p>Online Input</p>	<p>View or enter the IP Address of the Nemtek system.</p> <p>View or enter the Server TCP Port Number of the Nemtek system.</p> <p>An unused Zone Input may be assigned to monitor the “Online” status.</p> <p>Any Zones used for this purpose must have the “Ignore Physical Input” option enabled in Input programming.</p>

Energizers	Energizer 1 Energizer 2 Energizer 3 ...etc.	Up to 32 NEMTEK Fence Energizers can be monitored by the Comms Task. Each Energizer to be monitored is assigned an Integriti Virtual Module.
IO Cards	IO Card 1 IO Card 2 IO Card 3 ...etc.	Up to 32 NEMTEK IO Cards can be monitored by the Comms Task. Each IO Card to be monitored is assigned an Integriti Virtual Module.

<u>MODBUS FORMAT</u>		V4.3 or later only. (V4.3.2 or later recommended)
Configuration	IP Address Port Online Input	View or enter the IP Address of the Modbus system. View or enter the Server TCP Port Number of the Modbus system. An unused Zone Input may be assigned to monitor the "Online" status. Any Zones used for this purpose must have the "Ignore Physical Input" option enabled in Input programming. <i>See "Poll Time" and "Slave Timeout" below</i>
	RS232 Serial Interface Serial Channel None Modem Onboard RS485 Reader Port Uart 0 Unibus Uart1(1) Unibus Uart1(2) Unibus Uart2(1) Unibus Uart2(2) Unibus Uart3(1) Unibus Uart3(2) Unibus Uart4(1) Unibus Uart4(2) USB Master USB Slave	Select the Port to use. No Modem connection. Not relevant to this format. Not relevant to this format. On-board "Port 0" connection. Unibus UART 1, RS232 Port 1 Unibus UART 1, RS232 Port 2 Unibus UART 2, RS232 Port 1 Unibus UART 2, RS232 Port 2 Unibus UART 3, RS232 Port 1 Unibus UART 3, RS232 Port 2 Unibus UART 4, RS232 Port 1 Unibus UART 4, RS232 Port 2 Not relevant to this format. Not relevant to this format.
	Baud Rate 1200 / 2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200	The next four options configure the serial port.
	Data Bits	Select from: 5 Bits / 6 Bits / 7 Bits / 8 Bits
	Parity	Select from: None / Odd / Even / Force 1 (Mark) / Force 0 (Space)
	Stop Bits	Select from: 1 Bit / 2 Bits
	Poll Time	Sets the maximum time allowed between received packets before the Comms Task considers the link to have failed and triggers the 'Online Input'.
	Slave Timeout	Triggers the online input and disconnects TCP if no message is received within this time.

	Comms Mode Rtu Master Rtu Slave TCP Master TCT Slave	
--	--	--

Telephone Numbers

Entity/Feature	Option	Description
Telephone Numbers		Select Telephone Number to program.
Name.		Program a name for the Telephone Number up to 32 characters in length.
Telephone Number		<p>Enter the Telephone Number.</p> <p>The telephone number can include the digits 0 to 9 and the * and # character.</p> <p>A Pause can be programmed into any part of the telephone number sequence by inserting one or more comma (,) or full-stop (.) characters. , (comma) = 125 millisecond pause. . (full-stop) = 2 second pause. e.g. A 0.5 second pause would be: , , , , A 2.25 second pause would be: . , ,</p> <p>Some Telephone Numbers such as the SMS Service number must be entered in international format starting with the country code. e.g. The Telstra Australia SMS service number is entered as "61418706700". (61 is the Country Code for Australia)</p> <p>Telephone numbers used as SMS numbers should also be entered in the international format. Note that when entering a number in international format <u>do not</u> include the + symbol at the beginning.</p>

Telephone Number Lists. See *"Users and Permissions" – "Lists"*.

Network Interface Controllers

Entity/Feature	Option	Description
Network Interface Controllers		Select Network Interface to program.
Name.		Program a name for the Network Interface Controller up to 32 characters in length.

IP Address	Local IP Address	Program the static IP address of the local machine (if needed). Only use this option for statically assigned IP addresses. If you do not know the correct value for this setting, see the person responsible for IT infrastructure at the installation site.
	Subnet Mask	Program the Subnet Mask used by this Network Interface. Only use this option for statically assigned IP addresses. If you do not know the correct value for this setting, see the person responsible for IT infrastructure at the installation site.
	Gateway address	Program the Gateway Address used by this Network Interface. Only use this option for statically assigned IP addresses. If you do not know the correct value for this setting, see the person responsible for IT infrastructure at the installation site.
	Use DHCP	If this option is enabled, the DHCP protocol will be used. Disable this option if the static IP Address settings defined above are to be used. If you do not know the setting for this option, see the person responsible for IT infrastructure at the installation site.
DNS Settings	Primary DNS	Program the Primary DNS Address used by this Network Interface. If you do not know the correct value for this setting, see the person responsible for IT infrastructure at the installation site.
	Backup (Secondary) DNS	Program the Backup DNS Address used by this Network Interface. If you do not know the correct value for this setting, see the person responsible for IT infrastructure at the installation site.

DNS Names

Entity/Feature	Option	Description
DNS Name		Select the DNS Name to program.
Name		Program a name for the DNS Name up to 32 characters in length.
DNS Name		Enter the DNS Name text.

System Options Programming

Entity/Feature	Option	Description
Memory Options		Select a Memory Configuration. (Not currently used)
Auxiliary Options		Program/Edit Auxiliary options.
EOL Configurations		Program/Edit Zone Input End Of Line Resistor Schemes.

Memory Configuration

Entity/Feature	Option	Description
Select Configuration		Not currently used.

Auxiliary Options

Entity/Feature	Option	Description
Auxiliary to Edit		Select the Auxiliary to program or edit.
Auxiliary Name		Program a text name of up to 32 characters in length. The name may include the Auxiliary location and/or function.
Options	Auxiliary Options. No Review. Remember State through Reset (Allow Turn On on Reset)	Activity on this Auxiliary will not be saved to Review. V3 Stream: In V3.3.10 or later, this includes Door Lock and DOTL Auxiliaries. V4 Stream and later: In V4.1.0 or later, this includes Door Lock and DOTL Auxiliaries. On a System Reset, the Auxiliary will be returned to the state it was in prior to the reset.
	Analogue Calibration	Assign a Calibration to this Auxiliary. Determines the calibration parameters for this Auxiliary if it is an Analogue output type. Calibrations are programmed separately.

EOL Configurations

CAUTION: Do not edit the default EOL configurations or create new configurations without a thorough understanding of how the scheme operates, and the ramifications across your system.

Note that most legacy Concept Modules do not support alternate EOL schemes.

See 'Inputs. EOL for Zones' under 'Controller - Module Details' for a list and descriptions of the default EOL Configurations.

Entity/Feature	Option	Description
EOL Configuration		Select the EOL Configuration to program or edit..

Name		Program a text name of up to 32 characters in length. The name should unambiguously describe the EOL Configuration.
Options	<p>Default state debounce time (ms)</p> <p>Alarm state debounce time (ms)</p> <p>Alarm Restore state debounce time (ms)</p>	<p>Minimum time that the Zone Input must remain in an EOL state to process a change.</p> <p>Optional minimum time that the Zone Input must remain in an Alarm EOL state to process a change.</p> <p>Optional minimum time that the Zone Input must <u>not</u> be in the Alarm EOL state to process a change.</p> <p>Note that these options do not apply to legacy Concept Modules.</p>
	<p>ELM Tamper Switch Type</p> <p>None</p> <p>Open Circuit Secure</p> <p>Closed Circuit Secure</p>	<p>This option defines how the dedicated ‘Tamper’ input on an ELM is wired. V4.3.0 or later only.</p> <p>The option is only relevant to EOL Configs that are intended to be used with the Infiniti Encrypted Expander and ELM devices. e.g. Class 5.</p> <p>No Tamper Switch is connected. (Tamper monitoring is performed by using EOL Resistors on the Alarm input)</p> <p>The Tamper Switch is Open Circuit when the enclosure is sealed/closed.</p> <p>The Tamper Switch is Closed Circuit when the enclosure is sealed/closed.</p>
Ranges	Resistance	<p>Program the eight Resistance settings to define the upper limit of each Band.</p> <p>Eight Bands are available. The resistance range for each Band is from the setting for the previous Band, to the setting of the Band being programmed.</p> <p>e.g. In “Concept3K”, the range for Band 1 is currently 0 Ohms to 1567 Ohms. For Band 2, 1567 Ohms to 4000 Ohms, etc.</p>
State Mapping	<p>Band States</p> <p><u>EOL Input States</u></p> <p>Alarm</p> <p>Tamper Low</p> <p>Tamper High</p> <p>Tamper</p> <p><u>Logical Input States</u></p> <p>Zone Self-Test Fail</p> <p>Battery</p> <p>Isolate</p>	<p>Select an EOL Zone “State” for each of the Bands that are to be monitored.</p> <p>There is a range of EOL and Logical Input States to choose from, however, normally only one state from the EOL Input States (Alarm to Tamper) is assigned for a Band.</p> <p>Logical Input States are not relevant to this option and must not be assigned.</p>

Access Control

Entity Types and Groups

Entity/Feature	Option	Description
Entity Types	Door Types Qualified Door Types Lift Types Qualified Lift Types Lift Groups Challenge Definitions	Edit the names, options and permissions of Access Control Entity Types and Groups. Types & Groups simplify the programming of other entities such as Doors and Lifts by providing pre-programmed entities that define operations.

DOOR TYPES

IMPORTANT NOTE: If the operation of certain types of Doors is required to change depending on time/date and/or the status of other entities, then “Qualified Door Types” need to be used. (MENU, 2, 4, 5)

e.g. If the credential requirements are “Card Only” to enter and REX button to exit during normal business hours, but “Card & PIN” to enter and “Card Only” to exit at other times.

A Qualified Door Type consists of one or more Door Types, each paired with a Qualifying entity such as a Time Period or an Area state, etc.

DOOR TYPES		Door Types provide a simple method of defining how Doors of the same type will operate. Door Types are used to define the operation of Doors where the operation is not required to change due to the status of other entities such as Time Periods.
Find/Create Door Type.		Select the Door Type you wish to edit.
Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Entry Options	User Credential Mode for Entry None Card Only PIN Only Card OR PIN Card AND PIN	Select the User Credential requirement for Entry. None Card must be used. PIN Code must be used. Card or PIN code may be used. User’s Card must be followed by the User’s PIN Code.
	Dual User. Mask Forced Mode.	Dual User requirement for entry. If enabled, REN will only be used to mask the Forced Door processing and not unlock the Door.

	<p>Anti-Passback Mode for Entry.</p> <p>None Soft</p> <p>Hard</p> <p>Harder</p> <p>Timed</p>	<p>Select the Anti-Passback mode for entry. The Anti-Passback feature is used to monitor or prevent misuse of the access control system by keeping a record of a User's current location. A message is logged to review and access denied (depending on mode selected) if access is attempted in violation of the anti-passback rules described below.</p> <p>No Anti-Passback. The Area the User is <u>about to enter</u> is checked against the User's <u>current</u> location. If these Areas are the same (i.e. The User credential has been "passed back" to a different User), access is still granted, but an Anti-passback violation is logged to Review.</p> <p>The Area the User is about to enter is checked against the User's current location as for "Soft" anti-passback above. If these Areas are the same, <u>access is denied</u> and an Anti-passback violation is logged to Review.</p> <p>The Area the User is about to enter, <u>and</u> the Area the Reader is located in, are both checked against the User's current location. If the entry Area is the same or the Reader Area is <u>not</u> the same, <u>access is denied</u> and an Anti-passback violation is logged to Review.</p> <p>Same as Hard Anti-passback, except that Amnesty is automatically applied when the Anti-Passback time for that User expires.</p> <p>IMPORTANT NOTES. All Anti-Passback Modes: All Doors used in the system's anti-passback scheme are required to have an IN Reader <u>and</u> OUT Reader unless the Door is a one-way entry or exit point such as a turnstile. Reed switch monitoring of the Door state is also recommended along with use of the Door option "Door Not Opened Review". "Hard" & "Harder" Anti-Passback Modes: Amnesty can be provided for an individual User via the "Set Area User is in" Action, or for all Users via the "Grant Amnesty" Action. If a firmware update & reset is performed on the Controller while users are in the anti-passback area/s, it may be necessary to grant amnesty to all Users. A "Grant Amnesty" action triggered by the Controller 'Reset' System Input (C01:S13) may be considered if appropriate.</p>
	<p>Entry Button Mode.</p> <p>None Enable Deadlock</p>	<p>Defines Entry button operation.</p> <p>Entry button is Disabled Entry button is Enabled Entry button is Enabled, but only while the Area that the button is located in is Off (Disarmed) i.e. The Area on the same side of the Door.</p>
	<p>Entry Area Disarm Options.</p> <p>Disarm Door Entry Area Disarm User Area</p>	<p>Defines Area Disarm operations on entry.</p> <p>Door Area OFF on entry. User Area OFF on entry.</p>

Exit Options	User Credential Mode for Exit None Card Only PIN Only Card OR PIN Card AND PIN	Select the User Credential requirement for Exit. None Card must be used. PIN Code must be used. Card or PIN code may be used. User's Card must be followed by the User's PIN Code.
	Dual User. Mask Forced Mode.	Dual User requirement for exit. If enabled, REX will only be used to mask the Forced Door processing and not unlock the Door.
	Anti-Passback Mode for Exit. None Soft Hard Harder Timed	Select the Anti-Passback mode for exit. No Anti-Passback. The Area the User is about to enter is checked against the User's current location. If these Areas are the same, access is still granted, but an Anti-passback violation is logged to Review. The Area the User is about to enter is checked against the User's current location. If these Areas are the same, access is denied and an Anti-passback violation is logged to Review. The Area the User is about to enter, <u>and</u> the Area the Reader is located in, are both checked against the User's current location. If the entry Area is the same or the Reader Area is <u>not</u> the same, access is denied and an Anti-passback violation is logged to Review. Same as Hard Anti-passback, except that Amnesty is automatically applied when the Anti-Passback time for that User expires. For "Hard" and "Harder" Anti-passback, amnesty can be provided for an individual User via the "Set Area User is in" (Uarea) Action. <i>See additional notes in 'Anti-Passback Mode for Entry'.</i>
	Button Mode for Exit. None Enable Deadlock	Defines Exit button operation. Exit button is Disabled Exit button is Enabled Exit button is Enabled, but only while the Area that the button is located in is Off (Disarmed) i.e. The Area on the same side of the Door.
	Exit Area Disarm Options. Disarm Door Entry Area Disarm User Area	Defines Area Disarm operations on exit. Door Area OFF on exit. User Area OFF on exit.

QUALIFIED DOOR TYPES

IMPORTANT NOTES:

1. If more than one Door Type is used in a Qualified Door Type, and there is a possibility that more than one Door Type may be valid at the same time, it is important to consider the order in which the Door Types are assigned.
i.e. The Door Types in the Qualified Door Type are prioritised from Q1 to Q8.

2. If the Door operations are not required to change due to the status of other entities then "Door Types" should be used.
(MENU, 2, 4, 2)

A Qualified Door Type consists of a list of one or more Door Types, each paired with a Qualifying entity such as a Time Period or an Area state, etc.

If a Qualified Door Type is assigned to a Door, then on any access attempt, the Door operation is determined by the first Door Type in the list that is currently valid.

QUALIFIED DOOR TYPES		Qualified Door Types provide a simple method of defining how Doors of the same type will operate, and allow for circumstances where the operation of certain types of Doors is required to change depending on time/date and/or the status of other entities. e.g. If the credential requirements are “Card Only” to enter and REX button to exit during normal business hours, but “Card & PIN” to enter and “Card Only” to exit at other times.
Find/Create Qualified Door Type.		Select the Qualified Door Type you wish to edit.
Name.		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Door Types	Door Types What When	Program or Edit the first Door Type for this Qualified Door Type. The “What” <u>must</u> be a Door Type that defines how the Door is to operate. The “When” will be an entity that will define when the Door is to operate in this way. e.g. Typically a Time Period or an Area status. Up to 8 Door Types can be assigned to a Qualified Door Type.

INTERLOCKS

Interlocks provide a simple means of programming Door Interlocking and/or qualifying Door Access with the state of one or more other entities.

An Interlock may be assigned to a Door so that access through the Door is qualified by that Interlock Group. The Interlock restricts access through the Door based on the state of entities (typically one or more Doors or Door Lists) in the Interlock Group programming.

e.g. Access to a Door into an airlock can be disabled while any other Door into the same airlock is Unlocked and/or Open.

Interlock programming also allows other entities to be used to qualify Door access. e.g. The state of one or more Areas, Zone Inputs or Auxiliaries.

Once programmed, an Interlock may be assigned to any number of Doors that share the same interlocking requirements.

INTERLOCKS	Firmware V4.2.0 or later recommended.	Select the Interlock you wish to edit.
Name.		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.

Interlock Entities	What	Program or Edit the “Interlocked Entities” for this Interlock Group. e.g. To define the Door List, Area, etc., to be applied in the Interlock logic.
	When	Defines the entity for this Interlock Entity. e.g. Door List, Area, Input, etc. Defines when the entity is valid for this Interlock Entity. e.g. Time Period, Area state, etc. Up to 16 Interlock Entities can be assigned to an Interlock Group. <i>See “Permission Programming” for details of how to program this option.</i>

LIFT TYPES

Lift Types are used to define the operation of Lifts where the operation is not required to change due to the status of other entities such as Time Periods.

IMPORTANT NOTE:

If the operation of certain types of Lifts is required to change depending on time/date and/or the status of other entities, then “Qualified Lift Types” need to be used. (MENU, 2, 4, 5)

e.g. If the credential requirements are “Card Only” to enter and REX button to exit during normal business hours, but “Card & PIN” to enter and “Card Only” to exit at other times.

A Qualified Lift Type consists of one or more Lift Types, each paired with a Qualifying entity such as a Time Period or an Area, etc.

LIFT TYPES	<i>See the “Integriti Lift Interfacing” document for a full description of Integriti Lift Access Control.</i>	Lift Types provide a simple method of defining how Lifts of the same type will operate.
Find/Create Lift Type.		‘Add New’ or select a Lift Type to edit.
Name		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Entry Options	User Credential Mode for Entry None Card Only PIN Only Card OR PIN Card AND PIN	Select the User Credential requirement for Entry. None Card must be used. PIN Code must be used. Card or PIN code may be used. User’s Card must be followed by the User’s PIN Code.
	Dual User. Mask Forced Mode	Dual User requirement for entry. REX/REN only used to mask the Forced Door processing and not unlock the Door. NOT relevant to Lift Access Control.

	<p>Anti-Passback Mode for Entry.</p> <p>None Soft</p> <p>Hard</p> <p>Harder</p> <p>Timed</p>	<p>Select the Anti-Passback mode for entry.</p> <p>No Anti-Passback. The Area the User is about to enter is checked against the User's current location. If these Areas are the same, access is still granted, but an Anti-passback violation is logged to Review.</p> <p>The Area the User is about to enter is checked against the User's current location. If these Areas are the same, access is denied and an Anti-passback violation is logged to Review.</p> <p>The Area the User is about to enter, <u>and</u> the Area the Reader is located in, are both checked against the User's current location. If the entry Area is the same or the Reader Area is <u>not</u> the same, access is denied and an Anti-passback violation is logged to Review.</p> <p>Same as Hard Anti-passback, except that Amnesty is automatically applied when the Anti-Passback time for that User expires.</p> <p>For "Hard" and "Harder" Anti-passback, amnesty can be provided for an individual User via the "Set Area User is in" (Uarea) Action.</p> <p>NOT relevant to Lift Access Control.</p>
	<p>Button Mode for Entry.</p> <p>None Enabled Deadlock</p>	<p>Defines Entry button operation.</p> <p>Entry button is Disabled Entry button is Enabled Entry button is Enabled, but only while the Area that the button is located in is Off (Disarmed) i.e. The Area on the same side of the Door.</p> <p>NOT relevant to Lift Access Control.</p>
	<p>Entry Area Disarm Options.</p> <p>Disarm Door Entry Area Disarm User Area</p>	<p>Defines Area Disarm operations on entry.</p> <p>NOT relevant to Lift Access Control.</p>

QUALIFIED LIFT TYPES

A Qualified Lift Type consists of a list of one or more Lift Types, each paired with a Qualifying entity such as a Time Period or an Area, etc.

If a Qualified Lift Type is assigned to a Lift, then on any access attempt, the Lift operation is determined by the first Lift Type in the list that is currently valid.

If more than one Lift Type is used in a Qualified Lift Type, and there is a possibility that more than one Lift Type may be valid at the same time, it is important to consider the order in which the Lift Types are assigned.

i.e. The Lift Types in the Qualified Lift Type are prioritised from Q1 to Q8.

IMPORTANT NOTE:

If the Lift operations are not required to change due to the status of other entities then "Lift Types" should be used. (MENU, 2, 4, 2)

QUALIFIED LIFT TYPES	<i>See the “Integrati Lift Interfacing” document for a full description of Integrati Lift Access Control.</i>	Qualified Lift Types provide a simple method of defining how Lifts of the same type will operate, and allow for circumstances where the operation of certain types of Lifts is required to change depending on time/date and/or the status of other entities. e.g. If the credential requirements are “Card Only” to enter and REX button to exit during normal business hours, but “Card & PIN” to enter and “Card Only” to exit at other times.
Find/Create Qualified Lift Type.		Select the Qualified Lift Type you wish to edit.
Name.		Program a text name of up to 32 characters in length. This feature can be used to describe the purpose and/or contents of the entity.
Lift Types	Lift Types What When	Program or Edit the first Lift Type for this Qualified Lift Type. The “What” <u>must</u> be a Lift Type that defines how the Lift is to operate. The “When” will be an entity that will define when the Lift is to operate in this way. e.g. Typically a Time Period or an Area status. Up to 8 Lift Types can be assigned to a Qualified Lift Type.

LIFT GROUPS

See the “Integrati Lift Interfacing” document for a full description of Integrati Lift Access Control.

Entity/Feature	Option	Description
Create/Find Lift Group		Select Lift Group to program. Lift Groups are required when a high-level interface (EMS Comms Task format) is used. Not required for low-level interface.
Lift Group Name.		Program a text name of up to 32 characters in length. The name can be used to describe the purpose and/or contents of the entity.
EMS Floor Mapping		Assign each Floor ID of the EMS to the required Integrati Controller Floor record. For each Floor: <ul style="list-style-type: none"> • Add the Integrati Floor to be mapped. • Enter an EMS Floor number. • If the Floor record is for a Rear Door, then enable the “Rear Door” option.
Settings	EMS Rise	Enter the Rise number to send to an EMS system for Lifts in this Group. The number must be 1 or greater.
	EMS Group	Enter the Group number to send to an EMS system for Lifts in this Group. The number must be 1 or greater.

	Number of Floors	Enter the number of Floors in this Group. If left at 0, the largest EMS Floor number will be used.
--	------------------	---

CHALLENGE DEFINITIONS

Challenge definitions define the parameters for the Integriti Operator Challenge feature.

Operator Challenge displays information to the operator about a card access request and can be used to passively view or interactively grant/deny access to Users as they pass through one or more doors.

The Challenge Definitions can be programmed to:

- Randomly select Users to provide operations such as random bag searches or drug tests to be administered.
- Grant access to Users who do not normally have permissions to access particular Doors.

The Operator Challenge dialogue is completely customizable allowing User Photos, CCTV streams, Allow/Deny buttons, Challenge History, Information display with changeable font/colours and several other items to be arranged and sized as desired. The dialogue can optionally display:

- CCTV footage
- The User's photo
- Custom text
- Challenge history
- Allow button
- Deny button
- A web page

A list of Task Actions can be executed automatically on any challenge, random selection, allow or deny. These Task Actions are the same as used throughout the system, allowing control of entities, sending of messages, etc.

To enable Operator Challenge:

1. Enable the AURM option for any Integriti Controllers on which the Operator Challenge feature will apply.
2. Enable the "Ask PC" option for any Readers on which the Operator Challenge feature will apply.
3. Enable the "Ask PC" option for any Users to which the Operator Challenge feature will apply.

See the Integriti Software "Guide - Operator Challenge" document for more details.

Entity/Feature	Option	Description
Create/Find a Challenge Definition		Select Challenge Definition to program.
Challenge Definition Name.		Program a text name of up to 32 characters in length. The name can be used to describe the purpose and/or contents of the entity.
What To Challenge	Door	A combination of Doors, Sites/Keywords and Filters can be used to specify what Doors you want to monitor using this Challenge Definition. Add one or more individual Doors.
	Sites/Keywords	Add one or more entire Sites or Keywords.
	Filter	Create a Filter to define additional Door selection parameters.

	<p>User</p> <p>Sites/Keywords</p> <p>Filter</p>	<p>A combination of Users, Sites/Keywords and Filters can be used to specify what Users you want to monitor using this Challenge Definition.</p> <p>Add one or more individual Users.</p> <p>Add one or more entire Sites or Keywords.</p> <p>Create a Filter to define additional User selection parameters.</p>
Settings	<p>Show Challenge To Operator</p> <p>Never</p> <p>Always</p> <p>Only on Random Selection</p> <p>All Entry Requests</p> <p>All Exit Requests</p> <p>Randomly selected Entry Requests</p> <p>Randomly selected Exit Requests</p>	<p>This option determines when the Challenge dialogue will appear.</p> <p>The Operator Challenge will never display. If Users, Readers, etc. are configured for Operator Challenge (“Ask PC” option) and there is no corresponding Operator Challenge, the Controller will send a challenge request, time out after 20 seconds, then process the User based on their permissions.</p> <p>Operator Challenge will appear on every access event.</p> <p>Operator Challenge will appear on a random access event based on X occurrences out of Y challenges. <i>See Random Selection below.</i></p> <p>Operator Challenge will appear on every entry access event.</p> <p>Operator Challenge will appear on every exit access event.</p> <p>Operator Challenge will appear on a random entry access event based on X occurrences out of Y challenges. <i>See Random Selection below.</i></p> <p>Operator Challenge will appear on a random exit access event based on X occurrences out of Y challenges. <i>See Random Selection below.</i></p>
	<p>Requires Operator Input</p> <p>Never</p> <p>Always</p> <p>Only on Random Selection</p>	<p>Settings for “Requires Operator Input” behave the same way as “Show Challenge To Operator” described above. When an Operator is not required to Input anything, the Controller will continue to process the User based on their permissions.</p>
	<p>Random Selection</p> <p>Select X Occurrences Out of Y Challenges</p> <p>Random Selection Message</p>	<p>These options are used to represent the random percentage of access events that will trigger the Operator Challenge. e.g. Select 1 Occurrences Out of 3 Challenges will give you a 33% chance that the User will be picked for Operator Challenge.</p> <p>Program a simple text string that will be used to display a message to the Operator when an Operator Challenge event occurs.</p>

Challenge Response Layout	<p><i>See Integriti Software Documents:</i></p> <ul style="list-style-type: none"> - <i>“Guide - Operator Challenge”</i> - <i>“Integriti GateKeeper”</i> <p><i>for more details.</i></p>	<p>The Challenge response layout is configured the same way as an Alert Response Plan:</p> <ol style="list-style-type: none"> a) Information Boxes display custom text. ‘%’ tags and multiple lines are supported. b) Information Displays support basic HTML tags. The supported tags are listed in the Guide. c) Challenge Pass Button is required for situations where Operator response is required. d) Challenge Deny Button is required for situations where Operator response is required. e) User Image can display either the User image or a custom image field of the User that triggered the Operator Challenge. f) CCTV stream will display live CCTV video from the camera or cameras associated with the door(s) associated with the Operator Challenge. g) Challenge history displays a live stream of past and present Operator Challenges. h) Browser Item will display the web page specified. Keywords associated with the user can be used in the browser URL.
Automatic Actions	<p>On Challenge</p> <p>On Random Selection</p> <p>On Allow On Deny</p>	<p>Add one or more actions to perform for any of the four types of Operator Challenge events.</p> <p>The nominated action/s will occur on every occurrence of the Operator Challenge based on the “What To Challenge” criteria.</p> <p>The nominated action/s will occur whenever a Random Selection occurs on a random Operator Challenge event based on the “What To Challenge” Settings.</p> <p>The nominated action/s will occur whenever an “Allow” or “Deny” event occurs when an Operator selects these options via the Operator Challenge dialogue.</p>

Access Control Entities

Card Formats

Integrati provides an extensive range of pre-programmed Card Formats that will cater for the vast majority of applications. These default Card Formats are described in the table below.

Card formats are assigned to 'Card Templates' and to Readers on a number of LAN Module types. Note that some Module types (e.g. Prisma-SIFER Terminal) only support a limited number of Card Formats. Details are provided in the programming details for each Module.

An additional Card format would only need to be programmed to cater for a less common proprietary format or a newly developed format not already provided in the Integrati Card Formats.

Please report additional format requirements to Inner Range Support for inclusion in future updates.

#	Card Format	Description
CF1	Direct Entry Wiegand	Direct Entry Wiegand
CF2	26Bit Wiegand (H10301)	HID 26 Bit Wiegand (H10301)
CF3	Indala 27 Bit - Wiegand	Indala 27 Bit Wiegand
CF4	Keri 30 Bit Wiegand	Keri 30 Bit Wiegand
CF5	Ind/Kant KSF 32Bit Wiegand	Indala / Kantech KSF 32 Bit Wiegand
CF6	HID 32 Bit Wiegand	HID 32 Bit Wiegand
CF7	KASTLE 32Bit Wiegand	KASTLE Wiegand Swipe Card 32 Bit
CF8	HID 34Bit Wiegand (H10306)	HID 34 Bit Wiegand (H10306)
CF9	Indala 34Bit Wiegand	Indala 34 Bit Wiegand
CF10	HIDCorp1000 35Bit (H50360)	HID Corporate 1000 35 Bit Wiegand (H50360)
CF11	HID 35 Bit Wiegand	HID 35 Bit Wiegand
CF12	Indala 36 Bit Wiegand	Indala 36 Bit Wiegand
CF13	HID 36Bit Wieg (Std)	HID 36 Bit Wiegand (Std)
CF14	HID 36Bit Wiegand (S906133A)	HID 36Bit Wiegand (S906133A)
CF15	HID 37Bit No SC (H10302)	HID 37 Bit Wiegand with No Site Code (H10302)
CF16	HID 37Bit SC (H10304)	HID 37 Bit Wiegand with Site Code (H10304)
CF17	HID iClass 37Bit Wiegand	HID iClass 37 Bit Wiegand
CF18	BQT 38Bit Wiegand	BQT 38 Bit Wiegand
CF19	HID 40Bit Wiegand	HID 40 Bit Wiegand
CF20	IR Secure40 Wiegand	Inner Range Secure40
CF21	IRMag Secure	Inner Range Magnetic Card Secure Site Code
CF22	C3K Mag Direct	Concept 3000/4000 Magnetic Card Direct Entry
CF23	Integrati Mag Direct	Integrati Magnetic Card Direct Entry
CF24	SIFER Direct 88	For direct entry of Inner Range SIFER Cards. V4.0.0 or later only.
CF25	SIFER Site Code	Decrypts an Inner Range SIFER card and matches it on Site Code and Card Number. V4.0.0 or later only.
CF26	Tecom Secure	Tecom Smart Card Site Code & Card Number data. (From TS0870 Reader connected via RS485) V17 or later only. (If this Card Format is required and is not present refer to the Integrati Application Note: "Tecom TS0870 Series Smart Card Reader Integration")

Entity/Feature	Option	Description
Card Format		'Add New' or select a Card format to edit.
Name.		Program a text name of up to 32 characters in length. The name can be used to describe the data protocol, bit length and/or provider of the format.
Options	Card Type	The Card Type will tell the reader how to operate, including whether to expect Magnetic Stripe or Wiegand card data,

	<p>None</p> <p>Wiegand Raw Data</p> <p>Wiegand Site Code</p> <p>SIFER Direct 88</p> <p>SIFER Site Code</p> <p>IR Secure 40</p> <p>Mag Swipe Raw Data</p> <p>IR Mag Swipe (Site Code)</p> <p>Mag Swipe Site Code</p> <p>Hashed Credit Card</p> <p>Wiegand Site (Complex)</p> <p>40 Bit Mag Raw Data</p> <p>Mag Swipe Site Code (bits)</p> <p>Legacy: C3k Raw Data</p> <p>Custom Software Codec</p>	<p>whether it needs to convert the raw data to site code, card number and issue number, or if it needs to hash or decrypt the card data (e.g. Credit Card or IR Secure40). The additional programming fields displayed will vary depending on the Card Type chosen in this option.</p> <p>Select the Card Type to be used in this format.</p> <p>Note: If a “Raw Data” Card Type is selected, and the data on the Cards to be used will be of different bit lengths, ensure that the “Total Bits” option below is set to “0”.</p> <p>No Card Type selected.</p> <p>For direct entry Wiegand cards of any length. (If migrating the card database from a Concept 3000/4000 system you may wish to use the “Legacy: C3k Raw Data” Type.)</p> <p>Allows user credentials to be entered as site code and card number providing the format is known.</p> <p>For direct entry of Inner Range SIFER Cards. V16.0.3 or later recommended if the Card data is greater than 64 bits.</p> <p>Decrypts an Inner Range SIFER card and matches it on Site Code and Card Number.</p> <p>Decrypts an IR Secure 40 card and matches it on Site Code and Card Number.</p> <p>Reads up to the first 22 characters of a mag card, until it gets an end or separator sentinel character.</p> <p>Decrypts a Concept Secure Magnetic card and returns its site code, card number and issue number.</p> <p>Reads magnetic cards in character mode. Allows user definable site code parameters to be programmed, except lengths and offsets are specified in characters instead of bits.</p> <p>Reads the first 22 characters from a mag card and generates a 5 byte hash from this using the same algorithm as the Concept "Credit Card" format.</p> <p>Allows for Site Code formats unknown to Inner Range. This is the recommended format when only one card format is used throughout the system.</p> <p>This magnetic swipe card format reads the first 10 characters (40 bits) from a mag card, nibble swapping each byte (i.e: swapping each character pair). This allows for compatibility in migrations where Concept Mag Direct was used.</p> <p>This format makes the reader return the binary data from the card instead of characters. This supports non "ISO Track 2" cards where the site code and card number info is stored as binary data instead of characters.</p> <p>Reads the Wiegand card data and removes the start bit. This helps migrations from Concept direct entry Wiegand systems where the start bit was not used (i.e. Most C3k/C4k Wiegand Direct Entry installations).</p> <p>If using this Card Type for data from Readers on an IAC, the IAC firmware should be V16.0.3 or later.</p> <p>Allows some Card data formats not covered by any of the options above, to be decoded. V4.2.4 or later only. Contact Inner Range Technical Support for advice and information on fees that may be applicable. <i>See additional ‘Custom Codec’ information under ‘Card Programming’</i></p>
--	---	---

		<i>below.</i>
	Reverse Bytes (V4.3.0 or later only)	Reverse the order of 'direct entry' card data from the Reader. This option may be used when different readers supply UID data in different orders. This setting is only relevant to Direct Entry card formats and does not reverse card data bytes when the card format is a site code type.
Site Code Parameters		The Site Code Parameters options will vary depending on the Card Type selected above.
	<u>Wiegand Raw Data</u> <u>Mag Swipe Raw Data</u> <u>Hashed Credit Card</u> <u>40 Bit Mag Raw Data</u> <u>Legacy C3k Raw Data</u> <u>SIFER Direct 88</u> Total Bits	If one of these Raw Date Card Types is selected above, this option allows the Card data parameters to be defined. The total number of bits present in the Card's data.
	<u>Wiegand Site Code</u> <u>Mag Swipe Site Code</u> <u>Mag Swipe Site Code (bits)</u> <u>SIFER Site Code</u> Total Bits Site Code Offset Site Code Length Card Number Offset Card Number Length Issue Number Offset Issue Number Length	If one of these Site Code Card Types is selected above, this option allows the Card data parameters to be defined. The total number of bits present in the Card's data. The number of bits in the string prior to the Site Code data. The number of bits in the Site Code data. The number of bits in the string prior to the Card Number data. The number of bits in the Card Number data. The number of bits in the string prior to the Issue Number data. (If used) The number of bits in the Issue Number data. (If used) e.g. If the card data string is 38 bits where Bit 1 is Parity, Bits 2 to 17 are Site Code Data, Bits 18 to 37 are Card Number and Bit 38 is Parity, the settings would be programmed as follows: Total Bits: 38 Site Code Offset: 1 Site Code Length: 16 Card Number Offset: 17 Card Number Length: 20 Issue Number Offset: 0 Issue Number Length: 0

	<p><u>Wiegand Site Complex</u></p> <p>Encoding Method</p> <p>Standard</p> <p>Total Bits Site Code Offset Site Code Length Card Number Offset Card Number Length Issue Number Offset Issue Number Length</p>	<p>If this Site Code Card Type is selected above, this option allows the Card data parameters to be defined.</p> <p>Select the encoding method used for this format.</p> <p>Only the ‘Standard’ method is available at this time.</p> <p>The remaining parameters in this option are the same as described for “Wiegand Site Code” above.</p>
	<p><u>IR Secure 40</u></p> <p>Standard</p> <p>Registered Site</p> <p>Enterprise</p>	<p>If the Inner Range Secure 40 Card Type is selected above, choose the IR Secure 40 scheme that will apply to this Card Format.</p> <p>The Scheme is shown on the label affixed to the box that the cards were supplied in.</p> <p>The Site Code (Hex) is 10 characters in length and also indicates the scheme type as follows:</p> <ul style="list-style-type: none"> • 00nnnnnnnn = Standard • 01nnnnnnnn = Registered Site • 02nnnnnnnn = Enterprise <p>“Registered Site” and “Enterprise” Cards will also have the text “RS[nn]” printed on them, where nn is the production batch number.</p> <p>Standard. Over 32,000 Site Codes and Card Numbers up to 65,535.</p> <p>Registered Site. Unique Client Site Codes factory registered and Card Numbers up to 65,535.</p> <p>Enterprise. Unique Client Site Codes factory registered and Card Numbers up to 1,048,575.</p>

<p>Card Programming</p>	<p>Wiegand Card Type</p> <p>Legacy Modules:</p> <p>Integriti Modules:</p> <p>26 Bit 27 Bit 30 Bit 32 Bit 34 Bit 35 Bit 36 Bit 37 Bit N Bit Secure 40</p>	<p>For all Card Types in a Wiegand format, an option is provided to select a Wiegand Card Type. This can be N Bit meaning that any bit length is allowed or it can be set to a particular bit length. N Bit will always return all the bits read. For fixed bit lengths, the behaviour varies between legacy Concept Modules and Integriti Modules.</p> <ul style="list-style-type: none"> - For cards equal to or longer than the bit length, it will return the first n bits, as if the card read were n bits long. If the card is shorter than the bit length, it is ignored. - If the card is not equal to the bit length, it is ignored completely. <p>If a Wiegand Card Type is selected above, select the Wiegand Card Type required.</p> <p>26 Bits 27 Bits 30 Bits 32 Bits 34 Bits 35 Bits 36 Bits 37 Bits</p> <p>Any bit length is allowed. Inner Range Secure 40 Bits</p>
	<p>Alternate Card Format (V4.1.1 or later)</p>	<p>If the detected card bit length does not match the ‘Total Bits’ property of this card format, then the alternate card format defined here will be tried.</p> <p>By defining an Alternate Card Format for a Card Format that is assigned to a Reader, this enables the Reader to support 2 or more Card Formats. e.g. Corporate1000 and Standard 26Bit on a HID Reader.</p>
	<p>Direct Entry Ignore Mask (V4.2.0 or later only)</p>	
	<p>Custom Codec</p>	<p>If a Custom Codec is required for a card format that is not covered by the available Card Formats above, the codec is entered here.</p> <p>If a codec is able to be created for the format, it would be provided by Inner Range Technical Support, and may incur a fee.</p> <p>In firmware V17.0.0 or later, a Custom Codec can process up to 88 bits of credential (card) data. V4.2.4 to V16 supports up to 64 bits of credential data in a Custom Codec. See ‘Custom Software Codec’ under ‘Card Type’ above.</p>

SIFER Options	<p>Tag-Type</p> <p>SIFER MIFARE® DESFire® EV1 CSN MIFARE Classic® CSN MIFARE Plus® S CSN MIFARE Plus® X CSN MIFARE® JCOP CSN MIFARE Ultralight® CSN FELICA CSN 15693 CSN TYPEB CSN PicoPass CSN (incl. iClass)</p>	<p>For SIFER Readers and Cards, select the 'tag type' (i.e. Card data type) that is allowed to be processed. More than one option may be selected.</p>
---------------	--	--

Photo ID Designs

Entity/Feature	Option	Description
Photo ID Designs		<p>Photo ID Designs can be programmed to create design templates for different types of User Cards to be used in the system.</p> <p>A Photo ID Design is then assigned to a Card Template so that a default Photo ID Design will be provided when printing a Card for any User associated with that Card Template.</p>
Name.		<p>Program a text name of up to 32 characters in length. The name can be used to describe the design, or in the case of multi-tenancy systems, the name may be used to identify the Tenant.</p>
Card Properties and Elements.		<p>Refer to the Integriti Software Manual for details of programming and layout of the Card Properties and Elements.</p> <p>Some default designs are included in the Software which can be used as a guide when creating new designs.</p>

Locations

Entity/Feature	Option	Description
Location	Controller Firmware V3.0 or later only.	<p>'Add New' or select a Location to edit.</p> <p>Locations provide an entity to facilitate the global anti-passback feature when the access control system consists of multiple Integriti Controllers.</p> <p>It is only necessary to program Locations if global anti-passback is required across Integriti Controllers linked via the Peer-To-Peer feature.</p> <p>Once programmed, Locations can then be assigned to the Inside and/or Outside of each Door on which global anti-passback functionality is required.</p>

Location Name		Program a text name of up to 32 characters in length. The Location Name would typically include the physical location that it represents.
---------------	--	---

Door Programming

Entity/Feature	Option	Description
Door		'Add New' or select a Door to edit.
Door Name		Program a text name of up to 32 characters in length. The Door Name would typically include the location and possibly the type of the Door.
	Door Programming	<p>Door programming has been divided into two tabs:</p> <p>'Door Programming' allows all the basic parameters to be programmed easily within a simple graphical representation of the Door. If basic access control is required, most, if not all, of the programming can be done here.</p> <p>IMPORTANT NOTE: If a Door is being controlled by 2 or more different Modules, once the Door is assigned to both Modules, the 'Door Programming' tab becomes greyed-out and the 'Advanced' tab must be used.</p> <p>The Lock Auxiliary to be used to unlock the Door <u>must be defined</u> in the "Advanced Door Configuration" options.</p> <p>e.g. A Door Lock is controlled by the 1st Lock Relay on SLAM 'R02'. The Entry reader is also connected to R02, while the Exit reader is an EliteX-SIFER Keypad 'T03'. The Door "Lock Auxiliary" option must be set to R02:X01. In the LCD Terminal programming for the EliteX-SIFER keypad, the "Door Hardware" option under 'Access Control' must be set to "None".</p>
	Advanced	<p>'Advanced' allows the basic options and all other options associated with a Door, to be programmed.</p> <p>If basic access control is required, and the Door Programming tab has already been used, you may only need to program a few parameters on the Advanced tab such as "Door Unlock Time" (if you wish to change the default value of 5 seconds), "Door Open Too Long Time" and "Warn Time".</p>
	<i>DOOR PROGRAMMING</i>	
Module		<p>Select the Module that the Door Reader and hardware are connected to.</p> <p>This will most commonly be a:</p> <ul style="list-style-type: none"> - Reader Module (e.g. SLAM, C3/4k 2-Door, etc.) - Intelligent Reader Module (e.g. ILAM, C3/4k IFDAM, etc.) - IAC. <p>Or may also be an:</p> <ul style="list-style-type: none"> - LCD Terminal. (Elite LCD Terminal or EliteX Keypad) - Graphic Terminal. (Note that no Inputs or Outputs are available on Graphic Terminals)

Relay	No Lock Lock 1... Lock 2... Lock 3... Lock 4... Lock 5... Lock 6... Lock 7... Lock 8...	<p>Select the Lock Relay to be used for this Door. (Not required for Aperio Wireless Locks)</p> <p>The number of locks displayed in the drop-down list will vary according to the type of Module chosen above.</p> <p>The list indicates:</p> <ul style="list-style-type: none"> - Which Board ('On-board' or 'UniBus...') or Device (Salto, Intego or Tecom) the lock is associated with. e.g. Lock 2 On-Board - Which Lock output or device address each lock number is associated with. e.g. Lock 5 Unibus Door Module: DIP 3 #1 - Which Lock outputs are already in use. e.g. Lock 1 On-Board: In use by Conference Room Door.
Hardware options	Hardware Type Lock Number Unibus DIP switch Number Enable Reed Input Enable Tongue Input	<p>A 'Hardware Options' button is provided beside the Relay selection field. This allows the Installer to view &/or program relevant hardware options for the Module selected above if required.</p> <p>Details of these options can be found in the relevant Module type programming details in this document. e.g. 'Reader Module', 'Intelligent Reader Module', 'LCD Terminal', etc. programming.</p>
Door Type	Default Door Types: Entry Door Exit Door Internal (RIRO) Door Card+PIN Entry Door Card+PIN Exit Door Card+PIN Internal (RIRO) Door	<p>Select the Door Type or Qualified Door Type for use with this Door.</p> <p>The selected Door Type or Qualified Door Type will determine how this particular door will function. Door Types and Qualified Door Types are programmed separately</p> <p>The 6 default Door Types shown opposite cover common Door Access Control requirements. Additional Door Types or Qualified Door Types may be programmed.</p> <p>If a Qualified Door Type is assigned, then on any access attempt, the Door operation is determined by the first Door Type in the list that is currently valid.</p>
Outside Settings	Reader None R1... R2... R4... R4... ... R16...	<p>Select the Module Reader Port or Reader Device to be used for the Outside Reader. From 1 to 16 Readers may be available depending on the Module Type.</p> <p>The list indicates:</p> <ul style="list-style-type: none"> - Which Board/s (e.g. On-Board/UniBus) &/or Reader Devices (e.g. SIFER) are present & which Reader port or Device ID each Reader number is associated with. e.g. R2 On-Board (Wiegand) 2 R3 Unibus Door Module: DIP 2 #1 R5 SIFER 11977 - Which Readers are already associated with a Door. e.g. R1 On-Board (Wiegand) 1 Outside Staff Entry Door

	Reader Details	<p>A button is provided beside the Reader selection field to allow the Installer to view &/or program relevant Reader options if required. The button opens a dialog showing the Reader Details for the relevant Reader based on the Module and Reader already selected.</p> <p>e.g. Reader Details programming may be necessary if:</p> <ul style="list-style-type: none"> - The Reader purpose is not 'Control a Door'. - The Reader LED/Beeper options need to be defined. - A specific Card Format is required for this Reader. - The Reader is a PIN Code entry device. - The AURM (Ask PC) feature is implemented. - etc. <p>Details of all the Reader options can be found in the relevant Module programming details in this document. e.g. 'Reader Module', 'Intelligent Reader Module', 'Graphic Terminal', etc. programming.</p>
	<p>Arm Mode</p> <p>None Button</p> <p>3 Badge</p> <p>Area Empty</p>	<p>Select the Area Arming Mode for this Reader if required.</p> <p>No Area Arming via this Reader The "Arm" button must be held on while the Credential (i.e. Card) is presented. The Credential (i.e. Card) is presented to the Reader 3 times within a 5 second period. The Area will Arm when the User Count within that Area transitions from 1 to 0. i.e. When the last person exits the Area. V4.2.0 or later recommended.</p>
	Location	<p>Select the Location to be associated with the Outside of this Door. i.e. The "Exit" Location.</p> <p>This option is only required for operations in which User Location Tracking is needed such as Global Anti-passback on multi-panel sites. Locations are programmed separately. <i>See Locations programming for more details.</i></p> <p>Note that the Entry &/or Exit Area is still used to prevent access if the Area is armed and the User does not have permission to disarm, and Area User counting still occurs regardless of whether Global Anti-Passback is used.</p>
	Area	<p>Select the Area to be associated with the Outside of this Door. (The "Exit" Area)</p> <p>Required for operations and functions that use the Area status or data such as Reader Arming/Disarming, Anti-passback, User Counting, etc.</p> <p>If the Door is a perimeter Door this option is normally left set to "None". i.e. If exiting through the Door takes you out of all areas being protected by the system.</p>
Inside Settings	Reader	<p>Select the Module Reader Port or Reader Device to be used for the Inside Reader.</p> <p>Options as above.</p>

	Reader Details	<p>A button is provided beside the Reader selection field to allow the Installer to view &/or program relevant Reader options if required. The button opens a dialog showing the Reader Details for the relevant Reader based on the Module and Reader already selected.</p> <p>See above for details.</p>
	Arm Mode	<p>Select the Area Arming Mode for this Reader if required.</p> <p>Options as above.</p>
	Location	<p>Select the Location to be associated with the Inside of this Door. i.e. The “Entry” Location.</p> <p>This option is only required for operations in which User Location Tracking is needed such as Global Anti-passback.</p> <p>Note that the Entry &/or Exit Area is still used to prevent access if the Area is armed and the User does not have permission to disarm, and Area User counting still occurs regardless of whether Global Anti-Passback is used.</p>
	Area	<p>Select the Area to be associated with the Inside of this Door. (The “Entry” Area)</p> <p>Required for operations and functions that use the Area status or data such as Reader Arming/Disarming, Anti-passback, User Counting, etc.</p>
Door Options	<p>Enable Reed Input</p> <p>Enable Tongue Input</p>	<p>This option defines which Inputs on the nominated Module will be used when processing various operations such as Forced Door, DOTL monitoring, Door re-locking, Interlocking, Door Not Opened Review, etc.</p> <p>The “Reed” Input for this Door will be used.</p> <p>The “Tongue Sense” Input for this Door will be used.</p>
	ADVANCED	
Door Configuration	Door Type	<i>See above.</i>
	Inside Area	<i>See above.</i>
	Outside Area	<i>See above.</i>
	Inside Location	<i>See above.</i>
	Outside Location	<i>See above.</i>
	Leaf Door	<p>This option is required if the Door is part of a set of double doors, where the other Door is independently controlled (separate Lock relay) using the same Card Reader.</p> <p>The option is programmed by assigning the Door that is associated with the other Lock relay.</p>

	<p>Door State Follows Area State</p> <p>None Inside Area Outside Area Either Area</p> <p>Both Areas</p>	<p>Select if the Door state is to be controlled by the Inside and/or Outside Area. i.e. Door will Unlock if Area Disarmed, and will Lock if Area is Armed.</p> <p>Door state does not follow Area State. Door state follows Inside Area State. Door state follows Outside Area State. Door state is Locked when either the Inside <u>or</u> Outside Area is Armed, and will Unlock when both Areas are Disarmed. Door state is Locked when the Inside <u>and</u> Outside Areas are both armed, and will Unlock when either Area is Disarmed.</p> <p>NOTE: When this option is enabled and a Time Period is also assigned to the Door “Free Access” option, then the Door will only be unlocked when the conditions defined in both options are met. i.e.</p> <table border="1" data-bbox="810 768 1453 887"> <thead> <tr> <th>AREA STATE</th> <th colspan="2">FREE ACCESS TIME PERIOD</th> </tr> <tr> <th></th> <th>Invalid</th> <th>Valid</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Locked</td> <td>Locked</td> </tr> <tr> <td>OFF</td> <td>Locked</td> <td>Unlocked</td> </tr> </tbody> </table>	AREA STATE	FREE ACCESS TIME PERIOD			Invalid	Valid	ON	Locked	Locked	OFF	Locked	Unlocked
AREA STATE	FREE ACCESS TIME PERIOD													
	Invalid	Valid												
ON	Locked	Locked												
OFF	Locked	Unlocked												
	<p>Physical Type</p> <p>Normal Roller (Up – Down)</p> <p>Roller (Toggle)</p>	<p>Select the physical type of the Door.</p> <p>Normal Door. A Roller Door that requires separate outputs from the controller for Up and Down control. A Roller Door that requires a single timed output from the controller on which each activation toggles between Up and Down.</p> <p><i>See “Roller Doors” following the Door programming for details.</i></p>												
	<p>Inhibit Input</p>	<p>If a Roller Door type is selected above, an Inhibit Input may be programmed. The Inhibit Input is installed to detect something blocking the physical path of the Roller Door. e.g. A PE (Photo Electric) beam installed immediately inside the Roller Door to detect the presence of a pedestrian or vehicle under the raised Door.</p>												
<p>Advanced Door Configuration</p>	<p>Lock Auxiliary</p>	<p>Hardware Auxiliary address for Door lock. This option must be programmed only when:</p> <ol style="list-style-type: none"> a) The door does not use the predefined local lock auxiliary of the Reader Module, IAC or Terminal. b) When the Door is controlled by two or more different Modules. e.g. A SIFER Reader on an ILAM as entry reader and an EliteX-SIFER keypad as exit reader. 												

	Door Unlock Time	<p>Determines how long the door lock auxiliary remains On when the Door is accessed.</p> <p>Programmed in Hours, Minutes and Seconds up to a maximum of 18 Hrs, 12 Mins and 15 Seconds.</p> <p>If the Door is an Aperio Wireless Lock, this time should be the same value as the “Lock open time” in the Aperio Lock. <i>See the document ‘Integrati Application Note – Aperio Integration’ for details.</i></p>
	Disability Unlock Time	<p>Determines how long the door lock auxiliary remains On when the Door is accessed by Users that have the “disabled” option enabled.</p> <p>Programmed in Hours, Minutes and Seconds up to a maximum of 18 Hrs, 12 Mins and 15 Seconds.</p>
	Door Open Too Long (DOTL) Time.	<p>Determine how long a door may remain open until a DOTL warning or alarm is generated.</p> <p>If the Door remains open longer than this time, then:</p> <ul style="list-style-type: none"> - If a DOTL Warning Time is <u>not</u> programmed, the relevant DOTL (Door Held) System Input on the Module will go into alarm. - If a DOTL Warning Time <u>is</u> programmed (see below), the relevant local DOTL Warning output on the Module will be turned on for the Warning Time. If the Door continues to remain open for longer than the warning time, the relevant DOTL (Door Held) System Input on the Module will go into alarm. <p>Programmed in Hours, Minutes and Seconds up to a maximum of 18 Hrs, 12 Mins and 15 Seconds.</p>
	Warn Time (Door Open Too Long [DOTL] Warning Time)	<p>Determines the DOTL Warning timer period.</p> <p><i>See “Door Open Too Long (DOTL) Time” above for details.</i></p>
	Interlock	<p>Defining an Interlock restricts access through this Door based on the state of entities in the Interlock Group programming. e.g. Access to a Door into an airlock can be disabled while any other Door into the same airlock is Unlocked and/or Open.</p> <p>Interlock Groups are programmed separately.</p>
Anti-Passback	Entry Area Anti-Passback Minutes (For “Timed” Anti-passback only)	<p>Defines the Timed Anti-Passback period for an anti-passback violation on the Entry Area.</p> <p><i>See “Anti-Passback Mode” in Door Types programming for details.</i></p>
	Exit Area Anti-Passback Minutes (For “Timed” Anti-passback only)	<p>Defines the Timed Anti-Passback period for an anti-passback violation on the Exit Area.</p> <p><i>See “Anti-Passback Mode” in Door Types programming for details.</i></p>

<p>Debounce</p>	<p>Force Debounce.</p>	<p>This option will shunt the reed/tongue for this time after the door is unlocked. This is to stop the panel accidentally relocking the door due to bounce as it is opened. While the door is unlocked if the panel senses the door open, it will wait for it to close again. When it closes the panel will automatically relock the door, even if the lock timer hasn't expired.</p> <p>If the Door is an Aperio Wireless Lock, this option may need to be programmed to prevent false alarms if the Door Forced System Input is monitored. <i>See the document 'Integrity Application Note – Aperio Integration' for details.</i></p>											
<p>Behaviour</p>	<p>When Offline</p> <p>Permissive</p> <p>Restrictive</p> <p>No Access</p>	<p>Select an Offline option for this Door to define how it will operate if the host Module is offline.</p> <p>Normal offline access mode based on a subset of the User's permissions.</p> <p>Any Doors to which the User has unqualified access (i.e. access all the time) will be allowed.</p> <p>Any Doors to which the User has time-period qualified access (i.e. access only at certain times) will <u>not</u> be allowed.</p> <p>Access will be denied to all Users at this Door if the host Module is offline.</p>											
	<p>Free Access</p>	<p>If the Door is required to be in Free Access under certain conditions, select the Time Period that will define the Free Access conditions.</p> <p>NOTE: When a Time Period is assigned to this option, and the "Door state follows Area state" option is also enabled, then the Door will only be unlocked when the conditions defined in both options are met.</p> <p>i.e.</p> <table border="1" data-bbox="807 1234 1453 1352"> <thead> <tr> <th rowspan="2">AREA STATE</th> <th colspan="2">FREE ACCESS TIME PERIOD</th> </tr> <tr> <th>Invalid</th> <th>Valid</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Locked</td> <td>Locked</td> </tr> <tr> <td>OFF</td> <td>Locked</td> <td>Unlocked</td> </tr> </tbody> </table>	AREA STATE	FREE ACCESS TIME PERIOD		Invalid	Valid	ON	Locked	Locked	OFF	Locked	Unlocked
AREA STATE	FREE ACCESS TIME PERIOD												
	Invalid	Valid											
ON	Locked	Locked											
OFF	Locked	Unlocked											
	<p>Access Granted Action (V4.2.0 or later only)</p>	<p>Allows an action to be defined that will be performed whenever a User is granted access at this Door.</p> <p>IMPORTANT NOTES:</p> <ol style="list-style-type: none"> 1) The 'Qualifier' programmed in the nominated Action is processed differently when used in this operation. Valid qualifier types are "User" or "Permission Group" only, and are used to define which User/s will cause the action to be performed. 2) Only the 'Assert' edge can be triggered. 											
<p>Card Format</p>	<p>Card Format.</p>	<p>This option is no longer shown in Advanced Door options. The Card Format can be edited via the 'Reader Details' button next to the Reader selection field on the 'Door Programming' tab.</p> <p><i>See the table under "Card Formats" in the 'Access Control' section for the full list of default card formats and their details.</i></p>											

Roller Doors

Options are provided in Door programming to define a physical Door type of “Roller (Up – Down)” or “Roller (Toggle)”. Roller (Up – Down) is a Roller Door that requires separate outputs from the controller for Up and Down control. Roller (Toggle) is a Roller Door that requires a single timed output from the controller on which each activation toggles between Up and Down.

To implement Roller Door control, a Reed Switch is installed (door reed input) that seals when the door is fully closed, and an optional reed switch is installed (tongue sense input) that seals when the door is fully open.

The complete list of Input and Output states used for Roller Doors is as follows:

Door reed sealed	Roller door fully down (locked)
Door reed in alarm	Roller door not fully down
Tongue reed sealed	Roller door fully up (locked) (tongue input must be enabled)
Tongue reed in alarm	Roller door not fully up (tongue input must be enabled)
Door Lock output	Roller up output (or toggle output for toggle type doors)
Door DOTL output	Roller down output (only for up/down type doors)
Door Tamper Input	Alarms when a roller door fault occurs, seals when tries again
Door DOTL Input	Alarms at start of down warning, seals at end of down warning (Program an action to the Door DOTL Input to annunciate a door down warning)
Door Forced Input	Alarms if the door is currently fully opening, and is being prevented from closing by the Door inhibit input (see below)
Door Inhibit Input	Pauses a door going down via an input (e.g. safety beam) When input re-seals door continues down Doesn't work for toggle mode doors

The following Door and Reader Module programming options are required to implement Roller Door control:

- Set the Physical Door Type option to Up/Down roller door or Toggle roller door.
- Set the “Door Unlock Time” to the maximum time it takes to open the roller door, or if tongue sense is not enabled, the time that the roller door requires to reach its desired open position.
- Set the “Extended Unlock Time” to the maximum time it takes to close the roller door.
- Set the “Door Open Too Long Time” to the maximum time it takes the roller door to signal it is now opening/closing via the reed or tongue inputs.
- Set the “Warn Time” to the time that the DOTL input will remain in alarm as a warning prior to the roller door closing (going down warning)
- Set “Force Debounce” time to set the time the toggle relay turns on for in toggle mode (Also sets the gap between toggles)
- Select the “Inhibit Input” if being used.
- The Reader Module “Enable Tongue Input” option is set for the appropriate Door if a reed is installed to indicate the roller door is fully open (connected to the tongue sense input).

The roller state machine is designed to try and get the roller door either open (if the door is unlocked) or closed (if the door is locked).

The roller state machine does not alter the lock status of the door - it simply tries to manipulate the roller door to get it into the correct state.

If the roller doors cannot be got into the correct state to match the lock status of the door, then a "Fault" state is assumed and no more effort is made to get the roller door to match the door lock status until another lock(or relock) or unlock (or re-unlock) attempt is made.

Whilst in the "Fault" state, the door tamper input is in the alarm condition indicating a problem. If a door is currently up and is being prevented from closing because of the inhibit input, then the door forced input will be in alarm.

All attempts to close (lock) a roller door are preceded by a "Down Warning" state. This state puts the door DOTL input into alarm which can be used to warn personnel that the door is about to close. At the end of the warning time the door attempts to close. Once the door direction down is established, if the inhibit input is sensed in alarm then the door will revert to going up. When a card is presented or REX/REN button pushed and the door is a roller door, then the current lock state of the door is toggled. i.e. Lock to unlock or unlock to lock.

A Motor overload output can be wired to tamper either reed or tongue input to immediately cause the fault input state.

Note on Inhibit Input and Roller Door toggle mode: In toggle mode, the lock output pulses to reverse the direction of the door, i.e. going up or going down. The roller state machine attempts to deduce the correct direction the door is travelling, however, it is possible under abnormal circumstances that the door direction is not ascertained correctly. This can result in the inhibit input not successfully stopping a closing door. When using toggle mode, another means must also be used to sense door obstructions.

Note on tongue sense: If tongue sense is disabled, then the state machine uses the “Door Unlock Time” to determine when the door is considered to be fully open from fully closed. Note that subsequent locks and unlocks could result in the door going higher than desired.

It is not recommended to have tongue sense disabled in toggle mode because when the door is in the open state, there is no way to see if the toggle state is correct by monitoring for an alarm on the tongue reed switch (door fully open).

Lift Car Programming

See the “Integriti Lift Interfacing” document for a full description of Integriti Lift Access Control.

Entity/Feature	Option	Description
Lift Car		‘Add New’ or select a Lift Car to edit.
Name		Program a text name of up to 32 characters in length. The Lift Car Name may include the location and/or type of the Lift.
Restricted Floors		If the Lift Car does not service all Floors, permissions may be programmed to define one or more Floors or Floor Lists that are serviced (by selecting “Allow”) and/or are not serviced (by selecting “Deny) by this Lift Car and when these restrictions apply. Up to 3 Restricted Floor Permissions may be assigned.
Lift Configuration	Lift Mode None Low Level (No Button Feedback) Low Level (Button Feedback) High Level / EMS	Select the Interface Mode used for this Lift Car. None Low Level Lift interface with no Button Feedback Low Level Lift interface with Button Feedback High Level Lift interface via Serial or Ethernet communications.
	Lift Type	Select the Lift Type or Qualified Lift Type for use with this Lift Car. The selected Lift Type or Qualified Lift Type will determine how this particular Lift will function. Lift Types and Qualified Lift Types are programmed separately. There are no default Lift Types. If a Qualified Lift Type is assigned, then on any access attempt, the Lift operation is determined by the first Lift Type in the list that is currently valid.
	Lift Floors	Define the Floors to be serviced by this Lift Car.

	Button On Time	<p>Program the Button time in Hours, Minutes and Seconds. This option determines how long the lift buttons are enabled when the Lift is accessed by a User. A value of 5 seconds is typical, but longer times may be required for service elevators and vehicle elevators, etc.</p> <p>Note that the button time for Users that have the ‘Disability’ option enabled will be determined by the ‘Disability Button On Time’ below.</p>
	Disability Button On Time	<p>Program the Button time for Users with the “Disability” option enabled in their User record. The time is programmed in Hours, Minutes and Seconds and will override the ‘Button On Time’ programmed above for these Users.</p>
	Valid Auxiliary	<p>Select an Auxiliary to be used to indicate a valid User Lift access request. This auxiliary will be turned on when a valid card is presented. Typically used to access a turnstile where an interface (typically a relay) is required to signal a 3rd party control device.</p>
High Level	<p>EMS Type</p> <p>Car Panel</p> <p>Destination Panel</p> <p>Home Floor Caller</p>	<p>The Reader and Floor selection panel are located within the Lift Car.</p> <p>This Lift Car is logically a Destination Panel. The Reader and Floor selection panel are located in the Lift Lobby (outside the Lift Car)</p> <p>Kone RCGIF.</p> <p><i>See the Guide: Integriti Communications Tasks –Lift Interfacing (EMS).</i></p>
	Lift Group	<p>Select a Lift Group to define the EMS parameters for this Lift Car. Lift Groups are programmed separately.</p>
	EMS Terminal ID	<p>Identifies the EMS Terminal associated with this Lift Car if required.</p> <p><i>See the Guide: Integriti Communications Tasks –Lift Interfacing (EMS).</i></p>
	EMS Lift ID	<p>Program an EMS Lift number to identify this Lift Car to the EMS.</p> <p>If the EMS Type is a Destination Panel, program the Destination Panel ID for this Lift Car.</p> <p><i>See the Guide: Integriti Communications Tasks –Lift Interfacing (EMS).</i></p>
	EMS Floor Number	<p>If the EMS Type “Destination Panel” or “Home Floor Caller” has been selected, program this option to identify the Floor number to the EMS.</p> <p>Destination Panels and Home Floor Callers are installed in Lift lobbies or in Offices/Apartments, etc. and not within Lift Cars. This option defines the Floor on which the Destination Panel or Caller is installed.</p>

	Valid Auxiliary Time	Program an On time for the Valid Auxiliary when using High Level Lift mode.
	Offline Lift (Firmware V16 or later only)	This lift handles the permission when system is offline in HLI.
	Global Permissions (Firmware V16 or later only)	This Lift handles the global permissions of HLI.
	Associated Reader Module (Firmware V16 or later only)	When the HLI receives card data for this Lift, it will create reads from this Reader Module.
	Associated Reader Number (Firmware V16 or later only)	When the HLI receives card data for this Lift, it will create reads from this Reader on the 'Associated Reader Module'.
Low Level	Hardware Interface a) UniBus Lift Interface board. b) LAN Zone Expanders	<p>If a Low Level interface is in use, select the hardware that will be used for Floor button enables for this Lift. The hardware entity selected will be a relevant Controller/LAN Module or an Auxiliary depending on which of the two interface methods listed below are used.</p> <p>If UniBus Lift Interface Boards are used, select the host LAN Module or Controller that the Lift Interface board/s are connected to. IMPORTANT NOTES: 1. A host module is required per lift car. Adding more UniBus Lift Interfaces to a host module only expands the number of floors for a single lift car. 2. UniBus Lift Interface outputs are <u>not</u> Auxiliaries.</p> <p>If LAN Zone Expanders are used, select the first Auxiliary. The Floor Button enable Relays will be a continuous sequence of Outputs starting at this Auxiliary and continuing up to the number of Floors defined in "Lift Floors". After the last Auxiliary on the Module, you move to the next Auxiliary on the next sequential module (E01:32 to E02:X01)</p>
	Error Auxiliary	Select an Auxiliary to be used to indicate an Invalid User credential or an error in the Lift access control process.
	Add Floors	Set to Yes IF you require additional Floor buttons to immediately be enabled when another User presents their Card to the Reader while the previous User's buttons are still enabled.
	Use 2 nd Enables	Set to Yes if you require the previous User's enabled buttons to be cancelled when another User presents their Card to the Reader.
	Button Enable Hold Time	If Button Feedback is in use, program the Button Enable Hold Time in Days, Hours, Minutes and Seconds. This option defines the time that the Floor buttons remain enabled after button feedback is received.

Floor Programming

See the "Integriti Lift Interfacing" document for a full description of Integriti Lift Access Control.

Entity/Feature	Option	Description
-----------------------	---------------	--------------------

Floor		'Add New' or select a Floor to program.
Name		Program a text name of up to 32 characters in length. The Floor Name may include the location of the Floor.
Associated Area		Select an optional Area to be associated with this Floor if required.

Locker Programming

Integriti allows access control of up to 1000 Lockers per Controller. This feature is useful for applications such as secure units in a self-storage facility, lockers provided for personal belongings in a sports centre, etc.

A 'Locker Bank Control' Smart Card Licence is required and the Controller Firmware must be V16.0.0 or later.

Lockers can be created quickly by using the "Bulk Create Lockers" feature in Locker Bank programming.

See the "Integriti Locker Configuration" document for a full description of Integriti Locker Access Control.

Entity/Feature	Option	Description
Locker		'Add New' or select a Locker to program/edit. NOTE: If planning to use Locker Banks, see "Bulk Create Lockers" below before proceeding with Locker programming.
Name		Program a text name of up to 32 characters in length. The name may include the location of the Locker.
Miscellaneous Options	Lock Auxiliary	Select the lock auxiliary to be associated with this Locker. The lock auxiliary is defined by entering the Module Auxiliary ID. e.g. E03:X09
	Bank	If Locker Banks are utilized, select the Bank that this Locker belongs to. One or more Locker Banks must be created before this option can be programmed.

Locker Bank Programming

Controller Firmware V16.0.0 or later only.

See the "Integriti Locker Configuration" document for a full description of Integriti Locker Access Control.

Entity/Feature	Option	Description
Locker Bank		'Add New' or select a Locker Bank to program/edit.
Name		Program a text name of up to 32 characters in length. The name may include the location of the Locker Bank.
Miscellaneous Options	Allocation Mode	Select the locker allocation mode. i.e. How Lockers are linked to Users. Dynamic modes allow card holders to 'claim' lockers by presenting their card at the Reader. Unlimited: A User can claim any number of Lockers. 1 per User: A User can only claim one Locker in any Locker Bank.
	Dynamic – Unlimited Dynamic – 1 per User (per bank)	
	Pre-Assigned	Pre-assigned mode

	Unlock Time	Program a time value to define how long the lock auxiliary remains on when the Locker is unlocked in static (Pre-assigned) mode.
	Save Aux Review	Allows Locker auxiliary actions to be saved to review.

Bulk Create Lockers

The Locker Bank programming window provides a 'Bulk Create Lockers' wizard button to allow multiple Lockers to be quickly created for the chosen Locker Bank.

Controller Firmware V16.0.0 or later only.

See the "Integriti Locker Control" document for a full description of Integriti Locker Access Control.

Entity/Feature	Option	Description
Locker Bank		Shows the Locker Bank in which the Lockers will be created.
Starting Auxiliary		Select the Module Auxiliary ID for the lock auxiliary of the first locker in this Locker Bank. The lock auxiliaries for the nominated number of Lockers will be sequential auxiliaries/lock auxiliaries starting at the nominated 'Start Auxiliary'.
How Many		Enter the number of Lockers to be created. Do not enter a number that exceeds the capabilities of the system hardware.
Reader Assignment	Assign a Reader to each locker	This options causes the wizard to assign a separate Reader to each Locker. If not enabled, then one Reader will be assigned for the Locker Bank.
	Reader Module	If you do <u>not</u> wish the Readers associated with the selected Lock Auxiliary to be assigned automatically, enter the Module ID of the starting Reader Module you wish to assign.
	Re-purpose existing readers	This option allows the wizard to assign existing Readers to Lockers if they fall within the sequential range of the nominated number Lockers. If not enabled, Readers already assigned for another purpose will be skipped.

Automation and Logic Functions

Entity/Feature	Option	Description
Auxiliary Lists		Create a list of Auxiliaries.
Named Actions		Program/Edit Named Actions.
Action Lists		Enables up to 8 actions to be combined in a single entity.
Macros		Perform complex logic operations.
Air-conditioning		
Comparisons		Program/Edit Comparisons.
Calibrations		
Compound Entities		Allows multiple entities to be combined logically for use as a Qualifier in Permissions.
General Variables		
General Timers		
Automation Points		Defines the relationship between Integriti and entities on 3 rd Party products communicating with Integriti via the BMS Comms Task format. e.g. C-Bus.

Auxiliary Lists. See “Users and Permissions”, “Lists”.

Compound Entities

Entity/Feature	Option	Description
Compound Entity		Select the Compound Entity to program or edit. Compound Entities enable up to eight different Entities to be logically combined for use as: <ul style="list-style-type: none"> - A Qualifier in Permissions. - A Qualifier in an Action or a Named Action. - A trigger in a Named Action. - An entity in a Macro. How cool is that?
Name		Program a text name of up to 32 characters in length. The name may include the purpose of the Compound Entity and/or a summary of the entities associated with it.
Define Entities and Relationships		Up to 8 Entities may be assigned to a Compound Entity. Any relevant entity may be used, except for another Compound Entity or any entities that do not support a Valid/Invalid state. <i>See the table ‘Entity State Valid/Invalid conditions’ in ‘Action Programming’ for guidance.</i> For each Entity assigned, an “Invert” option and logical relationship may be defined. The programming options below are repeated for each of the eight Entities.

Entity Selection		Select an Entity to include in this Compound Entity.
Invert Entity	User Door Door List Area Area List Input Auxiliary Time Period Schedule Holiday	<p>Enable this option if you require the logic for this Entity to be Inverted.</p> <p>Normally the different Entity types will be considered <u>Valid</u> in the state shown in the table below. Enable this option if you require the Entity to contribute a Valid condition to the Compound Entity when in the <u>opposite</u> state.</p> <p>Programmed. Locked and Closed. All Locked and Closed. Armed All Armed Sealed On Valid Valid Valid</p>
Logical Relation	And Or eXclusive OR (XOR)	<p>Select the logical relationship of this Entity to the next Entity.</p> <p>This Entity is ANDed with the following Entity This Entity is ORed with the following Entity XOR logic is applied to these Entities. i.e. The result is Valid if <u>either</u> entity is Valid and Invalid when <u>both</u> Entities are either Valid or Invalid.</p> <p>The logic is applied in the order in which it is entered. The first two Entities take the first Logical Relation (operator). The second Logical Relation is applied to the result of the first two entities and the third entity. The third Logical Relation is applied to the previous result and the fourth entity, etc. Imagine A, B, C, D, and E are entities 1 to 5 respectively and 1, 2, 3 and 4 are Logical Relations 1 to 4 respectively. The expression would be: (((A 1 B) 2 C) 3 D) 4 E).</p>

Foreign Entities

Entity/Feature	Option	Description
Foreign Entity		<p>Select the Foreign Entity to program or edit.</p> <p>Foreign Entities enable Entities from one Controller to be used in operations on another Controller. <i>See "Peer-To-Peer" in General Controller Programming for details.</i></p>
Name		<p>Program a text name of up to 32 characters in length. The name may include the purpose of the Foreign Entity and/or a summary of the entities associated with it.</p>
Miscellaneous Options	Target Entity	Select an Entity from another Controller that will be represented by this Foreign Entity.

Automation Points

An Automation Point defines the relationship between Integriti and entities on 3rd Party products that interface to Integriti via one of the following Comms Task formats:

Comms Task Format	3 rd Party products
BMS	C-Bus
Intrepid	Intrepid Fence Inputs

Comms Task Format	3 rd Party products
Modbus	Modbus

Entity/Feature	Option	Description
Automation Point		Select the Automation Point to program or edit.
Name		Program a text name of up to 32 characters in length.
BMS Type	<p>C-Bus Lighting</p> <p>C-Bus Custom</p> <p>Intrepid Fence Input</p> <p>Modbus</p>	<p>Select the Automation Type required for the interface.</p> <p>Once a type is selected, program the ‘Common Options’ below and then refer to the type-specific programming options that follow.</p> <p>Selects the C-Bus “Lighting” Application.</p> <p>Selects the C-Bus Custom type which allows an Application ID and parameters to be programmed for C-Bus Applications other than lighting.</p> <p>Selects a Fence Input on an Intrepid Fence Controller system. Controller Firmware V4.1.0 or later only. V4.3.0 or later is recommended.</p> <p>Selects a Modbus entity. Controller Firmware V4.3.2 or later only. V16.0.5 or later is recommended.</p>
<p>Common Options.</p> <p>NOTE: These options are common to all BMS Types.</p>	<p>Update Entity</p> <p>C-Bus</p> <p>Intrepid Fence Input</p> <p>Modbus</p>	<p>Select this option if the Integriti Mapped Entity is to be controlled by the nominated BMS entity.</p> <p>In the case of C-Bus, the Integriti entity will be controlled by the C-Bus Group Address according to the “Ramp Threshold” option programmed above.</p>
	Mapped Entity	<p>Select the Integriti entity to be mapped to the BMS entity.</p> <p>Whenever this entity changes state, an update may be sent to the BMS according to the command options programmed above for the type of BMS selected.</p>
	Qualifier	Select a qualifier entity if required. If a qualifier is selected, changes in state on the Mapped Entity will be ignored unless the Qualifier is valid.
	Associated Action	If required, select an action to perform when the Mapped Entity is asserted as a result of a change of state of the BMS entity.

C-Bus Lighting

C-Bus Lighting Options	Group	Program the C-Bus Group Address for this Automation Point. Commands will be sent to this Group Address.
	Ramp Threshold	Program a Ramp Threshold value between 0 and 255 to define when the C-Bus entity will alter the state of the Integrati entity. When the level on the nominated C-Bus Group Address: - Falls below this value, the mapped Integrati entity is deasserted. - Rises to this value or higher, the mapped Integrati entity is asserted. The “Update Entity” option described below must be enabled.
	Assert Command On Off Stop Ramp Ramp	Select the C-Bus command to perform when the nominated Integrati entity is asserted.
	Assert Ramp Rate	Select the ramp rate to be used when the “Ramp” command is selected above. This is the period that it will take for the nominated C-Bus entity to ramp from its current level to the “Ramp Level” specified below. 16 pre-defined ramp rates are available. Instant (0s) and 15 periods ranging from 4 Seconds to 17 Minutes.
	Assert Ramp Level	Program a Ramp Level to be used when the “Ramp” command is selected above. This is the final level that the C-Bus entity will ramp to.
	Deassert Command	Select the C-Bus command to perform when the nominated Integrati entity is deasserted.
	Deassert Ramp Rate	Select the ramp rate to be used when the “Ramp” command is selected for the Deassert command above. This is the period that it will take for the nominated C-Bus entity to ramp from its current level to the “Ramp Level” specified below. 16 pre-defined ramp rates are available. Instant (0s) and 15 periods ranging from 4 Seconds to 17 Minutes.
	Deassert Ramp Level	Program a Ramp Level to be used when the “Ramp” command is selected for the Deassert command above. This is the final level that the C-Bus entity will ramp to.
	Custom App Code	Allows a different Application Code to be sent/monitored for this Automation Point. A Custom Application Code may be entered as a Decimal number. If left at 0, the default “Lighting” App Code will be used.
C-Bus Route	First Route Hop Second Route Hop Third Route Hop Fourth Route Hop	These options are available to allow C-Bus commands to be sent to different C-Bus networks across C-Bus Network Bridges. Using these options it is possible to specify up to four Network Bridges for the command to traverse.

Common Options	Update Entity Mapped Entity Qualifier Associated Action	<i>See 'Common Options' above.</i>
----------------	--	------------------------------------

C-Bus Custom

C-Bus Custom Options	Custom App Code	Commands will be sent with this C-Bus Application Code. The value is programmed in hexadecimal format. These options should only be attempted by experienced C-Bus integrators. Distributor/Factory Technical Support is not available for this feature.
	Assert String	Program a C-Bus message that will be sent when the Integriti Mapped entity is Asserted. Do not include the Application Code or Route. The string will automatically be prefixed with these according to the settings in those options.
	Deassert String	Program a C-Bus message that will be sent when the Integriti Mapped entity is Deasserted. Do not include the Application Code or Route. The string will automatically be prefixed with these according to the settings in those options.
C-Bus Route	First Route Hop Second Route Hop Third Route Hop Fourth Route Hop	These options are available to allow C-Bus commands to be sent to different C-Bus networks across C-Bus Network Bridges. Using these options it is possible to specify up to four Network Bridges for the command to traverse.
Common Options	Update Entity Mapped Entity Qualifier Associated Action	<i>See 'Common Options' above.</i>

Intrepid Fence Input

Miscellaneous Options.	Module ID	This option defines the ID of the Intrepid Module that hosts this Input.
	Starting Input	
	Ending Input	
Common Options	Update Entity Mapped Entity Qualifier Associated Action	<i>See 'Common Options' above.</i>

Modbus

Miscellaneous Options	Coil Discreet Input Input Register Holding Register	Program the type of this point in the Modbus system.
	Mapping Type None Inputs Auxiliaries	When connected to a Virtual Module, these types will be mapped.
	Slave Address	
	Data Address	
	Number of Mapped Points	
Common Options	Update Entity Mapped Entity Qualifier Associated Action	<i>See 'Common Options' above.</i>

Named Actions

Entity/Feature	Option	Description
Named Action		Select the Named Action to program or edit. Named Actions allow Users to perform predefined actions from a Terminal. Options are also provided to allow the Named Action to be controlled by another Entity instead of, in addition to, User control.
Name		Program a text name of up to 32 characters in length.
Action to Take		Select the Entity Type to be controlled or operation to be performed by this action. Once an Entity Type or operation is selected, additional fields are displayed to program the Action details and any action Qualifier parameters. <i>See Action Programming in "Generic Programming Operations" for more details.</i>

Optional Trigger		<p>Select an Entity that will trigger this Named (Predefined) Action. e.g. An Input, Time Period, Auxiliary, Door, etc. that will trigger the Named Action.</p> <p>NOTES:</p> <ul style="list-style-type: none"> Any entity can be used as the trigger entity. The trigger entity and the action qualify entity (if defined) are continuously tested to see whether the action needs to be asserted or de-asserted. On power-up, after 20 seconds, all Named Actions with trigger entities will assert or de-assert the action depending on the combined state of the trigger entity and the action qualify entity. Action processing only checks the action qualify entity on assert, not de-assert. If the trigger entity is a User or Permission Group, then: <ul style="list-style-type: none"> a) The Named Action is asserted at the time of User logon. b) Qualifications in the 'Action to Take' programming can only be used if Controller Firmware is V4.0 or later.
User Interface	<p>Interface Style</p> <p>None On / Off Open / Close Air Conditioning Auxiliary Control Trigger Secure</p>	<p>Select the User Interface style to be used when this Named (Predefined) Action is operated manually via a Terminal. i.e. What the icons look like or what terminology is used to show the state of the action.</p> <p>No style On / Off Open / Close Air-conditioning Auxiliary Trigger Secure</p>
	Sense Entity	<p>Select the Entity to display the state of this Named Action.</p> <p>e.g. An Auxiliary or a Zone Input.</p> <p>Typically this entity is simply the target of the action, but it could be something else. e.g. A Relay controls a motor and a Zone Input is wired to a tachometer which senses when the motor is running. Instead of having the state of the auxiliary display the state, you could use the Input to give you a truer display of state so that you know when the motor is actually spinning.</p> <p>Note that for some actions there is no entity available to represent the current state of the action. e.g. A Door Override state.</p>
	Invert Sense Entity	<p>Allows the result of the Sense Entity to be inverted.</p> <p>e.g. If an Auxiliary is chosen as the Sense Entity, then inverting the Sense Entity will allow the Auxiliary to be turned On when the Action is de-asserted instead of when asserted. e.g. If the NC contacts instead of the NO contacts of a relay are used, so on means off, etc.</p>

	Allow Logged off access.	The Named Action can be controlled from a Terminal without the User logging on.
User Access	Action Groups	<p>This option allows Named Actions to be grouped together in up to 16 Action Groups for the purpose of defining which Users and Entities are allowed to control which Actions.</p> <p>The Named Actions allowed to be controlled from an LCD or Graphic Terminal, or by particular Users or Types of Users are defined via similar screens in Menu Group programming. The Menu Group can then be assigned to an LCD Terminal or Graphic Terminal, a User and/or Permission Group.</p> <p>Select which of the 16 Action Groups this Named Action will belong to.</p>

Action Lists

Entity/Feature	Option	Description
Action List	Controller Firmware V3.2.1 or later.	<p>Select the Action List to program or edit.</p> <p>Action Lists enable up to eight separate Actions to be combined in a single entity.</p> <p>NOTE: If upgrading from a firmware version prior to V3.2.1, a Controller memory default will need to be performed to add Action Lists to the memory configuration.</p>
Name		<p>Program a text name of up to 32 characters in length. The name may include the purpose of the Action List and/or a summary of the actions associated with it.</p>
Define Actions		<p>Up to 8 Actions may be assigned to an Action List.</p> <p>For each Action, once an Entity Type or operation is selected, additional fields are displayed to program the Action details and any action Qualifier parameters.</p> <p><i>See Action Programming in “Generic Programming Operations” for more details.</i></p>

Macros

Macros can be used to perform complex operations that are not practical to achieve via one or more of the other logic and automation features of the product.

Before programming a Macro, please check that the operation cannot be more easily achieved by programming one or more other features such as Input Optional Actions, Area Actions, Named Actions, Action Lists, Compound Entities, General Variables and General Timers.

Entity/Feature	Option	Description
Macro		Select the Macro to program or edit.
Name		<p>Program a text name of up to 32 characters in length. The name may include the purpose and/or some details of the Macro.</p>

<p>Type</p>	<ul style="list-style-type: none"> - Do an Action - Do an Action when the Expression Changes - Goto <label> If - Pause for Time - Define a Label - Set Entity to Expression - Wait for Condition - Execute Modified Action - End Current Macro 	<p>Select the Type of Macro to program.</p>
<p>Action</p>		<p>If the Macro Type is:</p> <ul style="list-style-type: none"> - Do an Action - Do an Action when Expression changes - Execute Modified Action... <p>Select the Entity Type to be controlled by this action.</p> <p>Once an Entity Type is selected, additional fields are displayed to program the Action details.</p> <p><i>See Action Programming in “Generic Programming Operations” for more details.</i></p>
<p>Expression</p>		<p>If the Macro Type is:</p> <ul style="list-style-type: none"> - Do an Action when Expression changes - Goto <label> if... - Pause for Time... - Set Entity to Expression - Wait for Condition <p>Program the Expression. Expressions can evaluate to true or false, or to a number, depending on the context in which they are used.</p>
<p>Label</p>		<p>If the Macro Type is:</p> <ul style="list-style-type: none"> - Goto <label> if... - Define a Label <p>Program the Label.</p>
<p>Entity to Set</p>		<p>If the Macro Type is:</p> <ul style="list-style-type: none"> - Set Entity to Expression <p>Select the Entity.</p> <p>Nearly all entities can return a numerical value. For instance an Input can hold a count value. This statement changes the entities value to the value returned by the expression, which could be a constant, another entity, or a maths formula involving any of these. This is primarily how GVars get set to a value.</p>

Entity 1 Entity 2 Entity 3 Entity 4		<p>If the Macro Type is:</p> <ul style="list-style-type: none"> - Execute Modified Action... <p>Select up to 4 Entities to define the numeric parameters for the action.</p> <p>The numeric value returned by the first entity will set the first numeric parameter for the action, the second entity the second parameter. So if the action were “control an auxiliary” and the first entity is a count Input, the on time of the aux action would be determined by the count value in the Input.</p>
Comment		<p>If the Macro Type is:</p> <ul style="list-style-type: none"> - Do an Action - Do an Action when Expression changes - Goto <label> if... - Pause for Time... - Define a Label - Set Entity to Expression - Wait for Condition - Execute Modified Action... - End Current Macro <p>You may enter a comment in this field.</p> <p>Just like comments in programming language, allows the programmer to document the intended functionality of each line.</p>
Statements		

General Variables

Entity/Feature	Option	Description
General Variable		<p>Select the General Variable to program or edit.</p> <p>General Variables provide a place to store a value and perhaps do something when that value reaches a certain threshold.</p>
Name		Program a text name of up to 32 characters in length.
Test Value		<p>Program a Test Value.</p> <p>The Variable will be True if the General Variable value is greater than this number.</p>
Calibration		<p>Select a Calibration for this General Variable to define the formatting of the General Variable.</p> <p>Calibrations are programmed separately.</p>

General Timers

Entity/Feature	Option	Description
----------------	--------	-------------

General Timer		Select the General Timer to program or edit. Normally a general timer is valid, which means it can trigger or qualify an action. There is an action which can set the time for a timer. When set, the timer is invalid, so would de-assert or not qualify an action, and begins counting down its timer. When its timer expires, it goes valid again, so would assert or qualify another action.
Name		Program a text name of up to 32 characters in length. The name may be used to describe the purpose and/or period of this timer.

Calibrations

Calibrations define processing and display parameters and options for analogue inputs in an Integriti system.

A number of default Calibrations are provided to cover common requirements as follows:

Configuration	Description/Purpose.
Raw Value	Raw value 00000 – 65535.
IR 994089 Temp Sensor	Inner Range Serial Temperature Sensor. 0 to +40 °C.
C3K Alog 0-5 Volts	Concept Analogue Module Input configured for voltage sense.
C3K Alog 4-20mA as mA	Concept Analogue Module Input configured for current loop.
C3K Alog 4-20mA as %	Concept Analogue Module Input configured for current loop displayed as a percentage.
GT Light %	Integriti Graphic Terminal light sensor.
GT Temp DegC	Integriti Graphic Terminal temperature sensor. -10 to +50 °C.
Unibus Alog 0-10 Volts	Integriti Unibus Analogue board Input configured for voltage sense.
Unibus Alog 4-20mA as mA	Integriti Unibus Analogue board Input configured for current loop.
C3k Alog IR 994089 Freezer Mode	Inner Range Serial Temperature Sensor. -55 to +70 °C. (V3.3.13 / V4.1 or later only)

Notes on Analogue Sensors.

- At present, support for Current Loop analogue devices and the Inner Range Serial Temperature Sensor is only available via the Concept Analogue Module.
- Selection and adjustment of a third-party analogue sensor for a particular purpose (e.g. temperature, humidity, gas sensor, etc.) is normally done by a technician specialised in that field. e.g. A BMS technician or a contractor qualified in instrumentation. Analogue input devices typically consist of the sensor and a transceiver. The transceiver converts the sensor output to an industry standard voltage or current output and often allows the technician to also calibrate the transceiver output (0-5V or 4-20mA) over the range of sensor values that are of interest to the client (which might be less than the possible range of the sensor) in order to get the best measurement resolution and accuracy. Once a suitable analogue input device has been chosen and calibrated, the technician can provide details of the output parameters to the Integriti installer so that an Integriti Calibration can be programmed.
e.g. If a current loop device; The values represented by 4mA and 20mA.
If a voltage device; The values represented by 0V and 5V.

Summary descriptions of the parameters and options are provided below.

See the “Integriti System Configuration Handbook” for full details.

Entity/Feature	Option	Description
Calibration ID		Select the Calibration to program or edit.
Name		Program a text name of up to 32 characters in length.
Calibration	Offset	Offset to add to Raw multiplied to Gain.
	Overall Shift	The entire result will be divided by 2 to the power *this value*
	Calibrate Calculation	This is the calculation that will be used in this Calibration where 'R' is the raw value. This equation is derived from the parameters programmed in the options above.
Calibration Linear Component	Gain	Factor by which the Raw value is multiplied.
	Shift	Denominator (as a power of 2) for the Gain / Offset calculation.
	Linear effective Gain	The gain that would achieve the same result (without the shift)
Calibration Quadratic Component	Quadratic Gain	Factor by which the Raw value is multiplied.
	Quadratic Shift	Denominator (as a power of 2) for the Gain / Offset calculation.
	Quadratic Effective Gain	The gain that would achieve the same result (without the shift).
Calibration Cubic Component	Cubic Gain	Factor by which the Raw value is multiplied.
	Cubic Shift	Denominator (as a power of 2) for the Gain / Offset calculation.
	Cubic Effective Gain	The gain that would achieve the same result (without the shift).

Display	Format / Scale	<p>Used to determine how the analogue value is to be displayed. It includes the scaling, sign if required and text for the desired units.</p> <p><u>Example 1.</u> units = COMMON_UNIT_MILLIKELVIN and we want to display between -30.0 and +10.0 degrees C. -30C=243000, 0C=273000, +10C=283000 Format string = "K3 Z273000 S2.1 DegC" Where: K3 - indicates scale is 3 decimal places. Z273000 - indicates the sign transition is 273000 COMMON_UNIT_MILLIKELVIN. S - Means display sign. 2.1 - Indicates the format. DegC - Is displayed as is.</p> <p><u>Example 2.</u> units = COMMON_UNIT_MILLIVOLTS and we want to display between 00.00 and 99.99 Volts. Format string = "K3 F2.2 Volts" Where: K3 - Indicates scale is 3 decimal places. F - Means do not display sign. 2.1 - Indicates the format. Volts - Is displayed as is.</p>
	Display String	Units or gauge ID text to display.
	Minimum String	Minimum value in XXX.YYY format, matching scale_string.
	Maximum String	Maximum value in XXX.YYY format, matching scale_string.

Comparisons

Entity/Feature	Option	Description
Comparison to Edit		Select the Comparison to program or edit. Comparisons provide the ability to trigger actions when certain analogue or count values are reached on an Input.
Comparison Name		Program a text name of up to 32 characters in length.
Input and Thresholds	Input to Monitor	Select an Analogue or Counter type Input to Monitor.
	Min Threshold	Enter the minimum threshold value. The un-calibrated Analogue or Count value representing the required threshold must be used.
	Max Threshold	Enter the maximum Max Threshold value.

Inputs to Trigger	Input for Min Threshold	<p>Select an optional Input to Trigger for Min Threshold.</p> <p>The alarm state of the selected Input will be asserted if the monitored Input is above Min Threshold. The alarm state will be de-asserted if the monitored Input is below or equal to Min Threshold.</p> <p>An Input trigger will be required if you wish the event to be reported.</p>
	Input for Max Threshold.	<p>Select an optional Input to Trigger for Max Threshold.</p> <p>The alarm state of the selected Input will be asserted if the monitored Input is above Max Threshold. The alarm state will be de-asserted if the monitored Input is below or equal to Max Threshold.</p> <p>An Input trigger will be required if you wish the event to be reported.</p>
Min Threshold Action.	Action 1	<p>Select Entity Type for Min Threshold Action.</p> <p>Once an Entity Type is selected, additional fields are displayed to program the Action details.</p> <p><i>See Action Programming in “Generic Programming Operations” for more details.</i></p>
	When Above Min Threshold. None Assert De-assert	<p>Choose what to do for Action1 when Above Min Threshold.</p> <p>No state triggered when above Min Threshold. State Asserted when above Min Threshold. State De-asserted when above Min Threshold.</p>
	When Below Min Threshold. None Assert De-assert	<p>Choose what to do for Action1 when Below Min Threshold.</p> <p>No state triggered when below Min Threshold. State Asserted when below Min Threshold. State De-asserted when below Min Threshold.</p>
Max Threshold Action.	Action 2	<p>Select Entity Type for Max Threshold Action.</p> <p>Once an Entity Type is selected, additional fields are displayed to program the Action details.</p> <p><i>See Action Programming in “Generic Programming Operations” for more details.</i></p>
	When Above Max Threshold. None Assert De-assert	<p>Choose what to do for Action2 when Above Max Threshold.</p> <p>No state triggered when above Max Threshold. State Asserted when above Max Threshold. State De-asserted when above Max Threshold.</p>
	When Below Max Threshold. None Assert De-assert	<p>Choose what to do for Action2 when Below Max Threshold.</p> <p>No state triggered when below Max Threshold. State Asserted when below Max Threshold. State De-asserted when below Max Threshold.</p>

Air-conditioning

Entity/Feature	Option	Description
Air-conditioner		Select the Air-conditioning Unit to program or edit. The Air-conditioning feature provides a low-level interface to multi-zone air-conditioning systems utilizing Zone Inputs to monitor thermostats and Auxiliary Outputs for Compressor, Zone Damper, Reverse Cycle, Fan, Fresh Air Damper and Bypass Damper control. Optional User control is available via nominated LCD or Graphic Terminals.
Name		Program a text name of up to 32 characters in length.
Temperature Sensors		Select the Inputs to be used for Temperature Sensing. Up to 8 Inputs may be selected, one for each Air-conditioning Zone. The Inputs do not have to be sequential, so each Temperature Sensor can be wired to a spare Zone Input on the nearest module.
Damper Auxiliaries		Select the Auxiliaries to be used to control the Zone Dampers. Up to 8 Auxiliaries may be selected, one for each Air-conditioning Zone. The Auxiliaries do not have to be sequential, so each Damper can be controlled by a relay on the nearest module that supports general purpose Auxiliary outputs.
Compressor Auxiliary		Select the Auxiliary to be used to control the Compressor.
2 nd Compressor Auxiliary		Select an optional 2 nd Compressor Auxiliary to be used to control a Compressor.
Reverse Cycle Auxiliary		Select the Auxiliary to be used to control Reverse Cycle On/Off.
Fan Auxiliary		Select the Auxiliary to be used to control the Fan.
Fresh Air Damper Auxiliary		Select the Auxiliary to be used to control the Fresh Air Damper.
Bypass Damper Auxiliary		Select the Auxiliary to be used to control the Bypass Damper.
Minimum Compressor ON Time.		Determines the Minimum Compressor On Time. Enter a value in Hours, Minutes and Seconds. A Value of up to 1 Hr, 49 Min and 13 Seconds can be entered.
Minimum Compressor OFF Time.		Determines the Minimum Compressor Off Time. Enter a value in Hours, Minutes and Seconds. A Value of up to 1 Hr, 49 Min and 13 Seconds can be entered.
Damper Time		Determines the Damper On Time. Enter a value in Hours, Minutes and Seconds. A Value of up to 1 Hr, 49 Min and 13 Seconds can be entered.
Return Air Zone		Defines the Air-conditioning Zone where the Return Air Damper is located.

Minimum Zones for Bypass		Defines the minimum number of zone dampers that can be open before the compressor bypass damper will be closed. If less than this number of zone dampers are open, the bypass damper output will turn off thus opening the bypass damper to lessen air flow from the fan. If this option is left at 0, the bypass damper will remain closed.
Dead-band		Defines the dead-band between heating and cooling mode in degrees Celcius.



Inner Range Pty Ltd
ABN 26 007 103 933

1 Millennium Court, Knoxfield, Victoria 3180, Australia
PO Box 9292, Scoresby, Victoria 3179, Australia
Telephone: +61 3 9780 4300 Facsimile: +61 3 9753 3499
Email: enquiries@innerrange.com Web: www.innerrange.com

